



No
Diagram
Available

Parts List
Only


Ref #	Part Number	Qty	Description
	66977		Bar
	65120M		Chain
	51445A		Combination Wrench-Screwdriver
	69048		Owner's Manual
	52958		Spike
	50134		Piston Assy - 0.020 in. oversize
	55125		Ring Set - 0.020 in oversize
	36248		Wrench - Spark plug
	63165		Spark Arrester
	65712		Timing Guide



Ref #	Part Number	Qty	Description
1	104393	1	Screw - Pan hd 10-24 x 3/8
2	63091	1	Cover Assy - Air cleaner
3	63090	1	Gasket - Air cleaner cover
4	52961	1	Screen - Air cleaner
5	102586	2	Screw - Hex hd 10-24 x 2
6	36388	2	Lockplate
7	68982	1	Plate Assy - Air cleaner
8	104171	1	Nut - Speed
9	63090	1	Gasket - Air cleaner
10	68132	1	Gasket - Carburetor
	68981	1	Carburetor Assy
11	47690	1	Screw - Choke plate
12	69505	1	Plate - Choke
13	69504	1	Shaft Assy - Choke
14	100302	1	Ball - Detent
15	67504	1	Spring - Detent
16	68106	1	Screw - Idle speed
17	67502	1	Spring - Idle speed screw
18	68104	1	Needle - High speed adjustment
19	68105	1	Needle - Idle adjustment
20	67502	2	Spring - Needle
21	47690	1	Screw - Throttle plate
22	67487	1	Plate - Throttle
23	68211	1	Ring - Retaining
24	69503	1	Shaft Assy - Throttle
25	69507	1	Spring - Throttle return
26	70798	4	Screw - Diaphragm cover
27	67485	1	Cover - Diaphragm
28	67499	1	Diaphragm - Metering
29	67496	1	Gasket - Diaphragm
30	67500	1	Screw - Lever pin
31	67508	1	Pin - Lever
32	67509	1	Lever - Metering
33	67503	1	Spring - Lever
34	67491	1	Valve - Needle
35	69502	1	Body Assy - Carburetor
36	67492	1	Plug - 3/8
37	69506	1	Plug - 5/16
	69508		Repair Kit




Ref #	Part Number	Qty	Description
1	104815	3	Screw - Hex hd 10-24 x 7/8
2	101191	3	Nut - Hex 10-24
	60130	1	Starter Assy
3	104396	2	Screw - Pan hd 10-24 x 3/4
4	57232	1	Plate - Starter handle
5	60647	1	Cover - Starter
6	57231	1	Cup - Starter handle
7	57230	1	Handle - Starter
8	101136	1	Rivet - Rd hd 3/32 dia x 5/16
9	28716	1	Rope - Starter
10	57790	1	Ratchet - Starter
11	57535	2	Bushing - Starter base
12	51665	1	Spring - Rewind
13	57792	1	Drum - Starter
14	60646	1	Base - Starter
15	50581A	1	Guard - Sawdust
16	57565	1	Cover Assy - Spark plug
17	57184B	1	Housing Assy - Fan
18	103819	1	Rivet
19	24236	2	Washer
20	50818	1	Spring - Switch
21	50817	1	Button - Switch
22	101179	1	Nut - Hex 7/16-20
23	101270	1	Washer - 7/16
24	68282	1	Flywheel & Pawl Assy
25	36144B	2	Pin - Starter pawl
26	24093	2	Pawl - Starter
27	50582	2	Spring - Pawl
28	103879	1	Key - Woodruff #3
29	102289	3	Screw - Hex hd 10-24 x 3/4
30	102189	3	Washer - #10
31	104815	1	Screw - Hex hd 10-24 x 7/8
32	50671	1	Retainer - Breaker cover
33	50588A	1	Cover - Breaker box
34	65584	1	Gasket - Breaker box
35	55494	2	Screw Assy - Sealing #10
36	55492	2	Washer - Sealing
37	100251	1	Nut - Hex 8-32
38	100057	1	Lockwasher - Internal #8
39	50381A	1	Insulator - Breaker terminal
40	103928	1	Screw - 8-32 x 1/2 (SEMS)
41	50076A	1	Breaker Assy
42	103928	1	Screw - 8-32 x 1/2 (SEMS)
43	50074	1	Condenser
44	51240	1	Gasket - Cover
45	100824	1	Bearing - Ball
46	57126A	1	Crankcase Cover Assy
47	50663	1	Seal - Oil
48	54184	1	Wiper - Felt
49	101326	2	Nut - Hex 10-24
50	101326	2	Nut - Hex 10-24
51	55670	1	Grommet



Ref #	Part Number	Qty	Description
1	104395	1	Screw - Pan hd 10-24 x 5/8
2	101191	1	Locknut - 10-24
3	100604	1	Jamnut - 1/2-20
4	110010	1	Washer - Spring 1/2
5	102861	2	Screw - Hex hd 1/4-20 x 5/8
6	103242	1	Nut - Hex 1/4-20
7	52804	1	Frame
8	103729	2	Nut - Hex 3/8-24
9	66275	1	Clamp Assy - Bar
10	52828	1	Nut - Adjusting
11	100640	1	Locknut - 1/4-28
12	102813	1	Washer - Spring
13	102843	1	Washer - 1/4
14	103919	1	Bolt - Fil hd 1/4-28 x 2-1/2
15	66276	1	Clamp - Bar
16	52837	1	Cover - Clutch
	52844	1	Clutch Assy
17	63999	2	Spring - Clutch
18	52845	2	Shoe - Clutch
19	52846	1	Rotor - Clutch
20	101270	1	Washer - 7/16
21	52878	1	Drum, Sprocket & Bushing Assy
22	50128	1	Bushing
23	50132	1	Washer - Sprocket
24	50742	2	Clamp - Hose
25	52808	1	Hose - Fuel
26	101330	1	Nut - Hex 5/16-18
27	100443	1	Lockwasher - 5/16
28	65382	1	Filter Assy - Oil tank
29	62779	1	Gasket - Filter
30	52822	1	Gland - Oiler
31	52887	1	Fitting - Fuel outlet
32	62776	1	Tank Assy
33	52923A	2	Cap - tank
34	52964	2	Gasket
35	68986	1	Rod - Throttle
36	52888	1	Screw - Trigger
37	52823	1	Trigger
38	101191	1	Nut - Hex 10-24
39	101449	1	Screw - Rd hd 8-32 x 5/8
40	65381	1	Pump Assy - Oiler
41	110208	4	Screw - Flat hd 1/4-20 x 3/4 (SEMS)
42	52957	2	Bolt - Bar mounting
43	68007	1	Handle Assy - Saw
44	110180	1	Nut - Speed
45	68005	1	Tube Assy - Oiler
46	52876	1	Sleeve - Tube
47			Carburetor & Air Filter See "Carburetor & Air Filter" illustration and parts list.
48	104815	3	Screw - Hex hd 10-24 x 7/8
49	103947	1	Screw - 10-24 x 1 (SEMS)
50	52883	1	Brace - Frame

Ref #	Part Number	Qty	Description
51			Fan Housing, Starter, Flywheel & Crankcase Cover See "Fan Housing, Starter, Flywheel & Crankcase Cover" illustration and parts list.
52	104840	2	Screw - Hex hd 10-24 x 3/4
53	50115	1	Pipe - Exhaust
54		1	Powerhead See "Powerhead" illustration and parts list.
55	69603	1	Instruction Decal



Ref #	Part Number	Qty	Description
1	102121	4	Screw - Hex 1/4-20 x 7/8
2	100005	4	Washer - 1/4
3	104476	2	Screw - Hex hd 8-32 x 5/16
4	51480	1	Lockplate
5	48591	1	Guard - Reed
6	48593	1	Valve - Reed
7	68979	1	Adapter - Carburetor
8	65578	1	Gasket - Carburetor adapter
9	104815	2	Screw - 10-24 x 7/8 (SEMS)
10	100352	2	Washer - #10
11	51253	2	Retainer - Coil
12	51251	1	Lamination Assy
13	57643A	1	Kit - Coil & Terminal Assy
14	101883	1	Wire Assy - Ground
15	57648	1	Wire - Spark plug
16	55060	1	Boot - Spark Plug
17	55061	1	Connector
18	55617	1	Nipple - Spark plug wire
19	57225	1	Wire Assy - Primary
20		1	Plug - Spark 14 mm
21	103814	4	Screw - 10-24 x 5/8 (SEMS)
22	8354	1	Cover - Transfer port
23	48605	1	Insulator - Reed plate
24	50206	1	Piston Assy - Standard
25	55123	1	Ring Set - Standard piston
26	50133	2	Ring - Retaining
27	47903	1	Connecting Rod Assy
28	60210A	2	Screw - Socket hd 10-32 x 5/8
29	102742	24	Roller - Needle
30	50207A	1	Pin - Piston
31	50659A	1	Crankshaft
32	52886A	1	Cylinder Crankcase Assy
33	104128	1	Seal - Oil
34	104129	1	Bearing - Needle
35	18556A	6	Retainer - Nut
36	105394	6	Nut - Hex 1/4-20
37	28053	2	Retainer - Nut
38	101326	2	Nut - Hex 10-24
39	110179	2	Plug - Expansion
40	53652	1	Gasket - Exhaust