



Ref #	Part Number	Qty	Description
1	210170	1	Engine - 10 H.P.
2	210109	1	Cradle - Lower Member Assembly
3	210051	2	Cradle - Top Member
4	210091	2	Cross Member - Upper
5	210092	8	Gusset
6	210014	2	Channel - Engine Mounting
7	210026	1	Bracket - Generator Mounting
8	210021	4	Isolator
9	210175	1	Adapter - Engine
10	210176	1	Generator Adapter Assembly
11	210177	1	Stator Assembly - Wound
12	210102	1	Rotor Assembly - Wound
13	210265	1	End Bell Assembly
13			Engine Adapter to Engine Torque Value 320-400 in./lbs.
14	210266	1	Hood - Receptacle Box
15	210037	1	Backplate
16	210542	1	Faceplate - Silkscreened
17	210049	1	Adapter Shaft
18	210050	1	Stud
19	210095	1	Sleeve - Generator Shaft
20	210096	1	Nut - Internal Wrenching
21	210182	1	Bracket - Solenoid
22	210142	1	Bracket - Throttle
23	210538	1	Solenoid Cover
24	210147	1	Solenoid Coil Assembly
25	21947		Bracket - Starter Switch
26	21948		Starter Switch
27	21909		Battery Cable
27			Corner Stud Torque Value 55-65 in./lbs.
28	22115		Starter Cable
29	210163	1	Nipple - Close
30	210166	1	Locknut 1" Conduit
31	210164	1	Fitting - 45° Elbow
32	210215	1	Bracket - Lift
33	210516	1	Silicon Rectifier
34	21715	1	Receptacle - 3 Prong Twist Lock
35	210063	1	Receptacle - 4 Prong Twist Lock
36	210048	1	Bridge Rectifier
37	210019	2	Circuit Breaker
38	21971	1	Switch, DPDT
39	22022	1	Switch, SPST
40	21622	1	Receptacle - Duplex
41	21628	1	Receptacle - Duplex
41			Electrical Box Assembly Torque Value 18-20 in./lbs.
42	210541	1	Wire Kit
43	21898	8	Screw, Phillips Head Machine No. 6-32 x 1/2
44	210056	1	Screw, Pan Head Machine No. 8-32 x 3/4
44			Generator Adapter to Engine Adapter Torque Value 85-95 in./lbs.
45	22049	10	Screw, Thread Forming No. 8-32 x 3/8
46	21020		Screw, Hex Head Cap - 1/4-20 x 3/4
47	210046	4	Screw, Hex Head Cap - 1/4-20 x 6-1/2
48	210128	1	Screw, Hex Head Cap - No. 8-32 x 3/8

Ref #	Part Number	Qty	Description
49	210172	4	Screw, Hex Head Cap - 3/8-16 x 1/2
49			Rotor Assembly Bolt Torque Value 120-180 in./lbs.
			Engine Cylinder Head Bolt Torque Value 175-200 in./lbs.
50	21003	2	Screw, Hex Head Cap - 3/8-16 x 1
51	21647	1	Screw, Hex Head Cap - 5/16-18 x 1
52	210020	4	Screw, Socket Head Cap - 7/16-14 x 1
53	210017	4	Bolt, Hex Tap - 3/8-16 x 7/8
54	210083	12	Bolt, Curved Head - 5/16-18 x 1-1/2
55	21657	1	Starwasher - 5/16
56	210087	4	Lockwasher - No. 6
57	210129	1	Lockwasher - No. 8
58	21657	1	Lockwasher - 5/16
59	21658	4	Lockwasher 1/4
60	21130	14	Lockwasher - 3/8
61	210088	4	Nut - Acorn - No. 6-32
62	21654	1	Wingnut - 5/16-18
63	21203	4	Nut - Hex - 1/4-20
64	22024	1	Idle Control Module
65	210245	10	Nut - Hex - 3/8-16
66	210279	3	Nut - Jam - 5/16-18
67	210084	4	Screw, Hex Head Cap - 3/8-16 x 1-1/2
68	21766	8	Nut - Keps - No. 6-32
69	21675	1	Nut - Keps - No. 8-32
70	21653	13	Nut - Keps - 5/16-18
71	21851	1	Grommet - Strain Relief
72	21997	1	Label Ground
73	210297	1	Bearing, Roller
74	210298	1	Capacitor
75	210299	1	Bracket, Capacitor Mounting
76	210300	4	Screw, Tapping - Hex Head - No. 6 x 3/8
77	210301	1	Guide, Brush
78	210302	2	Brush
79	210303	1	Terminal, Tab
80	210304	1	Screw, Tapping - Hex Head - No. 6 x 5/8
81	210305	2	Terminal, Tab
82	210306	1	Lead (3 1/4")
83	210307	1	Lead (3")
84	210544	1	Cord Set
85	21280	1	Fuse
86	21270	1	Fuseholder
87	210515	1	Binding Post (Black)
88	210514	1	Binding Post (Red)
89	210462	1	Alternator Wire
	210006		Natural Gas Conversion Kit HP-5000 DLX ES
	210007		Propane Conversion Kit HP-5000 DLX ES
	210296		Generator HP-5000 DLX ES