



## Accessories

Ref #	Part Number	Qty	Description
1	219179	1	Nozzle, Round
2	219173-01	1	Tube, Blower
3	218841	1	Nozzle, Fishtail
4	218717-02	1	Kit, Blo/Vac
5	218947	4	Screw, OV 10-24 x 1.12 TORX
6	105367	4	Nut 10-24 x 1
7	223800-01	1	Frame Rear
8	223798	1	Tube, Suction
9	223799	1	Tube, Outer
10	218660-02	1	Bag Assembly
11	218666	1	Harness
12	218938	1	Hook, Snap
13	224698	1	Adapter
	322962		Nut - Plate



Ref #	Part Number	Qty	Description
	224143-01	1	Carburetor - Zama M21B Not available separately. Factory stocked. Slow moving part.
1		2	Screw - Pump Cover Not available separately.
2		1	Cover - Pump Not available separately.
3		1	Gasket - Pump Not available separately.
4		1	Diaphragm - Pump Not available separately.
5		1	Strainer Not available separately.
6		1	Screw Throttle Valve Not available separately.
7		1	Valve - Throttle Not available separately.
8		1	Shaft Asy - Throttle Not available separately.
9		1	Spring - Throttle Not available separately.
10		1	"E" Ring - Throttle Not available separately.
11		1	Screw - High Speed Not available separately.
12		1	Screw - Low Speed Not available separately.
13		2	Spring - Adjuster Screw Not available separately.
14		2	Screw - Metering Cover Not available separately.
15		1	Retainer - Primer Not available separately.
16	223756	1	Primer Bulb
17		1	Base Asy - Primer Not available separately.
18		2	Screw - Base Asy Not available separately.
19		1	Diaphragm Asy - Metering Not available separately.
20		1	Gasket - Metering Chamber Not available separately.
21		1	Screw - Pin Retaining Not available separately.
22		1	Pin - Metering Lever Not available separately.
23		1	Lever - Metering Not available separately.
24		1	Valve - Inlet Needle Not available separately.
25		1	Spring - Metering Lever Not available separately.
26		1	Nozzle Asy - Check Valve Not available separately.
27		1	Plug - Welch Not available separately.
28		1	Retainer - Check Valve Not available separately.
29		1	Valve - Check Not available separately.
	300466		Major Repair Kit
	300472		Gasket/Diaphragm Kit




Ref #	Part Number	Qty	Description
1	322916	1	Housing, Inner impeller
2	216022	4	Screw, PN M4 x 23.4 TORX
3	218655	1	Disc, Drive
4	218518	1	Impeller
5	218656	1	Washer
6	213169	1	Nut, Hx Flange M8
7	218644	5	Screw, TR 10-14 x .75 TOR
8	219180	1	Housing Assembly, Outer
	300175	1	Housing Assembly, Outer
9	216389	1	Screw, Hx 8-32 x .50
10	218643	1	Screw, TR 8-16 x .50 TORX
11	218538	1	Pin, Cover
12	218539	1	Spring, Cover
13	218939	1	Cover, Inlet
14	218852	1	Decal, Warning Inlet
	46704-56	1	Decal, Warning Inlet
15	218797	1	Decal, Warning
	46704-55	1	Decal, Warning
16	223241	1	Switch, Momentary
17	219189	1	Trigger
18	218667	2	Link, Harness
19	219954	1	Screw, 8-18 x .75 T/B TRHD TX
20	218644	5	Screw, TR 10-14 x .75 TORX
21	219946	1	Shroud, Engine
22	219174	1	Adapter, Tube
23	219172	1	Clamp, Hose
24	217937	4	Screw, TR 10-24 x 1 TORX
25	322962	2	Plate-Nut
26	223800-01	1	Frame, Rear
27	219187	1	Spring, Throttle Lock
28	219188	1	Activator, Throttle Lock

No  
Diagram  
Available  
  
Parts List  
Only

Ref #	Part Number	Qty	Description
	322235		LOCTITE KIT
	322236		RETAINING COMPOUND 620 (10ml)
	322237		THREAD LOCKER 242 (10ml)
	322238		GASKET ELIMINATOR 518 (50ml)
	322239		BLACK MAX ADHESIVE 380 (30ml)





Ref #	Part Number	Qty	Description
1	217669	2	Screw, Pan M4 x 25 TORX S
2	215988	1	Cover, Air Cleaner
3	217376	1	Air Filter Assembly
4	216585	2	Nut, Lock M5
5	216591	1	Washer
6	215993	1	Spacer
7	223730	1	Kit, Choke Assembly
8		1	Shutter, Choke Lever Not available separately.
9	219016	1	Spring, Shutter
10		1	Plate, Choke Shutter Not available separately.
11	216108	1	Air Box/Grommet Assembly
12	215992	1	Grommet, Choke
13			Carburetor Assembly
14	224148	1	Gasket, Carburetor
15	223985	1	Insulator
16	224149	1	Shield, Insulator
17	222481	2	Stud
18	300631	1	Kit, Muffler, Universal
19	322011	1	Muffler Assembly, Universal
20	322018	1	Screen, Spark Arrester
21	322019	1	Plate, Deflector
22	215515	2	Gasket, Muffler
23	235642	2	Nut, M5
24	222480	2	Stud, Muffler
25	218652-01	1	Shield, Muffler, Universal
26	216022	3	Screw, PN M4 x 23.4 TORX
27	219590	1	Starter Assembly
	300173	1	Starter Housing Assembly
28	223331	1	Housing / Starter Assembly
	300174	1	Housing, Starter Assembly
29	219585	3	Spacer, Starter Housing
30	222800	1	Screw, 8-18 x 1.12 1/8 PN HD
31	216590	1	Washer, Flat M4
32	301252	1	Kit, Drum/Rope Assembly
33	216093	1	Rope, Starter 36"
34	300474	1	Spring, Starter Rewind
35	218941	1	Washer, Nylon
36	216792	1	Handle, Starter
37	217382	1	Cushion, Fuel Tank
38	219901	1	Tank Assembly
39	219899	1	Hose, Fuel inlet
40	216985	1	Pickup, Fuel
41	219897	1	Hose, Fuel Return
42	217383	1	Decal, 40:1
43	300700	1	Kit, Fuel Cap/Decal
44	211242	1	Decal (OPEN SLOWLY)
45	322250	1	Decal, Fuel Cap
46	217390	1	Cushion, Fuel Tank
47	213178	1	Screw, PN M5 x 8.5 SEMS T
48	218649	1	Terminal Assembly
49	218586	1	Cover, Cylinder
50	62345	1	Spark Plug DJ8J
	92879	1	Spark Plug RDJ8J
51	217320	2	Screw, PN M6 x 18 TORX SE
52	224448	1	Kit, Cylinder

Ref #	Part Number	Qty	Description
53	223925	1	Gasket, Cylinder
54	301443	1	Kit, Piston
55	223455	1	Ring, Piston
56	111026	2	Ring, Snap Internal
57	218275	1	Pin, Wrist
58	110984	1	Bearing, Needle
59	216583	1	Nut, Hx M8
60	225037	1	Starter Pawl Assembly
61	301203	1	Kit, C'Case/C'Shaft/C'Rod
62	83859	1	Seal, C'shaft, Oil
63	216500	1	Seal
64	216027	4	Screw, PN M5 x 28.5 SEMS
65	301153	1	Crankcase Assembly
66	301273	1	Crankshaft Assembly
67	213282	1	Bearing, C'shaft
68	216143	1	Bearing, Ball
69	215545	1	Gasket, C'case
70	213191	4	Pin
71	102164	1	Key, Flywheel
72	215541	1	Grommet
73	218654	1	Extension, Shaft
74	219383	1	Wire Assembly, Switch
75	222308	1	Flywheel
76	216022	2	Screw, PN M4 x 23.4 TORX
77	219848-01	1	Ignition Assembly
78	223884	1	Kit, Spark Plug Wire
79	95266	1	Boot, Spark Plug
80	102556	1	Connector, Spark
	215533-01	1	Grommet, H/T Lead
	110995	1	Grommet, Spark Plug Wire

No  
Diagram  
Available  
  
Parts List  
Only

Ref #	Part Number	Qty	Description
	215432		PRESSURE TEST TOOL
	217720		KIT, TORX WRENCHES
	222785		T-25 TORX DRIVE 3.5"