



Ref #	Part Number	Qty	Description
1	224142-02		Carburetor Asy (WT 211)
2		2	Screw, Pump Cover
3		1	Cover, Primer Cover
4	223077	1	Bulb, Primer
5	223913	1	Cover, Fuel Pump
6		1	Screw, Idle Adjustment
7		1	Spring, Idle Screw
8		1	Gasket, Fuel Pump
9		1	Diaphragm, Fuel Pump
10		1	Screen, Fuel Pump Inlet
11		1	Shaft Assembly, Throttle
12		1	Spring, Throttle Return
13		1	Ring, Shaft Retainer
14		1	Needle, Idle
15		1	Needle, High Speed
16		1	Spring, Idle Needle
17		1	Spring, High Speed Needle
18		1	Screw, Valve
19		1	Valve, Throttle
20		1	Screw, Metering Lever Pin
21		1	Pin, Metering Lever
22		1	Lever, Metering
23		1	Valve, Inlet Needle
24		1	Spring, Metering Lever
25		1	Seat Asy, Check Valve
26		1	Plug, Welch 5/16
27		1	Plug, Welch 1/4
28		1	Ring, Screen Retainer
29		1	Screen, Check Valve
30		4	Screw, Metering Cover
31		1	Cover, Metering Lever
32		1	Diaphragm Asy, Metering
33		1	Gasket, Metering Diaphragm
	224462		Kit, Major Repair
	223833		Kit, Gasket/Diaphragm



Ref #	Part Number	Qty	Description
1	217856	1	J-Handle/Grip Assembly
2	94212	1	Grip, Handle
3	215337	2	Clamp, Handle
4	217935	2	Screw, TR 10-24 x .5 TORX
5	218315	2	Nut, 10-24
6	222794	1	Housing, Trigger Throttle
7	223200	1	Screw, Self-tapping 10-16
8	216027	1	Screw, PN M5 x 28.5 SEMS
9	217159	1	Nut, Hex M5
10	215319	1	Base, Stop Switch
11	68846	1	Button, Stop Switch
12	110706	1	Screw, PN 8-18 x .5 ST H
13	215320	1	Contact, Switch
14	300361	1	Trigger, Throttle
15	215323	1	Guide
16	322141	1	Grip
17	300651	1	Kit, Stringhead - Small
18	322025	1	Housing/Eyelet Assembly
19	224998	1	Collar
20	322626	1	Spring, McC St/Head
21	300688	1	Kit, Line on Spool
22	300736	1	Kit, Knob Assembly
23	224150	1	Harness, Wiring
24	217403	2	Nut, Hex M6 x 1.0
25	216596	2	Washer, Flat M6
26	301739	1	Housing Assembly, Outer 48"
27	217366	1	Sleeve
28	218295	1	Decal, Warning
29	223407	1	Decal, Ear/Eye Cover
30	211214	1	Decal, Warning 15m
31	322099	1	Label, Debris Shield Warning
32	301024	1	Drive Assembly w/Clip
33	224062	1	Shield Assembly, Grass
34	224497-01	1	Cutter
35	216682	2	Nut Hex Lock 10-24
36	217935	2	Screw, TR 10-24 x 5 TORX
37	216595	1	Screw, Hex M6 x 1.0
38	215871	1	Nut, Hex M6 x 1.0



Ref #	Part Number	Qty	Description
1	224327	2	Screw, PN M5 x 69 TORX S.S.
2	223196	1	Cover Assembly, Choke
3	219023	2	Insert, A/C Cover
4	223520	1	Kit, Choke Knob
5		1	Lever, Choke
6	219016	1	Spring, Shutter
7		1	Plate Choke Shutter
8	219145	1	Filter, Air
9	222758	1	Box, Air
10			CARBURETOR ASSEMBLY
11	224148	1	Gasket, Carburetor
12	223984	1	Insulator
13	223986	1	Gasket, Shield Insulator
14	219508	2	Screw, PAN M4 x 17 SEMS TORX
15	217669	1	Screw, PAN M4 x 25 TORX S
16	219079	2	Spacer, Muffler Shield
17	218962	1	Shield, Muffler
18	300629	1	Kit, Muffler
19	322011	1	Muffler Asy., Universal
20	322016	1	Plate, Deflector
21	322018	1	Screen, Spark Arrester
22	235642	2	Nut M5 Torque 45-50 in. lbs.
23	215515	1	Gasket, Muffler
24	222480	2	Stud, Muffler
25	216022	2	Screw, PAN M4 x 23.4 TORX
26	301164	1	Starter Assembly
27	301163	1	Housing, Starter Assembly
28	219585	2	Spacer, Starter Housing
29	219584	1	Spacer, Muffler Shield
30	218932	1	Guide, Rope
31	218941	1	Washer, Nylon
32	216792	1	Handle, Starter
33	300474	1	Spring, Starter Rewind
34	301252	1	Drum/Rope Assembly
35	216093	1	Rope, Starter 36"
36	216590	1	Washer, Flat M4
37	215874	1	Screw, PN M4 x 9.5 TORX
38	225037	1	Starter Pawl Assembly
39	216583	1	Nut, Hex M8 Torque 150-170 in. lbs.
40	222239	1	Tank Assembly, Fuel
41	222238	1	Hose, Fuel Return
42	217264	1	Hose, Fuel
43	216985	1	Pickup, Fuel
44	300700	1	Kit, Fuel Cap/Decal
45	211242	1	Decal (OPEN SLOWLY)
46	322250	1	Decal, Fuel Cap
47	217390	1	Cushion, Fuel Tank
48	217382	1	Cushion, Fuel Tank
49	222308	1	Flywheel
50	219383	1	Wire Assembly, Switch
51	216022	2	Screw, PN M4 x 23.4 TORX Torque 30-35 in. lbs. Loctite type 242.
52	219848-01	1	Ignition Assembly
53	223884	1	Kit, Spark Plug Wire
54	102556	1	Connector

Ref #	Part Number	Qty	Description
55	95266	1	Boot
56	215533-01	1	Grommet, H/T Lead
57	110995	1	Grommet, Spk Plug Wire Not used
58	322189	1	Spark Plug, DJ7Y Torque 110-120 in. lbs.
59	213178	1	Screw, PN M5 x 8.5 SEMS T
60	215540-01	1	Cover, Cylinder
61	217320	2	Screw, PN M6 x 18 TORX SE Torque 70-80 in. lbs.
62	224448	1	Kit, Cylinder/Gasket
63	223925	1	Gasket
64	301443	1	Kit, Piston - Alum (21cc)
65	223455	1	Ring, Piston
66	218275	1	Pin, Wrist
67	111026	2	Ring, Snap
68	110984	1	Bearing, Needle
69	102164	1	Key, Flywheel
70	215541	1	Grommet
71	301203	1	Kit, Crankcase/Crankshaft Assembly
72	301153	1	Crankcase
73	213191	4	Pin
74	215545	1	Gasket, Crankcase
75	83859	1	Seal, C'shaft Oil
76	216500	1	Seal
77	216027	4	Screw, PN M5 x 28.5 SEMS Torque 45-50 in. lbs. Loctite type 242.
78	301273	1	Crankshaft/Ball Bearing Assembly
79	213282	1	Bearing, Crankshaft
80	216143	1	Bearing, Ball
81	217477	1	Coupling
82	224108	1	Housing, Fan
83	216591	1	Washer, Flat M5
84	217159	1	Nut, Hex M5
85	217158	1	Screw, Hex M5 x 35
86	219508	4	Screw, PAN M4 x 17 SEMS TORX
87	300653	1	Kit, Heat Shield
88		1	Bracket
89	219194	2	Screw, PAN 5-20 x 0.438
90	300296	2	Screw, 10-24 x 0.5 PN HD TX
91	216682	2	Nut, Hex Lock 10-24
92	300793	1	Kit, Engine Stand
93	224940	2	Spacer, Engine Stand
94	222944	2	Screw, TX HD M4 x 0.7 x 35
95	100002	2	Washer, Plane
96	222506	1	Decal, Storage
97	217383	1	Decal, 40:1
98	223215	1	Decal, Starting

No
Diagram
Available

Parts List
Only

Loctite Kit

Ref #	Part Number	Qty	Description
	322235		LOCTITE KIT
	322236		Retaining Compound 620 (10 ml)
	322237		Thread locker 242 (10 ml)
	322238		Gasket Eliminator 518 (50 ml)
	322239		Black Max Adhesive 380 (28.3 g)

No
Diagram
Available

Parts List
Only

Ref #	Part Number	Qty	Description
	215432		Pressure Test Tool
	217720		Torx Kit
	222785		T-25 Torx