



Ref #	Part Number	Qty	Description
1	224142-02	1	Carburetor Asy (WT 211)
2		2	Screw-Pump Cover Not available separately
3		1	Cover-Primer Pump Not available separately
4	223077	1	Bulb-Primer
5	223913	1	Cover Asy Fuel-Pump
6		1	Screw-Idle Adjustment Not available separately
7		1	Spring-Idle Screw Not available separately
8		1	Gasket-Fuel Pump Not available separately.
9		1	Diaphragm-Fuel Pump Not available separately.
10		1	Screen-Fuel Pump Inlet Not available separately.
11		1	Shaft Assembly Throttle Not available separately
12		1	Spring-Throttle Return Not available separately.
13		1	Ring-Shaft Retainer Not available separately.
14		1	Needle-Idle Not available separately.
15		1	Needle-High Speed Not available separately.
16		1	Spring-Idle Needle Not available separately.
17		1	Spring-High Speed Needle Not available separately.
18		1	Screw-Valve Not available separately.
19		1	Valve-Throttle Not available separately
20		1	Screw-Metering Lever Pin Not available separately.
21		1	Pin-Metering Lever Not available separately.
22		1	Lever-Metering Not available separately.
23		1	Valve-Inlet Needle Not available separately.
24		1	Spring-Metering Lever Not available separately.
25		1	Seat Asy Check-Valve Not available separately
26		1	Plug-Welch 5/16 Not available separately.
27		1	Plug-Welch 1/4 Not available separately.
28		1	Ring-Screen Retainer Not available separately.
29		1	Screen-Check Valve Not available separately
30		4	Screw-Metering Cover Not available separately.
31		1	Cover-Metering Lever Not available separately
32		1	Diaphragm Asy-Metering Not available separately.
33		1	Gasket-Metering Diaph. Not available separately.
	224462		Major Repair Kit
	223833		Gasket/Diaphragm Kit



Ref #	Part Number	Qty	Description
1	217403	2	Nut-Hex M6 x 1.0
2	216596	2	Washer Flat M6
3	224150	1	Harness-Wiring
4	215324	1	Shaft-Flex
5	222313	1	Housing Assembly-Outer
	224059	1	Housing Assembly-Outer
6	217366	1	Sleeve
7	215322	1	Grip
8	110706	1	Screw-Pn 8-18 x .50 St H
9	215320	1	Contact-Switch
10	215319	1	Base-Stop Switch
11	68848	1	Button-Stop Switch
12	215323	1	Guide
13	216027	1	Screw-Pn M5 x 28.5 SEMS
14	217159	1	Nut-Hex M5
15	223200	1	Screw-Self Tapping 10-16
16	215318	1	Trigger-Throttle
17	222794	1	Housing-Trigger Throttle
18	218295	1	Decal-Warning
19	217937	1	Screw-Tr 10-24 x 1.00 T
20	218315	1	Nut
21	215874	1	Screw-Pn M4 x 9.5 TORX
22	217672	1	Washer-M4 Flat
23	222468	1	Assy-Kit Spindle Housing
24	217477	1	Coupling
25	222402	1	Washer-Thrust
26	218214	1	Collar
27	216595	1	Screw-Hx M6 x 50
28	215871	1	Nut-Hex M6 x 1.0
29	224273	1	Shield-Grass 45ø
30	224062	1	Shield-Grass 45ø
31	229956	1	Shield-Grass 90ø
32	217935	2	Screw Tr 10 24 x .50 Torx
33	218315	2	Nut
34	103174	2	Washer-Lock #10
35	224153	1	Knife
36	224499	1	Spacer
37	300110	1	Kit-String Head
38	224305	1	Cover
39	224268	1	Spool-W/Line (.095)
40	223740	1	Spring-String Head
41	222403	1	Ring-Retaining
42	224986	1	Washer-Plain
43	224303	1	Housing-Eyelet Assembly
44	223739	2	Eyelets-String Head
45	224998	1	Collar
46	120041	2	Screw-Hx M5 x 0.8 x 22
47	217159	2	Nut-Hex M5
48	217442	1	Clamp
49	217444	1	Handle-Delta
50	224977	1	Kit Loop-Handle
51	228320	4	Screw-M6 x 0.8 x 45
52	236936	4	Washer
53	227045	1	Loop-Handle
54	227046	1	Clamp-Handle

Ref #	Part Number	Qty	Description
55	236642	4	Nut
56	224127	1	Spacer-Handle



Ref #	Part Number	Qty	Description
1	224327	2	Screw-Pn M5 x 69 Torx SS
2	223196	1	Cover Asy-Choke
3	219023	2	Insert-A/C Cover
4	223520	1	Kit-Choke Knob
5		1	Lever-Choke Not available separately
6		1	Lever-Shutter
7	219016	1	Spring-Shutter
8		1	Plate-Choke Shutter
9	219145	1	Filter-Air
10	222758	1	Box-Air
11		1	Carburetor Assembly See "Carburetor Assembly" illustration and parts list.
12	224148	1	Gasket-Spacer
13	223984	1	Insulator-S/T
14	223986	1	Gasket-Shield Insulator
15	219963	1	Kit-Muffler/Shield
16	219508	2	Screw-Pn M4 x 17 Sems Torx
17	217669	1	Screw-Pn M4 x 25 Torx S
18	219079	2	Spacer-Muffler Shield
19	218962	1	Shield-Muffler
20	219194	2	Screw-Pn 5-20 x .438 St
21	219150	1	Cover-Spk Arrestor
22	219149	1	Screen-Spark Arrestor
23	219152	1	Muffler Assembly
24	222247	2	Nut-Stud
25	215515	1	Gasket-Muffler
26	222480	2	Stud-Muffler
27	216022	2	Screw-Pn M4 x 23.4 Torx
28	217388	1	Starter Assembly
29	223326	1	Housing Starter
30	218932	1	Guide-Rope
31	219585	2	Spacer-Housing Starter
32	219584	1	Spacer-Muffler Shield
33	215874	1	Screw-Pn M4 x 9.5 Torx
34	216590	1	Washer-Flat M4
35	216092	1	Drum/Rope Assembly
36	216093	1	Rope-Starter (36")
37	216792	1	Handle-Starter
38	218941	1	Washer-Nylon
39	217482	1	Spring-Starter
40	217382	1	Cushion-Fuel Tank
41	222239	1	Tank Asy-Fuel
42	217264	1	Hose-Fuel
43	216985	1	Pickup-Fuel
44	222238	1	Hose-Fuel Return
45	217390	1	Cushion-Fuel Tank
46	222347-01	1	Cap-Fuel
47	217383	1	Decal 40:1
48	216583	1	Nut-Hex M8
49	215525	1	Ratchet Assembly
50	213177	4	Screw-Pn M4.2 x 18.5
51	217158	1	Screw-Hx M5 x 35
52	216591	2	Washer-Flat M5
53	217159	1	Nut-Hex M5
54	218057	1	Housing Asy-Fan

Ref #	Part Number	Qty	Description
55	215534	1	Plate-Thrust
56	213186	1	Ring-Retaining
57	213187	1	Bearing-Ball
58	218063	1	Drum-Clutch
59	217554	1	Clutch Assembly
60	215536	1	Rotor-Clutch
61	223770	2	Spring-Clutch
62		2	Shoe-Clutch Not available separately
63	215539	1	Plate-Side
64	216022	2	Screw-Pn M4 x 23.4 Torx
65	219383	1	Wire Assembly-Switch
66	219848	1	Ignition Assembly
67	95226	1	Boot-Spark Plug
68	102556	1	Connector-Spark
69	215533-01	1	Grommet H/T Lead
70	222308	1	Flywheel
71	62345	1	Sparkplug DJ8J
72	213178	1	Screw-PN M5 x 8.5 Sems T
73	215540	1	Cover-Cylinder
74	217320	2	Screw-Pn M6 x 18 Torx SE
75	224447	1	Cylinder/Gasket Kit
76	223925	1	Gasket-Cylinder
77	223455	1	Ring-Piston
78	223468	1	Piston Plated-Mach.
79	111026	2	Ring-Snap Int.
80	218275	1	Pin-Wrist
81	216027	4	Screw-Pn M5 x 28.5 Sems
82	215541	1	Grommet
83	223902	1	Crankcase Assembly
84	213191	4	Pin
85	215545	1	Gasket-Crankcase
86	110984	1	Bearing-Needle
87	102164	1	Key-Flywheel
88	213282	2	BBearing-Crankshaft
89	218106-01	1	Crankshaft Assembly
90	83859	2	Seal-Crankshaft Oil

No
Diagram
Available

Parts List
Only

Ref #	Part Number	Qty	Description
	215437		Tool-Oil Seal McCulloch service tool.
	215441		Tool Clutch Puller McCulloch service tool.
	215439		Tool Piston Driving McCulloch service tool.
	215443		Plate-Pressure Test McCulloch service tool.
	215444		Gasket Intake Pressure Test McCulloch service tool.
	215445		Gasket-Exhaust Pressure Test McCulloch service tool.
	217355		Wrench 8/10 mm (open end) McCulloch service tool.
	216767		Lock Spindle McCulloch service tool.
	218175		Socket-Wrench 9/16 McCulloch service tool.
	222785		T-25 TORX Drive 3.5" McCulloch service tool.