


7-39004

BODY & CHASSIS



D-6085-2


BODY & CHASSIS**7-39004**

KEY NO.	DESCRIPTION	PART NO.	KEY NO.	DESCRIPTION	PART NO.
1	Edge Trim, Hood*	21765	42	Screw, Tap	26X214
2	Hood Assembly	24087	43	Cover, Battery	407310
3	Screw, Machine No. 24X5/8"	4X21Z	44	Seat Spring	164X17
4	Grip, Hood Latch*	21434	45	Screw	26X49
5	Latch, Right Hood*	24081	46	Spring Retainer	90014
—	Latch, Left Hood*	24080	47	Reflector, Rear	23069
6	Washer*	17X17Z	48	Drawbar	23054
7	Nut, Hex No. 10-24*	15X81	49	Hair Pin	31X1
8	Baffle, Foam Heat	403154	50	Screw	26X197
9	Reflector, Headlight	90009C	51	Keps Nut 1/4"-20	15X66
10	Lens	90082	52	Flange Nut 5/16"-18	15X79Z
11	Screen, Left Grille	24254E	53	Right Side Plate	23292
—	Screen, Right Grille	24089E	54	Left Side Plate	23293
12	Grille Assembly	90668	55	Battery Tray	24157
13	Trim, Headlight	90654C	56	Rod, Battery Clamp	21762Z
14	Screw, Hex Head Tap	26X202	57	Clamp, Battery	21761Z
15	Pivot Bar*	23046	58	Locknut, Flange 1/4"-20	15X82
16	Throttle Control	91583	59	Mat, Running Board	21710
18	Nut, Hex 3/8"-24	15X33	60	Left Running Board	23823
19	Lockwasher	18X31	61	Right Running Board	23822
20	Panel, Control	91580	62	Wiring Shield	24321
21	Choke & Cable	23780	63	Bolt, Carriage 5/16"-18X3/4"	2X64
22	Screw, Tap	26X159	64	Running Board Support Assembly	24253
23	Bearing, Steering Post	21707	65	Bolt, Carriage 5/16"-18X5/8"	2X53
24	Screw, Tap	26X186	66	Running Board Support	24105
25	Seat	91042	67	Frame Channel	402054
26	Support, Seat	91044	68	Front Axle Assembly	21441
27	Bolt, Hex 5/16"-18X5/8"	1X45	69	Axle Hanger Assembly	23845
28	Bolt, Shoulder	9X30	70	Pivot Pin	21469
29	Locknut, Flange 5/16"-18	15X88	71	Bolt, Carriage 3/8"-16X3"	2X60
30	Washer	17X47Z	72	Pivot Bar Assembly*	23088
31	Lockwasher	18X16	73	Locknut, Flange 3/8"-16X3"	15X84
33	Pivot Bracket, Seat	90663	#	Parts Bag 6T & YT	91579
34	Rear Insert	23026	#	Parts Bag 42" Deck	24494
35	Panel, Top	90662	#	Inst. Book 6T & YT	F-87708
36	Bolt, hex 1/4"-20X5/8"	1X38	#	Parts List 6T & YT	F-87709
37	Washer	17X37Z	#	Inst. Book 42" Deck	F-87703
38	Screw, Machine No. 24X3/4"	4X67	#	Decal-Hood R.H.	58X938
39	Fender	23006	#	Decal-Hood L.H.	58X937
40	Panel, Right Side	90660	#	Decal-Grille	58X834

* NOTE: Parts shown with an asterisk (*) in the description are included when ordering key number 2 when ordering.

7-39004

STEERING PARTS




STEERING PARTS**7-39004**

KEY NO.	DESCRIPTION	PART NO.
1	Steering Wheel	90577
3	Keps Nut 5/16"-18	15X76
4	Hex Bolt 5/16"-18X1 3/4"	1X75
5	Steering Post	24345C
6	Upper Steering Coupling	21489
7	Hex Bolt 1/4"-20X7/8"	1X95
8	Flange Locknut 1/4"-20	15X89
9	Formed Washer	23039
10	Steering Disc	21532
11	Flange Locknut 3/8"-16	15X84
12	Hex Bolt 5/16"-15X5/8"	1X45
13	Steering Gear Bracket Assembly	21492
14	Bearing	20587
15	Hex Bolt 5/16"-15X5/8"	1X45
16	Steering Bracket	21693
17	Flange Locknut 5/16"-18	15X79
18	Steering Gear Assembly	21692
19	Hex Bolt 3/8"-16X1/4"	1X85
20	Flange Locknut 5/16"-18	15X88
21	Hex Nut	15X61
22	Steering Ball Joint	21031
23	Flange Locknut 3/8"-24	15X87
24	Cotter Pin	30X49
25	Washer	17X83Z
26	Spindle Bearing	23820
27	Left Spindle Assembly	23149
28	Drag Link Rod	21482
29	Sleeve, Drag Link Rod	156X2
30	Sleeve, Tie Rod	156X1
31	Tie Rod	21475
32	Right Spindle Assembly	23148
33	Wheel & Tire Assembly	24404
—	Wheel Only	24413E
—	Tire Only*	24410
—	Valve Stem & Cap	24373
—	Wheel Bearing	91334
—	Tire Tube	407048
34	Washer	17X83Z
36	Coupling Plate	21490

*NOTE: For replacement parts, always give the name of the side of the tire so that the tread pattern of the tires will match.

7-39004

DRIVE SYSTEM



D-8110

DRIVE SYSTEM**7-39004**

KEY NO.	DESCRIPTION	PART NO.	KEY NO.	DESCRIPTION	PART NO.
1	Engine***	—	42	Idler Bracket Assembly	24250
2	Screw	25X2	43	Adjustable Nut	21920
3	Heat Baffle, Front	91571E	44	Clutch Rod	21918Z
4	Exhaust Pipe Assembly	23743E	45	Drive Belt	37X26
5	Woodruff Key No. 6	20062	46	Backside Idler Pulley	23238
6	Oil Drain Extension	23783	47	Drive Pulley	23052
7	Oil Drain Cap	21651	48	Retainer Ring	11X5
8	Heat Baffle, Rear	91372E	49	Pedal, Clutch & Brake	21544
9	Fuel Cap	23787	50	Lever Assembly, Clutch & Brake	91333
10	Fuel Tank, Complete	23396	51	Cotter Pin	30X20
11	Hose Clamp	23713	52	Washer	17X53Z
12	Fuel Filter***	—	53	Support Bracket	23358
13	Fuel Line	23714	54	Parking Brake Arm	24245Z
15	Grommet	21268	55	Grip, Parking Brake	24235
16	Flange Locknut 3/8"-16	15X84	56	Brake Rod	23728Z
17	Carriage Bolt 1/4"-20X3/4"	2X67	57	Link Plate, Brake	24432
18	Flange Locknut 1/4"-20	15X89	58	Adjuster Rod	23735Z
19	Fuel Tank Support	24331	59	Spring, Brake	165X41
20	Screw	26X197	60	Pin	108X16
21	Right Front Transaxle Bracket	24244	61	Disc & Hub Assembly	23013
22	Left Front Transaxle Bracket	23023	62	Disc Brake Unit	23019
23	Lockwasher	18X31	63	Woodruff Key No. 9	20697
24	Hex Bolt 3/8"-16X3/4"	1X85	64	Knob, Shift Lever	20844
25	Hex Bolt 5/16"-24X5/8"	1X63	65	Transaxle** Peerless Model No. 2348	—
26	Star Washer	19X6	66	Rear Transaxle Bracket	23005
27	Spring, Drive Idler	165X22	67	Extruded Washer	23041Z
28	Hex Bolt 1/4"-20X5/8"	1X38	68	Square Key 1/4"	24039
29	Star Washer	19X8	69	Wheel Hub	23020
30	Hex Bolt, Engine Mount	25X6	70	Retainer Ring	11X6
31	Belt Guide	23826Z	71	Hex Bolt 7/16"-20X1"	1X80
32	Keps Nut 1/4"-20	15X66	72	Rear Wheel & Tire Assembly	
33	Stack Pulley Assembly	23725Z		Size: 23X8 1/2-12	23320
34	Screw	26X49		Size: 23X9 1/2-12	24400
35	Belt Guide, Stack Pulley	23789Z	*	Tire Only: For 23X8 1/2-12	407228
36	Hex Bolt 3/8"-24X1"	1X20	*	Tire Only: For 23X9 1/2-12	407920
37	Internal Tooth Lockwasher	19X39	*	Tube Only	407051
38	Washer	10851Z	*	Wheel Only	407226
39	Idler Pulley	21409	*	Valve Stem & Cap	400162
40	Shoulder Bolt	9X12	73	Bushing	23857
41	Idler Pulley, Clutch	20613	74	Screw No. 8X1/2"	26X203


NOTE: These parts, shown with an asterisk (), are included when ordering key number 72. For replacement parts, always give the name on the side of the tire so that the tread pattern will match.

**NOTE: Replacement parts for the transaxle are available from a Tecumseh Authorized Service Center. See the yellow pages under, "Engines, Gasoline" or "Gasoline Engines", in the telephone directory.

***NOTE: The engine model, type, and code numbers are on the engine. Replacement parts for the engine are available from a Briggs & Stratton Authorized Service Center. See the yellow pages under, "Engines, Gasoline" or "Gasoline Engines", in the telephone directory.

DISC BRAKE PARTS


7-39004



KEY NO.	DESCRIPTION	PART NO.
1	Hex Bolt	402001
2	Locknut	402002
3	Bracket	402003
4	Lever Assembly	402004
5	Stator Assembly	402008
6	Bracket	402006
7	Spacer	402007
—	Complete Disc Brake Key nos. 1-7	23019

7-39004

MOWER HOUSING TOP HALF



D-5113-5

MOWER HOUSING TOP HALF**7-39004**


KEY NO.	DESCRIPTION	PART NO.	KEY NO.	DESCRIPTION	PART NO.
1	Washer	10851Z	26	Nut, Hex 5/16"-18	15X2
2	Washer	17X124	27	Cable, Lifter	24470
3	Pin, Hair	31X2	28	Brace, Hanger	24472
4	Rod, Adjuster 7-5/16" Long For 23 inch Diameter Rear Wheels	23824	29	Bolt, Shoulder	9X14
4a	Rod, Adjuster 6 1/4" Long For 18 to 20 inch Diameter Rear Wheels	23275Z	30	Arm, Support	23185
5	Bracket, Right Hanger 6-3/8" Long** For 23 inch Diameter Rear Wheels	23204Z	31	Bolt, Hex 5/16"-18X1"	1X84
5a	Bracket, Right Hanger 5 1/2" Long** For 18 to 20 inch Diameter Rear Wheels	23188Z	32	Washer	17X57Z
6	Nut, Adjustable	21920	33	Pin, Pull	21912Z
7	Bolt, Carriage*	2X64	34	Pin, Cotter	30X20
8	Support, Lifter*	23184	35	Clevis	24073
9	Lifter Assembly*	24260	36	Cover, Pulley	23231
10	Bracket, Guide	23192	37	Screw, Tap	26X214
11	Bolt, Hex 1/4"-20X7/8"	1X95	38	Belt, Blade Drive	37X40
12	Grip, Engagement Lever	91573	39	Guide, Belt	23751Z
13	Grip, Lifter Latch	23222	40	Key, Woodruff No. 6	20062
14	Latch, Lifter	23194	41	Jackshaft	23180
15	Spring, Lifter	164X4	42	Pulley, Jackshaft	20615
16	Washer	17X53	43	Pulley, Backside Idler	23238
17	Bracket, Lifter Guide	23193	44	Bolt, Shoulder 3/8"-16X7/8"	9X12
18	Nut, Keps 1/4"-20	15X66	45	Idler Assembly, Blade Drive	23179
19	Bolt, Shoulder 3/8"-16	9X13	46	Rod, Brake	91593Z
20	Pin, Hair	31X6	47	Washer	17X46
21	Locknut, Flange 3/8"-16	15X84	48	Rod Assembly, Link	91535Z
22	Locknut, Flange 5/16"-18*	15X88	49	Link, Engagement	23226Z
23	Washer	17X47Z	50	Rod, Engagement Link	23228Z
24	Clevis, Adjusting	24471Z	51	Spring, Blade Drive	165X43
25	Pin, Clevis	29X93	52	Jackshaft, Short	20616
			53	Spacer	23213Z
			54	Pulley, Jackshaft	23739
			55	Pad Assembly, Brake	91592
			56	Belt, Cross Drive	37X22
			57	Idler Pulley	23211

NOTE: Parts that have an asterisk () in the description are included with Mower Housing Assembly on the Lower Half of the mower housing illustration.

**NOTE: These parts are measured from weld pin to weld pin.

7-39004

MOWER HOUSING LOWER HALF




MOWER HOUSING LOWER HALF**7-39004**

KEY NO.	DESCRIPTION	PART NO.	KEY NO.	DESCRIPTION	PART NO.
1	Nut, Flange 5/16''-18*	15X79	27	Deflector, Mower Housing	23224
2	Idler Assembly, Fixed*	23177	28	Locknut, Hex No. 10-24*	15X81
3	Support, Idler*	23240	29	Housing, Jackshaft	24384
4	Support, Engagement Link*	23241	30	Washer	17X140
5	Locknut, Flange 3/8''-16	15X84	31	Washer	17X141
6	Idler Assembly, Cross Drive	23178Z	32	Lockwasher	18X27
7	Bolt, Shoulder 3/8''-16X7/8''	9X15	33	Nut, Hex 1/2''-20	15X72
8	Spring, Cross Drive	165X60	34	Skid*	24070
9	Spring, Blade Brake Torsion	166X29	35	Axle, Roller	23186Z
10	Bracket & Pin Assembly	91591Z	36	Support, Rear Roller*	23208
11	Bolt, Shoulder 3/8''-16	9X13	37	Bolt, Carriage 5/16''-18X2-5/8''*	2X53
12	Pulley, Nylon	23187	38	Roller	23203
13	Guide, Cable	23191Z	39	Pin, Cotter	30X49
14	Housing Assembly, Mower	24261	40	Key, Woodruff No. 6	20062
15	Locknut, Flange 5/16''-18*	15X88	41	Adapter, Blade	54211
16	Bolt, Carriage 5/16''-18X3/4''	2X64	42	Washer	24614Z
17	Screw, Tap	26X214	43	Bolt, Hex 5/16''-18X3/4''	1X84
18	Guide, Cable	21953Z	44	Cable, Lifter	24470
19	Deck Stop*	23782	45	Bolt, Hex 1/4''-20X7/8''	1X95
20	Baffle, Mower Housing*	23207	46	Support, Front Roller*	24009
21	Screw	26X195	47	Guide, Curved Belt	24071Z
22	Cap, Push On	28X23	48	Locknut, Flange 1/4''-20	15X89
23	Rod, Deflector	23173Z	49	Blade	24458HT
24	Bracket, Deflector*	23172	50	Washer	21673Z
25	Screw, Machine No. 10-24X5/8''	4X21	51	Washer, Blade	20663Z
26	Spring, Torsion	166X4	52	Base Plate	24012
			—	Housing Complete, Mower	403134

NOTE: Parts that have an asterisk () in the description are included with Mower Housing Complete (Top & Lower Halves).

7-39004

WIRING DIAGRAM



KEY NO.	DESCRIPTION	PART NO.	KEY NO.	DESCRIPTION	PART NO.
1	Ammeter Assembly*	90829	13	Switch, Clutch Limit	24273
2	Switch and Key, Ignition	21064PA	14	Switch, Attachment	91070
2a	Key Only	20729	15	Shield, Switch	91071
—	Fuse, Auto Type	54212	16	Leaf Spring, Switch	91561
3	Wire Harness	250X9	17	Switch, Seat Sensor	S91031
4	Screw	26X49	18	Wire Harness-Seat Switch	250X10
5	Cable, Battery Ground	24X6	19	Switch, Mower Housing**	91032
6	Bolt, Hex 1/4"-20X5/8"	1X38	20	Boot, Cable	24196
7	Nut, Keps 1/4"-20	15X66	21	Switch, Light	90647
8	Battery 12-Volt 30-AMP	21075	22	Cable (Solenoid to Engine)	24X13
—	Acid, Battery (Electrolyte)	90665	23	Socket Assembly, Light	90155
9	Cable, Battery (Solenoid to battery)	24X25	24	Washer, Light Socket	90228
10	Cover, Solenoid	90565	25	Bult, Lamp	90084
11	Solenoid	24285	—	Strap, Tie	32618
12	Screw, No. 10X1/2"	26X233	—	Clamp, Wire	21980
			26	Nut, Hex 3/8"-24	15X33

*NOTE: Two Ammeters (Key No. 1) are shown in the diagram. Your unit will only have one ammeter. Both ammeters are shown because of the difference in appearance and how they connect.

**NOTE: Two Attachment Switches (Key No. 19) are shown in the diagram. Your unit will only have one switch. Both switches are shown because of the difference in appearance and how they connect.