


**MODEL NOS. 9-36600
9-38600
9-38608**

CHASSIS & HOOD



CHASSIS & HOOD


MODEL NOS. 9-36600
9-38600
9-38608

KEY NO	DESCRIPTION	9-36600	9-38600	9-38608
1	Seat	91965	91965	91965
2	Plate Assembly, Switch	91963Z	91963Z	91963Z
3	Spring, Compression	164x22	164x22	164x22
4	Spring, Seat	91964	91964	91964
5	Glide, Spring	91822	91822	91822
6	Bolt, Shoulder	9x38	9x38	9x38
7	Support, Seat	91728E701	91728E701	91728E701
8	Lockwasher	18x16	18x16	18x16
9	Bolt, Hex	1x45	1x45	1x45
10	Locknut, Flange	15x88	15x88	15x88
11	Bracket, Pivot	91729E701	91729E701	91729E701
12	Rod, Pivot	91730Z	91730Z	91730Z
13	Cap, Push On	28x23	28x23	28x23
14	Cap, Console	91704F200	91704F200	91704F200
15	Screw, Tap	26x250	26x250	26x250
17	Fender, Apron	91724F200	91724F200	91724F200
21	Screw	26x214	26x214	26x214
22	Tray, Battery	91895	91895	91895
23	Fender	91715F200	91715F200	91715F200
24	Clip, Battery	91941	91941	91941
25	Screw	26x184	26x184	26x184
28	Screw	26x249	26x249	26x249
29	Channel Assembly	91857E701	91857E701	91857E701
30	Console	91705F200	91705F200	91705F200
31	Trim, Edge	21765	21765	21765
32	Hood Assembly	91852F200	91852F200	91852F200
33	Eyelet	91733	91733	91733
34	Washer, Rubber	91751	91751	91751
35	Bolt, Shoulder	9x36	9x36	9x36
36	Dash Assembly	91858F200	91858F200	91858F200
37	Bearing	91759	91759	91759
38	Speed Nut	28x58	28x58	28x58
39	Grille, Upper (without Lens)	91726	91726	91726
40	Grille Assembly, Upper (includes Lens)	91736	91736	91736
41	Lens, Left	91735	91735	91735
42	Len, Right	91734	91734	91734
43	Insert, Lower Grille		91800	91800
44	Grille, Lower	91722F200	91722F200	91722F200
45	Locknut, Flange	15x84	15x84	15x84
46	U-Nut	28x57	28x57	28x57
47	Screw	26x252	26x252	26x252
48	Support, Grille	91723F200	91723F200	91723F200
49	Frame	91700F200	91700F200	91700F200
50	Mat	91900	91900	91900
51	Bulkhead, Foam	N/A	92004	N/A
—	Instruction Book	F89760	F-89760	F-89760
—	Repair Parts Book	F-89701	F-89702	F-89703
—	Decal, Left Hood	44x101	44x101	44x101
—	Decal, Right Hood	44x100	44x100	44x100
—	Decal, Grille	44x102	44x102	44x102
—	Decal, Left Console	44x103	44x111	44x111
—	Decal, Right Console	44x104	44x110	44x110
—	Decal, Right Console	44x106	44x106	44x106
—	Decal, Top Console	44x655	44x655	44x655
—	Decal, Top Console		44x112	44x112

N/A = Not Applicable

**MODEL NOS. 9-38620
9-40620**

CHASSIS & HOO




CHASSIS & HOOD**MODEL NOS. 9-38620
9-40620**

KEY NO.	DESCRIPTION	9-38620	9-40620
1	Seat	91965	91965
2	Plate Assembly, Switch	91963Z	91963Z
3	Spring, Compression	164x22	164x22
4	Spring, Seat	91964	91964
5	Glide, Spring	91822	91822
6	Bolt, Shoulder	9x38	9x38
7	Support, Seat	91728E701	91728E701
8	Lockwasher	18x16	18x16
9	Bolt, Hex	1x45	1x45
10	Locknut, Flange	15x88	15x88
11	Bracket, Pivot	91729E701	91729E701
12	Rod, Pivot	91730E701	91730E701
13	Cap, Push On	28x23	28x23
14	Cap, Console	91704F200	91704F200
15	Screw, Tap	26X250	26x250
16	Cover, Shift	91905	91905
17	Fender, Apron	91724F200	91724F200
18	Bolt, Hex	1x38	1x38
19	Washer	17x38Z	17x38Z
20	Gate, Shift	91893Z	91892Z
21	Screw	26x214	26x214
22	Tray, Battery	91895	91895
23	Fender, Left	91715F200	91715F200
24	Clip, Battery	91941	91941
25	Screw	26x184	26x184
26	Nut, Keps	15x66	15x66
27	Strut, Console	91910F200	91910F200
28	Screw	26x249	26x249
29	Channel Assembly	91857E701	91857E701
30	Console	91731F200	91731F200
31	Trim, Edge	21765	21765
32	Hood Assembly (without hole)	91852F200	91852F200
33	Eyelet	91733	91733
34	Washer, Rubber	91751	91751
35	Bolt, Shoulder	9x36	9x36
36	Dash Assembly	91858F200	91858F200
37	Bearing	91759	91759
38	Speed Nut	28x58	28x58
39	Grille, Upper (without Lens)	91726	91726
40	Grille Assembly, Upper (includes Lens)	91736	91736
41	Lens, Left	91735	91735
42	Len, Right	91734	91734
43	Insert, Grille	91800	91800
44	Grille, Lower	91722F200	91722F200
45	Locknut, Flange	15x84	15x84
46	U-Nut	28x57	28x57
47	Screw	26x252	26x252
48	Support, Grille	91723F200	91723F200
49	Frame	91700F200	91700F200
50	Mat	91900	91900
51	Fender, Right	91894F200	91894F200
—	Instruction Book	F-89761	F-89761
—	Repair Parts Book	F-89705	F-89706
—	Decal, Left Hood	44x101	44x101
—	Decal, Right Hood	44x100	44x100
—	Decal, Grille	44x102	44x102
—	Decal, Left Console	44x111	44x117
—	Decal, Right Console	44x110	44x118
—	Decal, Right Console	44x106	44x106
—	Decal, Top Console	44x656	44x656
—	Decal, Right Fender	44x116	44x119

MODEL NOS.
9-36600
9-38600
9-38608

MOTION DRIV



9-36602
uses 920-039 T-AX**MOTION DRIVE****MODEL NOS. 9-36600****9-38600****9-38608****KEY**

NO.	DESCRIPTION	9-36600	9-38600	9-38608
1	Guide, Belt	91754	91754	91754
2	Locknut, Flange	15x84	15x84	15x84
3	Nut, Flange	15x79Z	15x79Z	15x79Z
4	Bolt, Hex	1x124	1x124	1x124
5	Grip	91079	91079	91079
6	Screw	26x214	26x214	26x214
7	Rod, Control	91727Z	91727Z	91727Z
8	Guide, Bracket	91825Z	91825Z	91825Z
9	Screw	26x249	26x249	26x249
10	Clutch and Brake Pedal	21544	21544	21544
11	Lever Assembly	91862F200	91862F200	91862F200
12	Rod, Clutch	91808Z	91808Z	91808Z
13	Nut, Adjustable	21920	21920	21920
14	Pin, Cotter	30x20	30x20	30x20
15	Bracket, Support	91713F200	91713F200	91713F200
16	Latch, Park Brake	91712Z	91712Z	91712Z
17	Spring, Brake Extension	165x73	165x73	165x73
18	Washer	17x47Z	17x47Z	17x47Z
19	Bracket Assembly, Idler***	92029Z	92029Z	92029Z
20	Ring, Retainer	11x7	11x7	11x7
21	Bolt, Shoulder****	9x39	9x39	9x39
22	Spring, Drive Extension	165x74	165x74	165x74
23	Pulley, Motion Drive	91807	91807	91807
24	Pulley, Backside Idler	91179	91179	91179
25	Belt, Motion Drive	37x61	37x61	37x61
26	Knob, Shift Lever	91995	91995	91995
27	Lever, Shift	91805Z	91805Z	91805Z
28	Yoke, Shift	91806Z	91806Z	91806Z
29	Washer	17x148	17x148	17x148
31	Bolt, Hex	1x82	1x82	1x82
32	Lockwasher	18x32	18x32	18x32
33	Washer	17x38Z	17x38Z	17x38Z
34	Transaxle, JB Foote**	Foote 4360-8	Foote 4360-9	Foote 4360-9
35	Locknut, Flange	15x88	15x88	15x88
36	Bolt, Carriage	2x53Z	2x53Z	2x53Z
37	Support, Transaxle	91804F200	91804F200	91804F200
38	Screw	26x216	26x216	26x216
39	Key, Square	21553	21553	21553
40	Washer	17x160	17x160	17x160
41	Spacer, Foote Transaxle	91953	91953	91953
42	Tire*	91923	91914	91914
—	Tube	407049	407049	407049
43	Wheel	91627E804	91627E804	91627E804
44	Stem, Valve	24373	24373	24373
45	Washer	17x115	17x115	17x115
46	E-Ring	11x3	11x3	11x3
47	Washer	17x146	17x146	17x146
48	Washer	17x102Z	17x102Z	17x102Z

*When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.


**Replacement parts for the transaxle are available from a J.B. Foote Distributor listed on the warranty or contact: The J.B. Foote Foundry Co.; P.O. Box 236; Fredericktown, Ohio 43019; C/O Parts Service Manager.

***If D.O.M. (see page 89) is prior to 0519, order Part No. 92029SE.

****If D.O.M. (see page 89) is prior to 0519, order Part No. 9x12. 87

**MODEL NOS. 9-38620
9-40620**

MOTION DRIV



MOTION DRIVE**MODEL NOS. 9-38620
9-40620**

KEY NO.	DESCRIPTION	PART NO.	KEY NO.	DESCRIPTION	PART NO.
1	Grip	55449	31	Spring, Brake Extension	165x73
2	Grip, Inner	20476	32	Rod, Clutch	91808Z
3	Handle, Shift***	92031Z	33	Washer	17x148
4	Bolt, Shoulder***	9x39	34	Yoke, Shift	91884Z
5	Pin, Cotter	30x20	35	Bolt, Hex	1x82
6	Washer	17x47Z	36	Lockwasher	18x32
7	Nut, Adjustable	21920	37	Washer	17x38Z
8	Shifter Assembly	91888	38	Pilot, Support	91889
9	Guide, Belt	91754	39	Bracket Assembly, Idler***	92029Z
10	Locknut, Flange	15x84	40	Spring, Motion Drive Extension	165x74
11	Screw	26x249	41	Ring, Retainer	11x7
12	Link, Clutch	91877	42	Pulley, Motion Drive	91807
13	Pushnut	28x60	43	Pulley, Backside Idler	91179
14	Washer	17x100	44	Key, Woodruff #6	20697
15	Bracket, Shaft Pivot	91883	45	Transaxle, Peerless**	----
16	Link, Shifter	91887	46	Bolt, Carriage	2x53Z
17	Screw	26x249	47	Support, Transaxle	91804Z
18	Bracket, Support	91899Z	48	Screw	26x216
19	Nut, Flange	15x84	49	Locknut, Flange	15x88
20	Bolt, Hex	1x124	50	Key, Square	21553
21	Grip	91079	51	Washer	17x160
22	Rod, Control	91727Z	52	Spacer, Transaxle	91757
23	Screw	26x214	53	Tire*	91914
24	Guide, Bracket	91825Z	--	Tube	407049
25	Frame	91700F200	54	Wheel	91627
26	Clutch and Brake Pedal	21544	55	Stem, Valve	24373
27	Lever Assembly	91862	56	Washer	17x115
28	Belt, Motion Drive	37x61	57	E-Ring	11x3
29	Bracket, Support	91713	58	Washer	17x148
30	Latch, Park Brake	91712Z			

***The Date of Manufacture (D.O.M.) is a four digit number located under the Model Number on the Model Plate. The first three digits are the number of the day of the year. The fourth digit is the year (e.g. 0839 = March 24, 1989). If the D.O.M. is prior to 0519, refer to chart below when ordering parts.

KEY NO.	DESCRIPTION	REPLACEMENT PART NO.
3	Handle, Shift	92031SE
4	Bolt, Shoulder	9x12
39	Bracket Assembly, Idler	92029SE

* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.

** Replacement parts for the transaxle are available from a Tecumseh Authorized Service Center. See "Engines, Gasoline" or "Gasoline Engines" in the yellow pages of the telephone directory.

MODEL NO. 9-36600


9-38600

9-38608

9-38620

9-40620

STEERING



STEERING


MODEL NO. 9-36600
9-38600
9-38608
9-38620
9-40620

KEY NO.	DESCRIPTION	PART NO.
1	Wheel, Steering	91836
2	Nut, Hex	15x90
3	Bolt, Hex	1x66
4	Shaft, Steering	91714Z
5	Bolt, Hex	1x74
6	Screw	26x249
7	Bracket, Sector	91716F200
8	Gear, Pinion	91788
9	Bearing	91756
10	Locknut, Flange	15x84
11	Locknut, Flange	15x87
12	Washer	17x158
13	Gear, Sector	91750F200
14	Bracket Assembly, Sector	91834F200
15	Link, Drag	91749F200
16	Bolt, Hex	1x138
17	Support -Rear, Axle	91702F200
18	Rod, Tie	91717F200
19	Pin, Cotter	30x49
20	Bearing**	90035
21	Washer	17x57
22	Pin, Cotter	30x20
23	Washer**	17x113
24	Spindle Assembly, Right	91828F200
25	Spindle Assembly, Axle & Left	91827F200
26	Support, Front Axle	91701F200
27	Tire*	91912
—	Tube	407047
28	Stem, Valve	24373
29	Bearing, Wheel	91334
30	Washer	17x115
31	Wheel Assembly	91633E804
32	Spindle Assembly, Left	91830SE
33	Pin, Taper**	91753
34	Arm, Drag Link**	91833F200
35	Locknut, Flange**	15x79
36	Washer	17x83

* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.
 **Included with 91830SE.

**MODEL NOS. 9-36600
9-38608
9-38620
9-40620**

ENGINE MOUNT



* The engine model, type, and code numbers are on the engine. All parts to the engine are available from a Briggs & Stratton Authorized Service Center. See "Engines, Gasoline" or "Gasoline Engines" in the yellow pages of the telephone directory.
** 20094Z washer used in this engine mounting hole location only. In the three remaining engine mount locations use the 19x8 washer (Key 14). Mowers manufactured after D.O.M. 3358 (see page 89) use 19x8 (Key 14) in all four engine mount locations.

KEY

NO. DESCRIPTION

- 1 Fuel Cap
- 2 Fuel Tank
- 3 Hose Clamp
- 4 Fuel Line
- 5 Hose Clamp
- 6 Screw
- 7 Screw
- 8 Throttle Control
- 9 Engine*
- 10 Bolt, Hex
- 11 Shield, Muffler Heat
- 12 Muffler
- 13 Gasket
- 14 Washer
- 15 Bolt, Engine Mount

	9-36600	9-38608 9-38620 9-40620
23711	23711	
91869		
91174	91174	
90671	90671	
23713	23713	
26x214	26x214	
26x201	26x201	
90728	90728	
---	---	
1x118	1x134	
90332	91277	
90330	91271	
NA	91309	
19x8	19x8	
25x7	25x7	


KEY

- 16 Stack Pulley Assembly
- 17 Washer
- 18 Lockwasher
- 19 Bolt, Hex
- 20 Washer**

	9-36600	9-38608 9-38620 9-40620
91557Z	91557Z	
17x103	17x103	
19x35	19x35	
1x80	1x80	
20094Z	20094Z	

ENGINE MOUNT

MODEL NO. 9-38600




KEY NO.	DESCRIPTION	PART NO.
1	Fuel Cap	23711
2	Fuel Tank	91869
3	Hose Clamp (yellow)	91174
4	Fuel Line	91022
5	Hose Clamp (red)	23713
6	Screw	26x214
7	Screw	26x201
8	Throttle Control	90728
9	Engine*	----
14	Washer	19x8
15	Bolt, Engine Mount	25x7
16	Stack Pulley Assembly	91557Z
17	Washer	17x103
18	Lockwasher	19x35
19	Bolt, Hex	1x80
20	Washer**	20094Z

* All parts to the engine are available from a Tecumseh Authorized Service Center. See "Engines, Gasoline" or "Gasoline Engines" in the yellow pages of the telephone directory.

** 20094Z washer used in this engine mounting location only. In the three remaining engine mount locations use the 19x8 washer (Key 14). Mowers manufactured after D.O.M. 3358 (see page 89) use 19x8 (Key 14) in all four engine mount locations.

**MODEL NOS. 9-36600
9-38600
9-38608
9-38620
9-40620**

MOWER SUSPENSION



MOWER SUSPENSION


MODEL NOS. 9-36600
9-38600
9-38608
9-38620
9-40620

KEY NO.	DESCRIPTION	PART NO.
1	Grip	55449
2	Lever, Blade Control	91781Z
3	Bolt, Hex	25x3
4	Locknut, Hex	15x67
5	Lever Assembly, Switch	91917F200
6	Bolt, Carriage	2x53
7	Spring, Torsion	166x32
8	Bracket, Left Rear Hanger	91737F200
9	Nut, Flange	15x79
10	Nut, Adjusting	21920
11	Bracket, Adjuster Rod	91747F200
12	Washer	17x124
13	Pin, Hair	31x4
14	Washer	17x67
15	Pin, Pull	90827Z
16	Pin, Hair	31x6
17	Lever, Lower Blade Control	91787F200
18	Rod, Blade Control	91795Z
19	Plate, Adjuster	91741E701
20	Washer	17x103
21	Bell Crank*	92033Z
22	Lifter Assembly	91771F200
23	Knob, Steel	91261
24	Grip	91398
25	Spring, Compression	164x21
26	Handle Assembly	91823F200
27	Screw	26x49
28	Link Suspension	91776E701
29	Washer	17x47Z
30	Washer	17x91Z

*If D.O.M. (see page 89) is prior to 0519, order Part No. 92033SE.

**MODEL NOS. 9-36600
9-38600
9-38608
9-38620**

MOWER HOUSING



MOWER HOUSING**MODEL NOS. 9-36600****9-38600****9-38608****9-38620**

KEY NO.	DESCRIPTION	PART NO.
1	Nut, Hex	15x101
2	Lockwasher	18x33
3	Pulley, Jackshaft	91769
4	Locknut, Flange	15x84
5	Spacer	91903
6	Belt, Blade Drive	37x63
7	Pulley, Idler	91801
8	Pin, Cotter	30x20
9	Locknut, Flange	15x88
10	Washer	17x46Z
11	Brake Assembly, Right	91819E701
12	Brake Assembly, Left	91818E701
13	Spring, Torsion	166x27
14	Bolt, Hex	25x6
15	Bracket Assembly, Brake	91811Z
16	Rod, Brake	91745Z
17	Rod, Cross Link	91740Z
18	Pin, Hair	31x4
19	Nut, Adjustable	21920
20	Rod, Adjuster	91748Z
22	Link, Suspension	91776E701
23	Washer	17x103
24	Bracket Assembly, Right Lifter	91812E701
25	Nut, Flange	15x79
26	Bell Crank*	92033Z
27	Bolt, Shoulder*	9x39
28	Arm Assembly, Idler*	92032
29	Plate, Adjuster	91741E701
30	Cover, Pulley	91792E701
31	Guide, Belt	91797Z
32	Bracket Assembly, Left Lifter	91813E701
33	Spring, Extension	165x72
34	Bracket, Pivot	91743E701
35	Plate	91770E701
36	Washer	17x57
37	Bolt, Carriage	2x53
38	Deflector Assembly, Chute	91982
39	Spring, Torsion	166x4
40	Bracket, Hinge	91765E701
41	Bracket, Front Hanger	91793E701
42	Rod, Deflector	91767Z
43	Cap, Push On	28x23
44	Rod, Hanger	91739Z
46	Hanger, Front	91746E701
47	Screw	26x214
48	Guide, Belt	91782Z
49	Bolt, Hex	1x84
50	Housing, Jackshaft	90905
51	Jackshaft	91922
52	Adapter, Blade	91926
53	Blade (2 required)	91742HT
54	Washer, Belleville	17x166
55	Washer	17x165
56	Nut, Hex	15x100
58	Pin, Hair	31x6
1-58	Complete Mower Housing Assy.	403228

*If D.O.M. (see page 89) is prior to 0519, refer to chart below.


KEY NO.	PART NO.
26	92033SE
27	9x12
28	92032SE

Deck shell

91906 97

MODEL NO. 9-40620

MOWER HOUSING



MOWER HOUSING**MODEL NO. 9-40620**

KEY NO.	DESCRIPTION	PART NO.	KEY NOL	DESCRIPTION	PART NO.
1	Nut, Hex	15x101	31	Guide, Belt	91797Z
2	Lockwasher	18x33	32	Bracket Assembly, Left Lifter	91813E701
3	Pulley, Jackshaft	91943	33	Spring, Extension	165x72
4	Locknut, Flange	15x84	34	Bracket, Pivot	91743E701
5	Spacer	91903	35	Plate	91770E701
6	Belt, Blade Drive	37x62	36	Washer	17x57
7	Pulley, Idler	91801	37	Bolt, Carriage	2x53
8	Pin, Cotter	30x20	38	Deflector Assembly, Chute	91982
9	Locknut, Flange	15x88	39	Spring, Torsion	166x4
10	Washer	17x46Z	40	Bracket, Hinge	91765E701
11	Brake Assembly, Right	91819E701	41	Bracket, Front Hanger	91875E701
12	Brake Assembly, Left	91818E701	42	Rod, Deflector	91767Z
13	Spring, Torsion	166x27	43	Cap, Push On	28x23
14	Bolt, Hex	25x6	44	Rod, Hanger	91739Z
15	Bracket Assembly, Brake	91811Z	46	Hanger, Front	91746E701
16	Rod, Brake	91745Z	47	Screw	26x214
17	Rod, Cross Link	91873Z	48	Guide, Belt	91782Z
18	Pin, Hair	31x4	49	Bolt, Hex	1x84
19	Nut, Adjustable	21920	50	Housing, Jackshaft	90905
20	Rod, Adjuster	91872Z	51	Jackshaft	91922
22	Link, Suspension	91874E701	52	Adapter, Blade	91926
23	Washer	17x103	53	Blade (2 required)	91871HT
24	Bracket Assembly, Right Lifter	91812E701	54	Washer, Belleville	17x166
25	Nut, Flange	15x79	55	Washer	17x165
26	Bell Crank*	92033Z	56	Nut, Hex	15x100
27	Bolt, Shoulder*	9x39	58	Pin, Hair	31x6
28	Arm Assembly, Idler*	92032	1-59	Complete Mower Housing Assy.	403229
29	Plate, Adjuster	91741E701			
30	Cover, Pulley	91792E701			

*If D.O.M. (see page 89) is prior to 0519, refer to chart below.

KEY NO.	DESCRIPTION	PART NO.
26	Bell Crank	92033SE
27	Bolt, Shoulder	9x12
28	Arm Assembly, Idler	92032E701

MODEL NOS.

9-36600


9-38600

9-38608

9-38620

9-40620

WIRIN



WIRING

MODEL NOS. 9-36600
9-38600
9-38608
9-38620
9-40620

KEY NO.	DESCRIPTION	PART NO.
1	Switch, Seat Sensor	91031SE
2	Nut, Keps	15x66
3	Bolt, Hex	1x38Z
4	Battery 20 amp	91414
--	Acid, Battery (Electrolyte)	55702
5	Cable, Battery Ground	24x9
6	Screw	26x249
7	Cable, Red Battery	24x12
8	Cover, Solenoid	56049
9	Solenoid	24285
10	Nut, Hex	15x105
11	Washer, Shakeproof	19x40
12	Switch, Ignition	91846
13	Key & Ring, Ignition	20729
14	Harness, Wire	250x22
--	Fuse, Replacement	54212
--	Holder, Fuse Replacement	407078
15	Switch, PTO	91299
16	Screw	26x233
17	Switch, Clutch	24273
18	Screw	26x214
19	Socket, Light	91890
20	Bulb, Light	91954
21	Wire Harness	250x23
22	Jumper Wire	250x19
	(On Some Units Only)	
23	Ammeter	90729
	(On Some Units Only)	