

PARTS LIST NO. 530164216		WEED EATER® PARTS LIST	MODEL(s) GHT195LE
DATE 2/21/05	Replaces 530164216 - 6/17/04		PAGE NO. 3


Note: Illustration may differ from actual model due to design changes

TYPE 1



WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.



Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530054133	Assy-Leadwire/Switch (Incl.#2)	18.	530029948	Seal-Blade (Felt)
2.	530029954	Switch-Ignition	19.	530403228	Assy-Blade 19"
3.	530071656	Assy-Rear Handle & Tank	20.	530029946	Spring
4.	530015828	Washer-Clutch	21.	530014871	Assy-Fuel Cap
5.	530014396	Kit-Clutch Assy.	22.	530016406	Screw
6.	530056069	Assy-Drum	23.	530053900	Lockout-Throttle
7.	530096102	Assy-Gear Box (incl.# 9-11)	24.	530015934	Screw
8.	530015886	Screw	25.	530038305	Cover-Handle
9.	530016013	Bearing-Gear	26.	530015940	Screw
10.	530096009	Assy-Pinion	27.	530015775	Screw
11.	530015805	Screw	28.	530029958	Lever-Trigger
12.	530032121	Bushing-Blade	29.	530036123	Spring-Trigger
13.	530036046	Plate-Isolator	30.	530053884	Trigger
14.	530015849	Screw	31.	530015955	Screw
15.	530015934	Screw	32.	530094992	Handle-Front
16.	530029916	Cover-Gear Box Plate			
17.	530071690	Kit-Drive Gear Ass'y. (Incl. #12)			

✓ = NEW PART NUMBER FOR THIS IPL

★ = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)

● = THESE PARTS ARE ILLUSTRATED FOR CLARITY. ORDER COMPLETE ASSEMBLY.


PARTS LIST NO. 530164216		WEED EATER® PARTS LIST	MODEL(s) GHT195LE
DATE 2/21/05	Replaces 530164216 - 6/17/04		PAGE NO. 4

Note: Illustration may differ from actual model due to design changes

TYPE 2



WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.



Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530054133	Assy-Leadwire/Switch (Incl.#2)	19.	530071690	Kit-Drive Gear Ass'y. (Incl. #12)
2.	530029954	Switch-Ignition	20.	530029948	Seal-Blade (Felt)
3.	530071656	Assy-Rear Handle & Tank	21.	530403228	Assy-Blade 19"
4.	530015828	Washer-Clutch	22.	530016284	Nut
5.	530014396	Kit-Clutch Assy.	23.	530029946	Spring
6.	530056069	Assy-Drum	24.	530014871	Assy-Fuel Cap
7.	530071931	Assy-Gear Box (incl.# 9-11,13,17,22)	25.	530016406	Screw
8.	530015886	Screw	26.	530053900	Lockout-Throttle
9.	530016013	Bearing-Gear	27.	530015934	Screw
10.	530096009	Assy-Pinion	28.	530038305	Cover-Handle
11.	530015805	Screw	29.	530015940	Screw
12.	530032121	Bushing-Blade	30.	530015775	Screw
13.	530015940	Screw	31.	530029958	Lever-Trigger
14.	530036046	Plate-Isolator	32.	530036123	Spring-Trigger
15.	530015849	Screw	33.	530053884	Trigger
16.	530015934	Screw	34.	530094992	Handle-Front
17.	530016472	Screw	35.	530015955	Screw
18.	530029916	Cover-Gear Box Plate			

✓ = NEW PART NUMBER FOR THIS IPL ★ = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)
● = THESE PARTS ARE ILLUSTRATED FOR CLARITY. ORDER COMPLETE ASSEMBLY.

PARTS LIST NO. 530164216		WEED EATER® PARTS LIST	MODEL(s) GHT195LE
DATE 2/21/05	Replaces 530164216 - 6/17/04		PAGE NO. 5


Note: Illustration may differ from actual model due to design changes

TYPE 3



WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.



Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530054133	Assy-Leadwire/Switch (Incl.#2)	19.	530071690	Kit-Drive Gear Ass'y. (Incl. #12)
2.	530029954	Switch-Ignition	20.	530029948	Seal-Blade (Felt)
3.	530071656	Assy-Rear Handle & Tank	21.	530403228	Assy-Blade 19"
4.	530015828	Washer-Clutch	22.	530016284	Nut
5.	530014396	Kit-Clutch Assy.	23.	530029946	Spring
6.	530056069	Assy-Drum	24.	530014871	Assy-Fuel Cap
7.	530071931	Assy-Gear Box (incl.# 9-11,13,17,22)	25.	530016406	Screw
8.	530015886	Screw	26.	530053900	Lockout-Throttle
9.	530016013	Bearing-Gear	27.	530015934	Screw
10.	530096009	Assy-Pinion	28.	✓ 545008001	Kit-Handle Cover
11.	530015805	Screw	29.	530015940	Screw
12.	530032121	Bushing-Blade	30.	530015775	Screw
13.	530015940	Screw	31.	✓ 530057818	Lever-Trigger
14.	530036046	Plate-Isolator	32.	530036123	Spring-Trigger
15.	530015849	Screw	33.	530053884	Trigger
16.	530015934	Screw	34.	530094992	Handle-Front
17.	530016472	Screw	35.	530015955	Screw
18.	530029916	Cover-Gear Box Plate			

✓ = NEW PART NUMBER FOR THIS IPL ★ = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)
● = THESE PARTS ARE ILLUSTRATED FOR CLARITY. ORDER COMPLETE ASSEMBLY.