


ROTARY LAWN MOWER -- MODEL NUMBER PO4QN20SE



ROTARY LAWN MOWER - - MODEL NUMBER PO4QN20SE

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	131696	Control Bar	35	142748	Shoulder Bolt
2	179585	Rope Guide	36	700263	Wheel and Tire Assembly
3	851201X004	Engine Washer	37	83923	Nut, Hex
4	166860X479	Upper Handle	39	800090	Hubcap
5	151590X479	Lower Handle	41	149741	Thread Cutting Screw 5/16-18 x 3/4
7	131959	Handle Bolt 5/16-18 x 1-3/4	42	85463	Danger Decal
8	86899X004	Up-Stop Bracket	43	751592	Locknut 3/8-16
9	189241	Hex Washer Head Screw #10-24 x 1/2	44	150406	Hex Head Thread Rolling Screw 3/8-16 x 1-1/8
10	180817	Engine Zone Control Cable	46	188470	Lawn Mower Housing
12	66426	Wire Tie	49	851084	Hex Head Screw 3/8-24 x 1-3/8 Grade 8
13	51793	Hairpin, Cotter	50	850263	Helical Lockwasher 3/8
14	189713X428	Knob	51	851074	Hardened Washer
15	752052	Discharge Guard	52	145106	Blade, 20"
16	128415	Rivet	53	850977	Blade Adapter
17	73800400	Locknut 1/4-20	55	700839X479	Front Baffle
19	851855	Torsion Spring	56	---	Engine, Briggs & Stratton, Model Number 10K902 (For engine service and replacement parts, call Briggs & Stratton at 1-800-233-3723)
21	88602	Hinge Deflector	57	132004	Nut, Hex
22	150215	Hinge Rod	58	750634	Nut, Hex
23	189240	Rear Deflector	--	161058	Warning Decal (not shown)
24	750085X007	Wheel Adjusting Bracket	--	133379X479	Rear Baffle (not shown)
26	170345X479	Handle Bracket Assembly, RH	--	172782	Operator's Manual, English
27	170346X479	Handle Bracket Assembly, LH	--	172784	Operator's Manual, Spanish
29	146630	Spacer	--	190742	Repair Parts Manual
31	700331X004	Selector Spring			
32	87877	Selector Knob			
33	145935X479	Axle Arm Assembly			
34	62335	Belleville Washer			

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm