


# REPAIR PARTS

## ROTARY LAWN MOWER - - MODEL NO. PR6N22SHB



# REPAIR PARTS

## ROTARY LAWN MOWER - - MODEL NO. PR6N22SHB

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	63601	Locknut 1/4-20	45	170258	Wheel Assembly (Rear)
2	170285	Control Bar	46	83923	Locknut 1/16-18
3	132001	Rope Guide	47	170261	Wheel Assembly (Front)
4	172139X479	Upper Handle	48	57143	Washer
5	169708X479	Lower Handle	50	77400	Hubcap
6	63601	Locknut 1/4-20	51	74760514	Hex Head Bolt 5/16-18x
7	131959	Handle Bolt 5/16-18	52	150406	Hex Head Thread Rolling Screw 3/8-16 x 1
8	144929	Hex Washer Head Screw 1/4-20 x 2-1/8	55	107339X	Danger Decal
9	<b>170297</b>	Throttle Control	59	<b>172820</b>	Lawn Mower Housing (Incl. Key Nos. 55)
11	<b>133107</b>	Engine Zone Control Cable	61	851514	Blade Adapter
12	750097	Hex Washer Head Screw #10-24 x 1/2	62	141114	22" Blade
13	850733X004	Up-Stop Bracket	63	851074	Hardened Washer
14	213146	Cable Clamp	64	850263	Helical Lockwasher 3/8
15	83816	Screw #10 x 5/8	65	851084	Screw Hex Head 3/8-24 x 1-3/8 (Grd. 8)
16	170146	Handle Knob	67	-----	Engine - Briggs & Stratton Model No. 12H802
19	51793	Hairpin Cotter			Order parts from engine manufacturer
21	165858	Rear Deflector	70	167130X004	Axle Arm Assem.(LR)
22	66426	Wire Tie	72	167132X004	Axle Arm Assm. ((LF)
23	160831	Discharge Guard	73	167133X004	Axle Arm Assm. (RF)
27	160832	Torsion Spring	74	751153	Nut
30	160833	Hinge Rod	75	160830	Plate. Mulcher
33	63124	Locknut 5/16-18	76	161622	Clip. Closeout
34	170373X479	Wheel Bracket Support (Left)	77	74760412	Screw
35	170374X479	Wheel Bracket Support (Right)	--	172782	Operator's Manual (English)
36	160835X007	Wheel Bracket Adjuster	--	172783	Operator's Manual (French)
39	168360X004	Selector Spring	--	162300	Warning Decal(Not Shown)
40	170143	Selector Knob	--	<b>175453</b>	Replacement Parts Manual
41	167131X004	Axle Arm Assembly (RR)			
43	19112222	Washer			
44	160828	Shoulder Bolt			