


ROTARY LAWN MOWER -- MODEL NUMBER SO45N22SHA



ROTARY LAWN MOWER -- MODEL NUMBER SO45N22SHA

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	73800400	Locknut 1/4-20	46	83923	Locknut 1/16-18
2	86902	Control Bar	47	800220	Wheel Assembly, Front
3	179585	Rope Guide	51	74760514	Hex Head Bolt 5/16-18
4	169709X479	Upper Handle	52	150406	Hex Head Thread Rolling Screw 3/8-16 x 1
5	169708X479	Lower Handle	55	141846	Danger Decal
6	132004	Nut, Hex	59	165865	Lawn Mower Housing (Includes Key Number 55)
7	131959	Handle Bolt 5/16-18	61	851514	Blade Adapter
11	176556	Engine Zone Control Cable	62	141114	22" Blade
12	750634	Hex Washer Head Screw #10-24 x 1/2	63	851074	Hardened Washer
13	86899X004	Up-Stop Bracket	64	850263	Helical Lockwasher 3/8
16	128638	Wing Nut, Steel	65	851084	Screw Hex Head 3/8-24 x 1-3/8 Grade 8
19	51793	Hairpin Cotter	67	---	Engine, Briggs & Stratton, Model Number 10M902 (For engine service and replacement parts, call Briggs & Stratton at 1-800-233-3723)
21	188987	Rear Deflector	70	180409X004	Axle Arm Assembly, LR
22	66426	Wire Tie	72	186577X004	Axle Arm Assembly, LF
23	160831	Discharge Guard	73	186578X004	Axle Arm Assembly, RF
27	160832	Torsion Spring	74	166785	Nut, Hex
30	160833	Hinge Rod	76	161622	Clip, Closeout
33	73800500	Locknut 5/16-18	77	74760412	Screw
34	170373X479	Wheel Bracket Support, LH	79	160830	Mulcher Plate
35	170374X479	Wheel Bracket Support, RH	--	161058	Warning Decal (Not Shown)
36	160835X007	Wheel Bracket Adjuster	--	172782	Operator's Manual, English
39	168360X004	Selector Spring	--	172784	Operator's Manual, Spanish
40	87877	Selector Knob	--	190323	Replacement Parts Manual
41	180410X004	Axle Arm Assembly, RR			
43	183901	Spacer			
44	160828	Shoulder Bolt			
45	188808	Wheel Assembly, Rear			

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm