


BLOWER VACUUM PARTS LIST - MODEL BV720r

(Serial no. 611000001 and greater)



<u>Item</u>	<u>Part No.</u>	<u>Description</u>
1	612605	Hanger
2	180917	Boom Assembly
3	145569	Anti-Rotation Screw
4	683882	Drive Shaft Assembly
5	153597	Lower Clamp Assembly (includes 3)
6	181853	Mounting Screw
7	180107	Upper Housing
8	683884	Clamp Assembly
9	612929	Adapter
10	612930	Clamp
11	180108	Vacuum Bag Assembly (includes items 9 and 10)

<u>Item</u>	<u>Part No.</u>	<u>Description</u>
12	145570	Retaining Ring
13	145567	Washer
14	181636	Bushing Housing Assembly
15	612931	Impeller Shaft
16	180197	Impeller
17	683887	Nut and Washer Assembly
18	181586	Shield
19	180109	Lower Housing
20	181345	Mounting Screw
21	683888	Vacuum Tube Assembly
22	181641	Blower Tube Assembly