

Item	Part No.	Description
1	182402	Front Handle
2	181403	Screw
3	180443	Disc Assembly
4	181405	Switch
5	181406	Lock Button
6	181407	Spring
7	181401	Tag
8	180836	Screw
9	180170	Bearing Strap
10	181388	Screw
11	181408	Logo Decal (Model HT716r)
	181409	Logo Decal (Model HT718r)
	181410	Logo Decal (Model HT722r)
12	181411	Housing Assembly
13	180161	Sleeve Bearing
14	180162	Washer
15	180163	Washer
16	181412	Field Assembly (Model HT716r)
17	180842	Field Assembly (Model HT718r, HT722r)
18	180167	Brush Tube
19	181414	Armature
20	181415	Spring Washer
21	181416	Washer
22	180172	Sleeve Bearing
23	181417	Gear Housing w/Bearings (includes items 22, 25 and 26)
24	180174	Blade Seal
25	182418	Spacer
26	180176	Sleeve Bearing
27	180177	Washer
28	180178	Gear Assembly
29	180179	Spring Washer
30	180180	Drive Washer
31	181419	Blade Assembly (Model HT716r)
	181420	Blade Assembly (Model HT718r)
	181421	Blade Assembly (Model HT722r)
32	180185	Grease Cover
	181398	Screw
		Blade Cover

