


REPLACEMENT PARTS - MODEL HT816r/HT818r/HT822r

SINGLE ACTION HEDGE TRIMMERS

41AF816G034 / 41AF818G034 / 41AF822G034



Item	Part No.	Description
1	182884	Housing Assembly
2	182886	Screw
3	182887	Logo Plate (HT816r)
3	182888	Logo Plate (HT818r)
3	182889	Logo Plate (HT822r)
4	182855	Switch
5	182856	Switch Trigger Assembly
6	182857	Lock-On Button
7	182903	Sleeve Bearing
8	182905	Washer
9	182906	Washer
10	182859	Field and Disc Assembly
11	182907	Brush Assembly
12	182862	Armature (HT816r/HT818r/HT822r)
13	182890	Spring Washer
14	182891	Washer
15	182892	Gear Housing with Bearings (HT816r/HT818r/HT822r) (Includes 8, 9, 20, 25, 26, 27)
16	182894	Bearing Strap

Item	Part No.	Description
17	181345	Screw
18	181424	Screw
19	182895	Data Plate (HT816r)
19	182896	Data Plate (HT818r)
19	182897	Data Plate (HT822r)
20	182632	Blade Seal
21	181422	Blade Cover
22	181424	Screw
23	180182	Blade Assembly (HT816r)
23	180183	Blade Assembly (HT818r)
23	180184	Blade Assembly (HT822r)
24	180185	Grease Cover
25	182637	Drive Washer
26	182635	Gear Assembly (HT816r)
27	182633	Washer (HT816r/HT818r/HT822r)
28	180050	Lock Nut
29	182908	Front Handle
30	180048	Screw
*	182556	Owner's Manual

*Not shown