


**PARTS LIST - RYOBI SS720r**

Serial no. 406147515 and greater.



ITEM	PART NO.	PART NAME
1	612605	Hanger
2	180689	Driver Shaft Housing
3	683608	Flexible Drive Shaft
4	153597	Clamp Assembly
5	180547	Guard Mounting Hardware
6	145569	Anti-Rotation Screw
7	180549	Gearbox Assembly
8	180548	Guard and Blade Assembly
9	180553	Blade Assembly
10	153619	Outer Spool and Eyelet Assembly

ITEM	PART NO.	PART NAME
11	145566	Eyelet
12	610660	Retainer (10 pack)
13	610317	Spring
14	153600	Inner Reel
15	153066	Bump Knob
*	610375	Monofil Line, 50 feet
*	153577	Spool and Line Assembly
*		not shown