
For Discount Tecumseh Engine Parts Call 606-678-9623 or 606-561-4983 HH100-115174C Page 1 of 9 Engine Parts List #1

ILLUSTRATION SHOWS TYPICAL PARTS ONLY, ORDER BY PART NUMBER, PARTS NOT LISTED ARE SUPPLIED BY DEM.




Ref #	Part Number Qt	y Description
	33039	Cylinder (Incl.2,4,30,47,119) (3-5/16 ")
2	27652	Pin, Dowel
4	31950	Seal, Oil
	31940	Intake Valve (Std.)
	31941	Intake Valve (1/32" OS) (Incl. 9)
	31942	Exhaust Valve (Std.)
	31943	Exhaust Valve (1/32" OS) (Incl. 9)
	650592	Key, Flywheel
	31944	Spring, Valve
	31946	Cap, Lower valve spring (1/32" OS)
	31945	Cap, Lower valve spring (Std.)
	31945	Cap, Lower valve spring (Std.)
	31946	Cap, Lower valve spring (1/32" OS)
	20810	Pin, Valve spring retainer
	32059B	Crankshaft (Incl. 12, 13, 17, 78 & 79)
	29783	Pin, Crankshaft gear
	31931	Gear, Crankshaft
	32001C	Piston & Pin Ass'y. (Std.)(Incl.16)(3 -5/16")
	32002B	Piston & Pin Ass'y. (.010" OS) (Incl. 16)
	32003B	Piston & Pin Ass'y. (.020" OS) (Incl. 16)
	32619B	Piston & Pin Ass'y. (.030" OS) (Incl. 16)
	34508	Piston, Pin & Ring Set (Std.) (3-5/16 " Bore)
	34509	Piston, Pin & Ring Set (.010" OS)
	34510	Piston, Pin & Ring Set (.020" OS)
	34850	Piston, Pin & Ring Set (.030" OS)
	34523	Piston, Pin & Ring Set (.040" OS)
	32620B	Piston & Pin Ass'y. (.040" OS) (Incl. 16)
	32004	Ring Set (Std.) (3-5/16" Bore)
	32005	Ring Set (.010" OS)
	32006	Ring Set (.020" OS)
	32623	Ring Set (.030" OS)
	32624	Ring Set (.040" OS)
	32321	Re-Ringing Set, Piston
	31919	Ring, Piston pin retaining
	33093A	Connecting Rod Ass'y.(Std.)(Incl.18, 19 & 20)
	34383	Connecting Rod Assy. (.010" US)(Incl.1 8,19,20)
	34384	Connecting Rod Assy.(.020" US)(Incl.1 8,19,20)
	32077	Bolt, Connecting rod
	26073	Washer, Connecting rod
	28264	Nut Assy., Lock
	32150	Camshaft (MCR)
	31939	Lifter, Valve
23A	31956A	* Gasket, Cylinder cover
	32580A	Cover, Cylinder (Incl. 4, 28, 30, 34, & 43)
25A	29673	* Gasket, Oil fill
25A	35499	"O" Ring
26	33069	Dipstick (Incl. 25A)
28	32426	Spacer, Governor rod
29	650588	Screw, 1/4-20 x 2"
30	31927	Oil Drain Plug
	31968	Link, Governor
	650451	Screw, 1/4-20 x 1"
	31964	Clamp, Governor lever
	29193	Ring, Retaining
	31963	Lever, Governor adjusting
	650518	Lockwasher
37	650544	Screw, 10-24 x 7/8"
	7975	Nut, 10-24

Ref #	Part Number Qty	Description
39	31965	Plate, Governor spring
40	30312	Screw, 10-32 x 1/2"
41	31967	Spring, Governor
42	30590A	Washer, Flat
43	32425	Rod Assy., Governor
44	31948	Spool, Governor
	29193	Ring, Retaining
	31947	Gear Assy., Governor
	31930	Shaft, Mechanical Governor
	32000A	* Gasket, Cylinder head
	33034	Head, Cylinder
	650694A	Screw, 5/16-18 x 2" (Use as required)
	650711	Screw, 5/16-18 x 1-5/8" (Use as required)
	650628A	Screw, 5/16-18 x 2-3/8" (Use as requi red)
	650695A	Screw, 5/16-18 x 2-1/4" (Use as requi red)
	650714	Screw, 5/16-18 x 1-5/8" (Use as required)
	650697A	Screw, 5/16-18 x 2-1/2" (Use as required)
	650692	Screw, 5/16-18 x 1-3/4" (Use as required)
	650603	Screw, $5/16-18 \times 5/8"$ (Use as require d)
	33636	Resistor Spark Plug (RJ-8C)
	34251	Resistor Spark Plug (RJ-17LM)
	33035	Cover, Cylinder head
	28537	Washer, Plain
	650691	Washer, Flat (Use as required)
	650690	Washer, Belleville (Use as required)
	8274	Washer, Lock (Use as required)
	650128	Screw, 10-24 x 1/2"
	31976	Extension, Blower housing
	31978	Bracket, Fuel tank
	410144B	Fuel Cap (White Plastic)(Std.)(As req uired)
	34210	Fuel Cap (Red Plastic) (Spurt resistant, High profile) (Use as
		required)
	04070	
	31979	Strap, Fuel tank
	650451	Screw, 1/4-20 x 1"
	650456	Nut, Flange whiz-lock, 1/4-20
	650517	Screw, 1/4-20 x 27/32" (Use as required)
	650561	Screw, 1/4-20 x 5/8" (Use as required)
	30063	Screw, 1/4-20 x 1/2" (Use as required)
	792028	Screw, 5/16-18 x 7/8" (Use as require d)
	8345	Washer, Flat
	8303	Lockwasher
	29683	Strainer & Shut-off, Fuel
	26460	Clamp, Fuel line (Use as required)
	29774	Fuel Line (Braided) (8.25") (Use as r equired)
	30705	Fuel Line (Braided) (16") (Use as req uired)
	30962	Fuel Line (Braided) (32") (Use as req uired)
	30965	Fuel Line (Braided) (48") (Use as req uired)
	32579	Baffle, Blower housing
	650561	Screw, 1/4-20 x 5/8"
	31932	Bearing, Tapered roller
	31928	Cup, Bearing
80	32031	Spacer, Steel (.010" thick) NOTE: Determine the gap
		between the cover and the machined surface on the cylinder
		which can be from .001"up to .007" in which case no shim
		gaskets will be required. Use of gasket must be limited to a
		combined total of .010" thick. Steel spacersmust be used
		as required

Ref #	Part Number C	ty Description
81	31971	* Gasket, Shim (.004/.005 thick) NOTE: Determine the gap between the cover and the machined surface on the cylinder which can be from .001"up to .007" in which case no shim gaskets will be required. Use of gasket must be limited to a combined total of .010" thick. Steel spacersmust be used as req
	32599 31972	"O" Ring * Gasket, Shim (.005/.007 thick) NOTE: Determine the gap between the cover and the machined surface on the cylinder which can be from .001"up to .007" in which case no shim gaskets will be required. Use of gasket must be limited to a combined total of .010" thick. Steel spacersmust be used as req
83	32577	Cover, Cylinder NOTE: Determine the gap between the cover and the machined surface on the cylinder which can be from .001"up to .007" in which case no shim gaskets will be required. Use of gasket must be limited to a combined total of .010" thick. Steel spacersmust be used as required to eliminat
84A 85 86 87 91 92 95 96 98 99 100 101 102 103 104 105 106 107 108 109 112 113 114 115 120 121 122E 122D 125A 126 128 128	792028 650679 650594 33044A 8274 650595 8274 650624 31958 31957 35350 650128 28558 31966 31984A 650597 650591 33099 32042 32043B 33038 29752 650587 27272 650399 30767 32376 32378 32009 650513 650713 650713 650713 650713 650713 650713 650713 650713 650429 792028	Screw, 5/16-18 x 7/8" Lockwasher, 5/16" (Use as required) Washer, Lock Nut, Flywheel, 3/4-16 Blower Hsg. (Incl.73) (For electric s tarter) Washer, Lock Screw, 5/16-24 x 3/8" Washer, Lock Screw, 5/16-24 x 9/16" * Gasket, Breather Breather Assy. Tube, Breather Breather Assy. Tube, Breather Screw, 10-24 x 1/2" Washer, Wave Bushing, Control lever Lever, Control Screw, 10-24 x 5/8" Screw, 10-24 x 5/8" Screw, 10-24 x 2" Spring Nipple, Exhaust pipe Muffler Plug, Button (Use as required) Nut & Lockwasher Assy. Stud, Carburetor * Gasket, Air cleaner Screw, 10-32 x 5/8" Spacer, Air cleaner Bracket, Air cleaner Bracket, Air cleaner Bracket, Air cleaner Bracket, Air cleaner Nut, Wing Screw, 5/16-18 x 5/8" (Use as require d) Screw, 5/16-18 x 3/4" (Use as require d)
	8274 26073 31960	Lockwasher, Split (Use as required) Washer, Flat (Use as required) * Gasket, Carburetor

		y Description
147	31959	Baffle, Air
151	33356	Terminal, Ground
156	730201	Trigger Pin Kit (Use as required)
173	610118	Cover, Spark plug (Use as required)
176	31992	Spacer, Screen
	8345	Washer, 1/4 plain (Use as required)
	27070	Washer, Lock 1/4 E.T. (Use as require d)
178	650675	Washer, Flat 1/4 (Use as required)
	27793	Clip, Conduit
	28942	Screw, 10-32 x 3/8"
	650713	Screw, 5/16-18 x 5/8"
	26073	Washer, Flat
	33776	Screen, Starter pulley
	31980	Pulley, Starter
	650680	Screw, 1/4-20 x 1-1/2"
	32046	Rope Assy., Starter (Use as required)
	650661	Screw, 1/4-20 x 3/4"
	610408	Nut, Hex
	610750	Grommet, Lead wire
	610748	Solid State Magneto (Incl.151,173,265 ,266)
	610746	Solid State Flywheel
	34346	Decal, Instruction
	550223	Decal, Name
	32676	Decal, Solid State
	31752	Decal, Air cleaner
	32255A	Valve, Seat, Spring & Gasket Assy.
301	631564	Carburetor (Incl. 145) (Refer to Division 5, Section A, page 94 for breakdown)
304	33237A	* Gasket Set (Incl. items marked *)


For Discount Tecumseh Engine Parts Call 606-678-9623 or 606-561-4983 HH100-115174C Page 6 of 9 Engine Parts List #2



Ref #	Part Number	Qty	Description
178 180 222 222	27070 650675 650701 792028 650781 34276	Ĩ	Washer, Lock 1/4 E.T. (Use as require d) Washer, Flat 1/4 (Use as required) Screw, 8-18 x 7/16" (Use as required) Screw, 5/16-18 x 7/8" (Use w/32817 st r.motor) Screw,5/16-18 x 11/16"(Use w/33835 st r.motor) Plate, Cover (Use as required to cover regulator mounting hole in blower housing)
	650736 730134		Screw, 10-16 x 3/8" (Use as required) Rewind Starter Kit (Incl. 165, 166, 167, 168, 169 & 291) (Use as required)
	33018 610761		Harness Assy., Adapter (Use as requir ed) Alternator Coil (Solid State) (10 Amp) (Incl. Nos. 253, 256 & 257A)
256 257B 257A 266 268 275	650416 610922 610824 610819 610750 610749 730198 33835		Screw, 10-32 x 1" Terminal, Female Flat Connector (Female terminals) (As req.) Connector, Pyramid (For female termin als) Grommet, Lead wire Solid State Regulator (10 Amp) Starter Switch Kit(Incl. 287-298) (As req.) Electric Starter Motor (12 Volt) NOTE: The 32817 and 33835 starter motors are used interchangeably on the se models. Refer to service numberstamped on end cap of motor, or on decal for identification. Refer to Division 5, Section D for breakdown.

For Discount Tecumseh Engine Parts Call 606-678-9623 or 606-561-4983 HH100-115174C Page 8 of 9 Engine Parts List #3

ILLUSTRATION SHOWS TYPICAL PARTS ONLY. ORDER BY PART NUMBER. PARTS NOT LISTED ARE SUPPLIED BY DEM.



Ref #	Part Number	Qty	Description
41	31967		Spring, Governor
62A	31977		Fuel Tank (Incl. 63)
70	29634		Fitting, Fuel line
71	26460		Clamp, Fuel line (Use as required)
72	29774		Fuel Line (Braided) (8.25") (Use as r equired)
72	30705		Fuel Line (Braided) (16") (Use as req uired)
72	30962		Fuel Line (Braided) (32") (Use as req uired)
72	30965		Fuel Line (Braided) (48") (Use as req uired)
110	32141		90 Degree Exhaust Elbow
111	650590		Nut, Conduit
119	28534		Pipe Plug, 1/8-27 (Use as required)
119	9556		Plug, Pipe, 1/8-27 (Use as required)
123A	32008		Element, Air cleaner
172	31990		Bracket, Choke control
184	27793		Clip, Conduit
185	28942		Screw, 10-32 x 3/8"