
ILLUSTRATION SHOWS TYPICAL PARTS ONLY, ORDER BY PART NUMBER, PARTS NOT LISTED ARE SUPPLIED BY DEML



www.mymowerparts.com

| Ref# | Part Number (| Qty | Description |
|------|---------------|-----|--|
| | 33039 | | Cylinder (Incl.2,4,30,47,119) (3-5/16 ") |
| | 27652 | | Pin, Dowel |
| | 31950 | | Seal, Oil |
| | 31940 | | Intake Valve (Std.) |
| | 31941 | | Intake Valve (3.2" OS) (Incl. 9) |
| | 31942 | | Exhaust Valve (Std.) |
| | 31943 | | Exhaust Valve (3/32" OS) (Incl. 9) |
| | | | , , , |
| | 650592 | | Key, Flywheel |
| | 31944 | | Spring, Valve |
| | 31945 | | Cap, Lower valve spring (Std.) |
| | 31946 | | Cap, Lower valve spring (1/32" OS) |
| | 31946 | | Cap, Lower valve spring (1/32" OS) |
| | 31945 | | Cap, Lower valve spring (Std.) |
| | 20810 | | Pin, Valve spring retainer |
| | 33391B | | Crankshaft (Incl. 12, 13, 78 & 79) |
| 12 | 29783 | | Pin, Crankshaft gear |
| 13 | 31931 | | Gear, Crankshaft |
| 14A | 32001C | | Piston & Pin Ass'y. (Std.)(Incl.16)(3 -5/16") |
| 14A | 32002B | | Piston & Pin Ass'y. (.010" OS) (Incl. 16) |
| 14A | 32003B | | Piston & Pin Ass'y. (.020" OS) (Incl. 16) |
| | 32619B | | Piston & Pin Ass'y. (.030" OS) (Incl. 16) |
| | 34508 | | Piston, Pin & Ring Set (Std.) (3-5/16 " Bore) |
| | 34509 | | Piston, Pin & Ring Set (.010" OS) |
| | 34510 | | Piston, Pin & Ring Set (.020" OS) |
| | 34850 | | Piston, Pin & Ring Set (.030" OS) |
| | 34523 | | Piston, Pin & Ring Set (.000 OS) |
| | | | • |
| | 32620B | | Piston & Pin Ass'y. (.040" OS) (Incl. 16) |
| | 32004 | | Ring Set (Std.) (3-5/16" Bore) |
| | 32005 | | Ring Set (.010" OS) |
| | 32006 | | Ring Set (.020" OS) |
| | 32623 | | Ring Set (.030" OS) |
| | 32624 | | Ring Set (.040" OS) |
| | 32321 | | Re-Ringing Set, Piston |
| | 31919 | | Ring, Piston pin retaining |
| 17 | 33093A | | Connecting Rod Ass'y.(Std.)(Incl.18, 19 & 20) |
| 17 | 34383 | | Connecting Rod Assy.(.010" US)(Incl.1 8,19,20) |
| 17 | 34384 | | Connecting Rod Assy.(.020" US)(Incl.1 8,19,20) |
| 18 | 32077 | | Bolt, Connecting rod |
| 19 | 26073 | | Washer, Connecting rod |
| | 28264 | | Nut Assy., Lock |
| | 32150 | | Camshaft (MCR) |
| | 31939 | | Lifter, Valve |
| | 31956A | | * Gasket, Cylinder cover |
| | 32580A | | Cover, Cylinder (Incl. 4, 28, 30, 34, & 43) |
| | 32908 | | Oil Fill Tube |
| | 29673 | | * Gasket, Oil fill tube |
| | | | |
| | 29985 | | "O" Ring |
| | 35499 | | "O" Ring |
| | 33055 | | Dipstick (Incl. 25A) |
| | 32426 | | Spacer, Governor rod |
| | 650588 | | Screw, 1/4-20 x 2" |
| | 31968 | | Link, Governor |
| 32 | 650451 | | Screw, 1/4-20 x 1" |
| 33 | 31964 | | Clamp, Governor lever |
| 34 | 29193 | | Ring, Retaining |
| | 31963 | | Lever, Governor adjusting |
| | 650518 | | Lockwasher |
| | 650544 | | Screw, 10-24 x 7/8" |
| 9/ | WWW mumo | | |

Screw, 10-24 x 7/8"

WWW.mymowerparts.com

For Discount Tecumseh Engine Parts Call 606-678-9623 or 606-561-4983 $\,$ Page 3 of 9 Engine Parts List #1


| Ref # Part Number Qty Description 38 7975 Nut, 10-24 39 31965 Plate, Governor spring 40 30312 Screw, 10-32 x 1/2" 41 31967 Spring, Governor 42 30590A Washer, Flat 43 32425 Rod Assy., Governor 44 31948 Spool, Governor 45 29193 Ring, Retaining 46 31947 Gear Assy., Governor 47 31930 Shaft, Mechanical Governor 48 32000A * Gasket, Cylinder head 49 33034 Head, Cylinder 51 650694A Screw, 5/16-18 x 2" (Use as required) 51 650628A Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650695A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650697A Screw, 5/16-18 x 1-3/8" (Use as requi red) 51 650603 Screw, 5/16-18 x 1-3/8" (Use as required) 52 650603 Screw, 5/16-18 x 5/8" (Use as required) 53 33636 Resistor Spark Plug (RJ-8C) |
|---|
| 39 31965 40 30312 5crew, 10-32 x 1/2" 41 31967 5pring, Governor 42 30590A Washer, Flat 43 32425 Rod Assy., Governor 44 31948 Spool, Governor 45 29193 Ring, Retaining Gear Assy., Governor 47 31930 Shaft, Mechanical Governor 48 32000A 49 33034 Flead, Cylinder head 49 33034 Flead, Cylinder head 51 650694A Screw, 5/16-18 x 2" (Use as required) 51 650711 Screw, 5/16-18 x 2-3/8" (Use as requi red) 51 650695A Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650697A Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650692 Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650603 Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650603 Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650603 Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650603 Screw, 5/16-18 x 1-3/4" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as requi red) 52 Screw, 5/16-18 x 5/8" (Use as requi red) 53 33636 |
| 40 30312 Screw, 10-32 x 1/2" 41 31967 Spring, Governor 42 30590A Washer, Flat 43 32425 Rod Assy., Governor 44 31948 Spool, Governor 45 29193 Ring, Retaining 46 31947 Gear Assy., Governor 47 31930 Shaft, Mechanical Governor 48 32000A * Gasket, Cylinder head 49 33034 Head, Cylinder 51 650694A Screw, 5/16-18 x 2" (Use as required) 51 650711 Screw, 5/16-18 x 2-3/8" (Use as required) 51 650628A Screw, 5/16-18 x 2-3/8" (Use as required) 51 650695A Screw, 5/16-18 x 2-1/4" (Use as required) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as required) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as required) 51 650603 Screw, 5/16-18 x 5/8" (Use as required) 52 Screw, 5/16-18 x 5/8" (Use as required) 53 33636 Resistor Spark Plug (RJ-8C) |
| 41 31967 42 30590A 43 32425 44 31948 45 29193 46 31947 47 31930 48 32000A 49 33034 49 33034 51 650694A 51 650695A 51 650697A 51 650692 51 650603 51 650603 51 650603 51 650603 51 650609A 51 650603 52 650603 52 650607 54 650607 55 75 76 78 × 2-1/2" (Use as required) 56 75 76 78 × 2-1/2" (Use as required) 57 650603 58 75 76 718 × 1-3/4" (Use as required) 59 716 718 × 1-3/4" (Use as required) 50 75 716 718 × 1-3/4" (Use as required) 50 75 716 718 × 1-3/4" (Use as required) 51 650603 50 75 716 718 × 1-3/4" (Use as required) 51 650603 50 75 716 718 × 1-3/4" (Use as required) 51 650603 50 75 716 718 × 1-3/4" (Use as required) 51 650603 50 75 716 718 × 1-3/4" (Use as required) 51 650603 50 75 716 718 × 1-3/4" (Use as required) 51 650603 50 75 716 718 × 1-3/4" (Use as required) |
| 42 30590A Washer, Flat 43 32425 Rod Assy., Governor 44 31948 Spool, Governor 45 29193 Ring, Retaining 46 31947 Gear Assy., Governor 47 31930 Shaft, Mechanical Governor 48 32000A * Gasket, Cylinder head 49 33034 Head, Cylinder 51 650694A Screw, 5/16-18 x 2" (Use as required) 51 650711 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650695A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650714 Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650603 Screw, 5/16-18 x 1-3/4" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as requi red) 53 33636 Resistor Spark Plug (RJ-8C) |
| 43 32425 Rod Assy., Governor 44 31948 Spool, Governor 45 29193 Ring, Retaining 46 31947 Gear Assy., Governor 47 31930 Shaft, Mechanical Governor 48 32000A * Gasket, Cylinder head 49 33034 Head, Cylinder 51 650694A Screw, 5/16-18 x 2" (Use as required) 51 650711 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650628A Screw, 5/16-18 x 2-3/8" (Use as requi red) 51 650695A Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as requi red) 53 33636 Resistor Spark Plug (RJ-8C) |
| 44 31948 Spool, Governor 45 29193 Ring, Retaining 46 31947 Gear Assy., Governor 47 31930 Shaft, Mechanical Governor 48 32000A * Gasket, Cylinder head 49 33034 Head, Cylinder 51 650694A Screw, 5/16-18 x 2" (Use as required) 51 650711 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650628A Screw, 5/16-18 x 2-3/8" (Use as requi red) 51 650714 Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as requi red) 53 33636 Resistor Spark Plug (RJ-8C) |
| 45 29193 Ring, Retaining 46 31947 Gear Assy., Governor 47 31930 Shaft, Mechanical Governor 48 32000A * Gasket, Cylinder head 49 33034 Head, Cylinder 51 650694A Screw, 5/16-18 x 2" (Use as required) 51 650711 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650628A Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650695A Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650714 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as required) 53 33636 Resistor Spark Plug (RJ-8C) |
| 46 31947 Gear Assy., Governor 47 31930 Shaft, Mechanical Governor 48 32000A * Gasket, Cylinder head 49 33034 Head, Cylinder 51 650694A Screw, 5/16-18 x 2" (Use as required) 51 650711 Screw, 5/16-18 x 2-3/8" (Use as requi red) 51 650628A Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650695A Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650714 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as require d) 53 33636 Resistor Spark Plug (RJ-8C) |
| 47 31930 Shaft, Mechanical Governor 48 32000A * Gasket, Cylinder head 49 33034 Head, Cylinder 51 650694A Screw, 5/16-18 x 2" (Use as required) 51 650711 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650628A Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650695A Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650714 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as require d) 53 33636 Resistor Spark Plug (RJ-8C) |
| 48 32000A * Gasket, Cylinder head 49 33034 Head, Cylinder 51 650694A Screw, 5/16-18 x 2" (Use as required) 51 650711 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650628A Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650695A Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650714 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as required) 53 33636 Resistor Spark Plug (RJ-8C) |
| 49 33034 Head, Cylinder 51 650694A Screw, 5/16-18 x 2" (Use as required) 51 650711 Screw, 5/16-18 x 1-5/8" (Use as required) 51 650628A Screw, 5/16-18 x 2-3/8" (Use as required) 51 650695A Screw, 5/16-18 x 2-1/4" (Use as required) 51 650714 Screw, 5/16-18 x 1-5/8" (Use as required) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as required) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as required) 51 650603 Screw, 5/16-18 x 5/8" (Use as required) 53 33636 Resistor Spark Plug (RJ-8C) |
| 51 650694A Screw, 5/16-18 x 2" (Use as required) 51 650711 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650628A Screw, 5/16-18 x 2-3/8" (Use as requi red) 51 650695A Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650714 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as require d) 53 33636 Resistor Spark Plug (RJ-8C) |
| 51 650711 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650628A Screw, 5/16-18 x 2-3/8" (Use as requi red) 51 650695A Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650714 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as require d) 53 33636 Resistor Spark Plug (RJ-8C) |
| 51 650628A Screw, 5/16-18 x 2-3/8" (Use as requi red) 51 650695A Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650714 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as require d) 53 33636 Resistor Spark Plug (RJ-8C) |
| 51 650695A Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650714 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as require d) 53 33636 Resistor Spark Plug (RJ-8C) |
| 51 650714 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as requi red) 53 33636 Resistor Spark Plug (RJ-8C) |
| 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as require d) 53 33636 Resistor Spark Plug (RJ-8C) |
| 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as require d) 53 33636 Resistor Spark Plug (RJ-8C) |
| 51 650692 Screw, 5/16-18 x 1-3/4" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as require d) 53 33636 Resistor Spark Plug (RJ-8C) |
| 51 650603 Screw, 5/16-18 x 5/8" (Use as require d) 53 33636 Resistor Spark Plug (RJ-8C) |
| 53 33636 Resistor Spark Plug (RJ-8C) |
| |
| 53 34251 Resistor Spark Plug (RJ-17LM) |
| 54 33035 Cover, Cylinder head |
| 55 28537 Washer, Plain |
| 57 650691 Washer, Flat (Use as required) |
| 58 650690 Washer, Belleville (Use as required) |
| 58 8274 Washer, Lock (Use as required) |
| 59 650128 Screw, 10-24 x 1/2" |
| 60 31976 Extension, Blower housing |
| 63 410144B Fuel Cap (White Plastic)(Std.)(As req uired) |
| 63 34210 Fuel Cap (Red Plastic) (Spurt resistant, High profile) (Use as |
| required) |
| |
| 67 650517 Screw, 1/4-20 x 27/32" (Use as requir ed) |
| 67 650561 Screw, 1/4-20 x 5/8" (Use as required) |
| 67 30063 Screw, 1/4-20 x 1/2" (Use as required) |
| 67 792028 Screw, 5/16-18 x 7/8" (Use as require d) |
| 71 26460 Clamp, Fuel line (Use as required) |
| 72 29774 Fuel Line (Braided) (8.25") (Use as r equired) |
| 72 30705 Fuel Line (Braided) (16") (Use as req uired) |
| 72 30962 Fuel Line (Braided) (32") (Use as req uired) |
| 72 30965 Fuel Line (Braided) (48") (Use as req uired) |
| 73 32579 Baffle, Blower housing |
| 74 650561 Screw, 1/4-20 x 5/8" |
| 78 31932 Bearing, Tapered roller |
| 79 31928 Cup, Bearing |
| 80 32031 Spacer, Steel (.010" thick) NOTE: Determine the gap |
| between the cover and the machined surface on the cylinder |
| which can be from .001"up to .007" in which case no shim |
| gaskets will be required. Use of gasket must be limited to a |
| combined total of .010" thick. Steel spacersmust be used |
| as required |

| Pof # | Part Number Qty | Description |
|---|--|--|
| | 31971 Qty | * Gasket, Shim (.004/.005 thick) NOTE: Determine the gap between the cover and the machined surface on the cylinder which can be from .001"up to .007" in which case no shim gaskets will be required. Use of gasket must be limited to a combined total of .010" thick. Steel spacersmust be used as req |
| 82 | 31972 | * Gasket, Shim (.005/.007 thick) NOTE: Determine the gap between the cover and the machined surface on the cylinder which can be from .001"up to .007" in which case no shim gaskets will be required. Use of gasket must be limited to a combined total of .010" thick. Steel spacersmust be used as req |
| | 32599 32577 | "O" Ring Cover, Cylinder NOTE: Determine the gap between the cover and the machined surface on the cylinder which can be from .001"up to .007" in which case no shim gaskets will be required. Use of gasket must be limited to a combined total of .010" thick. Steel spacersmust be used as required to eliminat |
| 84 85 86 87 91 92 95 96 98 99 100 101 102 103 104 105 106 107 108 109 112 113 114 115 120 121 122E 123 125A 126 128 | 792028 650666 650594 33044A 8274 650595 8274 650624 31958 31957 35350 650128 28558 31966 31984A 650597 650591 33099 32042 34238 33038 29752 650587 27272 650399 30767 32377 31925 31926 650513 650713 650429 | Lockwasher, 5/16" (Use as required) Screw, 5/16-18 x 7/8" Washer, Lock Nut, Flywheel, 3/4-16 Blower Hsg. (Incl.73) (For electric s tarter) Washer, Lock Screw, 5/16-24 x 3/8" Washer, Lock Screw, 5/16-24 x 9/16" * Gasket, Breather Breather Assy. Tube, Breather Screw, 10-24 x 1/2" Washer, Wave Bushing, Control lever Lever, Control Screw, 10-24 x 5/8" Screw, 10-24 x 2" Spring Nipple, Exhaust pipe Muffler Plug, Button (Use as required) Nut & Lockwasher Assy. Stud, Carburetor * Gasket, Air cleaner Screw, 10-32 x 5/8" Spacer, Air cleaner Bracket, Air cleaner Cover, Air cleaner Nut, Wing Screw, 5/16-18 x 5/8" (Use as require d) Screw, 5/16-18 x 3/4" (Use as require d) |
| 141A 141 | 792028 8274 26073 31960 | Screw, 5/16-18 x 7/8" (Use as require d) Lockwasher, Split (Use as required) Washer, Flat (Use as required) * Gasket, Carburetor |

www.mymowerparts.com

For Discount Tecumseh Engine Parts Call 606-678-9623 or 606-561-4983 $_{\rm Page\ 5\ of\ 9}$ Engine Parts List #1


| Ref # | Part Number | Qty | Description |
|-------|-------------|-----|--|
| 147 | 31959 | | Baffle, Air |
| 151 | 33356 | | Terminal, Ground |
| 156 | 730201 | | Trigger Pin Kit (Use as required) |
| 173 | 610118 | | Cover, Spark plug (Use as required) |
| 176 | 32426 | | Spacer, Screen |
| 177 | 650675 | | Washer, Flat 1/4" |
| 177 | 8345 | | Washer, 1/4 plain (Use as required) |
| 178 | 27070 | | Washer, Lock 1/4 E.T. (Use as require d) |
| 178 | 650675 | | Washer, Flat 1/4 (Use as required) |
| 184 | 27793 | | Clip, Conduit |
| 185 | 28942 | | Screw, 10-32 x 3/8" |
| 187 | 650713 | | Screw, 5/16-18 x 5/8" |
| 188 | 26073 | | Washer, Flat |
| 219 | 32154 | | Cap, Pipe |
| 220 | 32673 | | Nipple, Pipe |
| 246 | 33776 | | Screen, Starter pulley |
| 248 | 650670 | | Screw, 1/4-20 x 3/4" |
| 249 | 32046 | | Rope Assy., Starter (Use as required) |
| 264 | 650661 | | Screw, 1/4-20 x 3/4" |
| 265 | 610408 | | Nut, Hex |
| 266 | 610750 | | Grommet, Lead wire |
| 267 | 610748 | | Solid State Magneto (Incl.151,173,265 ,266) |
| 278 | 610746 | | Solid State Flywheel |
| 299A | 31752 | | Decal, Air cleaner |
| 299 | 34346 | | Decal, Instruction |
| 299B | 550223 | | Decal, Name |
| 299B | 34768 | | Decal, Name |
| 299B | 32676 | | Decal, Solid State |
| 300 | 32411A | | Valve, Seat, Spring & Gasket Assy. |
| 301 | 631304A | | Carburetor (Incl. 145) (Refer to Division 5, Section A, page 94 for breakdown) |
| 304 | 33237A | | * Gasket Set (Incl. items marked *) |



www.mymowerparts.com

For Discount Tecumseh Engine Parts Call 606-678-9623 or 606-561-4983 $\,$ Page 7 of 9 Engine Parts List #2

| Ref # | Part Number Q | ty Description |
|-------|---------------|---|
| 178 | 27070 | Washer, Lock 1/4 E.T. (Use as require d) |
| 178 | 650675 | Washer, Flat 1/4 (Use as required) |
| 180 | 650701 | Screw, 8-18 x 7/16" (Use as required) |
| 222 | 792028 | Screw, 5/16-18 x 7/8" (Use w/32817 st r.motor) |
| | 650781 | Screw,5/16-18 x 11/16"(Use w/33835 st r.motor) |
| 235 | 34276 | Plate, Cover (Use as required to cover regulator mounting hole in blower housing) |
| 236 | 650736 | Screw, 10-16 x 3/8" (Use as required) |
| 252 | 730134 | Rewind Starter Kit (lncl. 165, 166, 167, 168, 169 & 291) (Use as required) |
| 253 | 33018 | Harness Assy., Adapter (Use as requir ed) |
| 254 | 610761 | Alternator Coil (Solid State) (10 Amp) (Incl. Nos. 253, 256 & 257A) |
| 255 | 650416 | Screw, 10-32 x 1" |
| | 610922 | Terminal, Female |
| 257B | 610824 | Flat Connector (Female terminals) (As req.) |
| 257A | 610819 | Connector, Pyramid (For female termin als) |
| | 610750 | Grommet, Lead wire |
| | 610749 | Solid State Regulator (10 Amp) |
| | 730198 | Starter Switch Kit(Incl. 287-298) (As req.) |
| 303 | 33835 | Electric Starter Motor (12 Volt) NOTE: The 32817 and 33835 |
| | | starter motors are used interchangeably on the se models. |
| | | Refer to service numberstamped on end cap of motor, or on |
| | | decal for identification. Refer to Division 5, Section D for |
| | | breakdown. |



www.mymowerparts.com

For Discount Tecumseh Engine Parts Call 606-678-9623 or 606-561-4983 $\,$ Page 9 of 9 Engine Parts List #3

| Ref # Part Number | Qty Description |
|-------------------|--|
| 41 31967 | Spring, Governor |
| 70G 32961 | Valve, Fuel shut-off |
| 71 26460 | Clamp, Fuel line (Use as required) |
| 72 29774 | Fuel Line (Braided) (8.25") (Use as r equired) |
| 72 30705 | Fuel Line (Braided) (16") (Use as req uired) |
| 72 30962 | Fuel Line (Braided) (32") (Use as req uired) |
| 72 30965 | Fuel Line (Braided) (48") (Use as req uired) |
| 111 650590 | Nut, Conduit |
| 119 28534 | Pipe Plug, 1/8-27 (Use as required) |
| 119 9556 | Plug, Pipe, 1/8-27 (Use as required) |
| 122 32919 | Bracket, Air cleaner |
| 160 32920 | Elbow, Air cleaner |
| 161 650416 | Screw, 10-32 x 1" (two required) |
| 162 650583 | Washer, Plain |
| 163 28788 | Screw, 8-32 x 1/2" |
| 172 31990 | Bracket, Choke control |
| 184 27793 | Clip, Conduit |
| 185 28942 | Screw, 10-32 x 3/8" |
| 237 32958 | Fitting, Fuel |
| 238 32959 | Fuel Pump, Impulse |
| 239 33010 | Repair Kit, Impulse fuel pump |
| 285 32960 | Washer, Lock |
| 286 650849 | Nut, Hex jam, 3/8-24 |