

Engine Parts List

Ref #	Part Number	Qty	Description
	1 250296		Cylinder & Cover Assy. (Incl. 105, 10 6 & 138)
16A	490304		Governor Lever
16	490317		Governor Lever
19	490320		Governor Spring
19A	490318		Backlash Spring
20	510340		Oil Seal (Flywheel end)
21	570673		Ball
22	510338		Slide Ring
23	530158		Ball Bearing (PTO end)
24	530161		Ball Bearing (Magneto end)
27	530159		Bearing Retainer
28	510339		Oil Seal (PTO end)
29	530164		Bearing Strip (31 needles)
30	290627		Crankshaft
35	29826		Screw, 10-32 x 3/4
37	29216		Square Nut
39	310277B		Piston & Rod Assy. (Incl. 29 & 42)
42	310278		Ring Set
64	650893		Muffler Screw, 5/16-18 x 3-13/64
75	510337		Oil Seal
80	490305		Governor Shaft
89	611107		Flywheel Key
90	611144		Flywheel
92	650815		Belleville Washer
93	650816		Flywheel Nut
100	34443A		Solid State Assy.
101	610118		Spark Plug Cover
103	650814		Screw, T-15, 10-24 x 1
105	650892		Screw, 5/16-18 x 2-3/16
106	650891		Screw, 5/16-18 x 1-5/8
135	611049		Spark Plug (RCJ8Y)
138	570683		Port Cover
163	650961		Screw, 4-40 x 1/4
177	650959		Screw, 1/4-20 x 1
184	510326A		Carburetor Gasket
186	490319		Governor Link
187	570438A		Carburetor Spacer
217	570667A		Speed Control Lever
218	650847		Screw, 8-32 x 1/2
239	35815		Filter Base Gasket
260	350439		Blower Housing
261	650894		Screw, 5/16-18 x 5/8
269	510343A		Muffler Gasket
275	390319		Muffler
285	34449		Starter Hub
287	650884		Screw, 8-32 x 1/2
325	29443		Spring Clip
330	611158		Wire Harness
332	570695		Carburetor Baffle
333	650229		Screw, T-25, 10-32 x 3/8
350	570629A		Primer Assy. (w/hole in bulb)
351	32180C		Primer Line
370	35977		Caution Decal
380	632565		Carburetor (Incl. 184) (Refer to Division 5, Section A, page A1-40 or Fiche 27A, Grid F-5 for breakdown)
390	590652		Rewind Starter (Refer to Division 5, Section C, page 34 or Fiche 27A, Grid G-10for breakdown)

Ref #	Part Number	Qty	Description
399	510334		Gasket Eliminator
422	730227A		2-Cycle Oil (8 oz.)