



| Ref # | Part Number | Qty | Description                              |
|-------|-------------|-----|--|
|       | 1 37120B    | 1   | Cylinder (Incl. 2, 20 & 72)              |
|       | 2 26727     | 2   | Dowel Pin                                |
|       | 14 651052   | 1   | Washer                                   |
|       | 15 37158    | 1   | Governor Rod                             |
|       | 16 37162    | 1   | Governor Lever                           |
|       | 30 37569    | 1   | Crankshaft                               |
|       | 35 651053   | 1   | Screw, Torx T-25, 10-32 x 63/64"         |
|       | 37 29216    | 1   | Lock Nut, 10-32                          |
|       | 38 37109    | 1   | Retaining Ring                           |
|       | 40 40004    | 1   | Piston, Pin & Ring Set (Std.)            |
|       | 40 40005    | 1   | Piston, Pin & Ring Set (.010" OS)        |
|       | 41 36070    | 1   | Piston & Pin Ass'y (Std.) (Incl. 43)     |
|       | 41 36071    | 1   | Piston & Pin Ass'y (.010" OS) (Incl. 43) |
|       | 42 40006    | 1   | Ring Set (Std.)                          |
|       | 42 40007    | 1   | Ring Set (.010" OS)                      |
|       | 43 20381    | 2   | Piston Pin Retaining Ring                |
|       | 45 32875A   | 1   | Connecting Rod Ass'y (Incl. 46 & 49)     |
|       | 46 32610A   | 2   | Connecting Rod Bolt                      |
|       | 48 35616    | 2   | Valve Lifter                             |
|       | 49 36611    | 1   | Oil Dipper                               |
|       | 50 37040    | 1   | Camshaft (Incl. 253 & 254)               |
|       | 64 651015   | 1   | Screw, 1/4-20 x 1-1/8"                   |
|       | 69 36624    | 1   | Cylinder Cover Gasket                    |
|       | 70 37795    | 1   | Cylinder Cover (Incl. 75 thru 83)        |
|       | 72 27642    | 2   | Oil Drain Plug                           |
|       | 75 36742    | 1   | Oil Seal                                 |
|       | 80 37160    | 1   | Governor Shaft                           |
|       | 81 30590A   | 1   | Washer                                   |
|       | 82 37161    | 1   | Governor Gear Ass'y (Incl. 81)           |
|       | 83 35322    | 1   | Governor Spool                           |
|       | 86 650488   | 8   | Screw, 1/4-20 x 1-1/4"                   |
|       | 89 610961   | 1   | Flywheel Key                             |
|       | 111 611207  | 1   | Low Oil Sensor (Incl. 112)               |
|       | 112 35967   | 1   | Low Oil Sensor Gasket                    |
|       | 113 650950  | 4   | Screw, Torx T-25, 10-24 x 5/8"           |
|       | 119 36719   | 1   | * Cylinder Head Gasket                   |
|       | 120 36721   | 1   | Cylinder Head                            |
|       | 125 36471   | 1   | Exhaust Valve (Std.) (Incl. 151)         |
|       | 125 36472   | 1   | Exhaust Valve (1/32" OS) (Incl. 151)     |
|       | 126 37711   | 1   | Intake Valve (Std.) (Incl. 151)          |
|       | 130A 650999 | 1   | Screw, 5/16-18 x 2-41/64"                |
|       | 130 650912  | 4   | Screw, 5/16-18 x 1-1/2"                  |
|       | 135 34645   | 1   | Resistor Spark Plug (RN4C)               |
|       | 150 37039   | 2   | Valve Spring                             |
|       | 151 31673   | 2   | Valve Spring Cap                         |
|       | 151A 40016A | 1   | Intake Valve Seal                        |
|       | 153 36649   | 1   | Push Rod Guide                           |
|       | 154 650913  | 2   | Rocker Arm Stud                          |
|       | 155 35624A  | 2   | Rocker Arm                               |
|       | 157 650914  | 2   | Nut, 1/4-28                              |
|       | 158 36629   | 2   | Push Rod                                 |
|       | 159 35626   | 1   | * Rocker Arm Cover Gasket                |
|       | 160 36630A  | 1   | Rocker Arm Cover                         |
|       | 161 651008  | 2   | Screw, 1/4-20 x 31/64"                   |
|       | 161A 651012 | 2   | Stud                                     |
|       | 173 36675A  | 1   | Breather Tube                            |
|       | 178 650852  | 2   | Nut, 1/4-20                              |
|       | 182 650451  | 2   | Screw, 1/4-20 x 1"                       |

## Engine Parts List #1

| Ref # | Part Number | Qty | Description                        |
|-------|-------------|-----|------------------------------------|
| 184   | 26756       | 1   | * Carburetor To Intake Pipe Gasket |
| 185   | 36631       | 1   | Intake Pipe                        |
| 207   | 36632       | 1   | Throttle Link                      |
| 223   | 650451      | 2   | Screw, 1/4-20 x 1"                 |
| 224   | 36581       | 1   | * Intake Pipe Gasket               |
| 238   | 28820       | 2   | Screw, 10-32 x 1/2"                |
| 239   | 27272A      | 1   | * Air Cleaner Gasket               |
| 240   | 36633A      | 1   | Air Cleaner Body (Incl. 239)       |
| 245   | 36046       | 1   | Air Cleaner Filter                 |
| 250   | 37073       | 1   | Air Cleaner Cover                  |
| 250A  | 37074       | 1   | Air Cleaner Baffle                 |
| 251   | 650886      | 1   | Wing Nut                           |
| 252   | 650821      | 1   | Screw, 10-32 x 1/2"                |
| 253   | 36701       | 1   | Compression Release Weight         |
| 254   | 36702       | 1   | Compression Release Spring         |
| 275   | 36722       | 1   | Muffler                            |
| 277   | 650988      | 2   | Screw, 1/4-20 x 2-9/32"            |
| 278   | 36674       | 1   | Spacer                             |
| 279   | 650852      | 1   | Nut & Lock Washer                  |
| 280   | 36893       | 1   | Heat Shield                        |
| 305   | 36877       | 1   | Oil Fill Tube                      |
| 307   | 35499       | 1   | "O" Ring                           |
| 308   | 37079       | 1   | Fill Tube Clip                     |
| 310A  | 36678       | 1   | Dipstick                           |
| 380   | 640135      | 1   | Carburetor (Incl. 184)             |
| 416   | 36085       | 1   | Spark Arrestor Kit (Incl. 417)     |
| 417   | 650983      | 1   | Screw, 8-32 x 17/32"               |
| 600   | 651013      | 1   | Washer                             |



| Ref # | Part Number | Qty | Description  |
|-------|-------------|-----|--|
| 19    | 37163       | 1   | Extension Spring   |
| 20    | 32600       | 1   | Oil Seal   |
| 25A   | 36622       | 1   | Air Baffle (Right)   |
| 25    | 36621       | 1   | Air Baffle (Left)  |
| 26    | 30200       | 1   | Screw, 10-24 x 9/16"   |
| 60    | 36623A      | 1   | Blower Housing Extension   |
| 65    | 30200       | 1   | Screw, 10-24 x 9/16"   |
| 90    | 611205      | 1   | Flywheel   |
| 92    | 650815      | 1   | Belleville Washer  |
| 93    | 650816      | 1   | Flywheel Nut   |
| 94    | 651016      | 1   | Lock Nut, 10-32  |
| 96    | 30845A      | 1   | RPM Adjusting Bolt   |
| 100   | 34443B      | 1   | Solid State Ignition   |
| 101   | 610118      | 1   | Spark Plug Cover   |
| 103   | 651007      | 2   | Screw, Torx T-15, 10-24 x 15/16"   |
| 103A  | 650767      | 1   | Screw, 8-32 x 27/64"   |
| 110   | 35589       | 1   | Ground Wire  |
| 110A  | 36964       | 1   | Ground Wire  |
| 111A  | 611224      | 1   | Rocker On/Off Switch   |
| 151A  | 40016A      | 1   | Intake Valve Seal  |
| 200   | 37123       | 1   | Control Bracket  |
| 209   | 650821      | 2   | Screw, 10-32 x 1/2"  |
| 260   | 36864       | 1   | Blower Housing   |
| 261   | 651008      | 1   | Screw, 1/4-20 x 31/64"   |
| 261A  | 650821      | 2   | Screw, 10-32 x 1/2"  |
| 262   | 651008      | 2   | Screw, 1/4-20 x 31/64"   |
| 285   | 35985B      | 1   | Starter Cup  |
| 287   | 0           | 4   | Rivet (Can be purchased locally)   |
| 290   | 30705       | 1   | Fuel Line  |
| 292   | 26460       | 2   | Fuel Line Clamp  |
| 298   | 650665      | 2   | Screw, 1/4-15 x 3/4"   |
| 300   | 36863       | 1   | Fuel Tank (Incl. 292 & 301)  |
| 301   | 36754       | 1   | Fuel Cap (Black)   |
| 313   | 34080       | 1   | Spacer   |
| 325   | 37471       | 1   | Fuel Line Bracket  |
| 340   | 37071       | 1   | Fuel Tank Bracket  |
| 341   | 36644       | 1   | Fuel Tank Bracket  |
| 342A  | 650738      | 1   | Screw, 1/4-20 x 5/8"   |
| 342   | 651010      | 2   | Screw, 1/4-20 x 7/8"   |
| 370L  | 36771       | 1   | Oil Sensor Decal   |
| 370K  | 36695       | 1   | Decal 6.0 HP   |
| 370A  | 36261       | 1   | Identification Decal   |
| 390   | 590736      | 1   | Rewind Starter (NOTE: This engine could have been built with 590748 starter.)                                    |
| 400   | 36720       | 1   | * Gasket Set (Incl. items marked PK in notes) Incl. (1) each of 26756, 27272A, 29673, 35626, 36581, 36624, 36719 |