








Ref #	Part Number	Qty	Description
	1 35677A	1	Cylinder (Incl. 2, 20, & 80)
	2 27652	2	Dowel Pin
	3 650820	2	Screw, 1/4-20 x 1/2"
	4 34171	1	Oil Drain Extension
	5 30969	1	Extension Cap
14A	28558	1	Washer
14	28277	1	Washer
15	35685	1	Governor Rod (Incl. 14 & 38)
16	35686	1	Governor Lever
17	35687	1	Governor Lever Clamp
18	650548	1	Screw, 8-32 x 5/16"
19	35688	1	Extension Spring
20	35319	1	Oil Seal
25	35326	1	Blower Housing Baffle
26	650561	2	Screw, 1/4-20 x 5/8"
30	35680A	1	Crankshaft
31	35327	1	Counterbalance Gear
35	29826	1	Screw, 10-32 x 3/4"
36	29918	1	Lock Washer
37	29216	1	Lock Nut, 10-32
38	29642	3	Retaining Ring
40	35776	1	Piston, Pin & Ring Set (Std.)
40	35777	1	Piston, Pin & Ring Set (.010" OS)
40	35778	1	Piston, Pin & Ring Set (.020" OS)
41	35773	1	Piston & Pin Ass'y. (Std.) (Incl. 43)
41	35774	1	Piston & Pin Ass'y. (.010" OS) (Incl. 43)
41	35775	1	Piston & Pin Ass'y. (.020" OS) (Incl. 43)
42	35779	1	Ring Set (Std.)
42	35780	1	Ring Set (.010" OS)
42	35781	1	Ring Set (.020" OS)
43	35772	2	Piston Pin Retaining Ring
45	35681	1	Connecting Rod Ass'y. (Incl. 46 & 47)
46	650908	1	Connecting Rod Bolt
47	650882	1	Connecting Rod Bolt
48	35313	2	Valve Lifter
50	35682A	1	Camshaft (MCR)
51	35315A	1	Counterbalance Weight
60	35316	1	Blower Housing Extension
61	34126	1	Grommet Mounting Bracket
62	650760	1	Screw, 8-32 x 3/8"
63	28545	1	Grommet
64	30063	1	Screw, Torx T-30, 1/4-20 x 1/2"
65	650128	1	Screw, 10-24 x 1/2"
66	650561	1	Screw, 1/4-20 x 5/8"
69	35683	1	* Cylinder Cover Gasket
70	35684A	1	Cylinder Cover (Incl. 14,15,38,71,75)
71	35377	1	Crankshaft Bushing
75	35319	1	Oil Seal
80	35751	1	Governor Shaft
81	35479	2	Washer
82	35321	1	Governor Gear Ass'y.
83	35322	1	Governor Spool
84	29193	1	Retaining Ring
86	650833	7	Screw, 1/4-20 x 1-3/16"
87	650832	1	Screw, 1/4-20 x 1-11/16"
89	32589	1	Flywheel Key
90	611093	1	Flywheel (W/Ring Gear)
92	650880	1	Lock Washer

Ref #	Part Number	Qty	Description
93	650881	1	Flywheel Nut
100	35135	1	Solid State Ignition
101	610118	1	Spark Plug Cover
102	650872	2	Solid State Mounting Stud
103	650814	2	Screw, Torx T-15, 10-24 x 1"
119	35306A	1	* Cylinder Head Gasket
120	35307	1	Cylinder Head
121	730218	2	Valve Guide Kit (Incl. 2 of 122)
122	792035	2	Retaining Ring
125	35308	1	Exhaust Valve (Std.)
125	35433	1	Exhaust Valve (1/32" OS)
126	35309	1	Intake Valve (Std.)
126	35432	1	Intake Valve (1/32" OS)
127	650691	6	Washer
128	650690	6	Belleville Washer
130A	650746	2	Screw, 5/16-18 x 1-3/8"
130	650692	4	Screw, 5/16-18 x 1-3/4"
135	34046	1	Resistor Spark Plug (RL86C)
141	33481	4	* "O" Ring (Also Incl. in 401)
142	35475	2	Push Rod Tube
143	35310	1	Rocker Arm Housing
144	33484	1	* "O" Ring (Also Incl. in 401)
145	650168	1	Washer
146	32610A	1	Screw, 1/4-20 x 29/32"
147	33509	1	* "O" Ring (Also Incl. in 401)
148	34410	1	* "O" Ring (Also Incl. in 401)
149	33510	2	Valve Spring Cap
150	33507	2	Valve Spring
151	33508	2	Valve Spring Keeper
152	35295	2	* "O" Ring (Also Incl. in 401)
153	35296	1	Push Rod Guide
154	650878	2	Rocker Arm Stud
155	35297	2	Rocker Arm
156	35298	2	Rocker Arm Bearing
157	28264	2	* Lock Nut (Incl. 162) (Also Incl. in 4 01)
158	35466	2	Push Rod
159	35299B	1	* "O" Ring (Incl. 2 of 161) (Also Incl. in 401)
160	35300	1	Rocker Arm Housing
161	650879	2	Screw, Torx T-20, 8-32 x 1/2"
162	650903	2	Jam Nut
169	27896A	2	* Valve Cover Gasket
170	28423	1	Breather Body
171	28424	1	Breather Element
172	28425	1	Valve Cover
173	35350	1	Breather Tube
174	650128	2	Screw, 10-24 x 1/2"
179	30593	1	Retaining Clip
180	35301	1	Blower Housing Extension
181	650128	1	Screw, 10-24 x 1/2"
182	650517	2	Screw, 1/4-20 x 27/32"
183	34583	1	Choke Bracket
184	33263	1	* Carburetor To Intake Pipe Gasket
185	35690	1	Intake Pipe
186	35691	1	Governor Link
200	35702	1	Control Bracket (Incl. 203 & 204)
202	33802	1	Compression Spring
203	31342	1	Compression Spring
204	650549	1	Screw, 5-40 x 7/16"

Ref #	Part Number	Qty	Description
205	650777	1	Screw, 6-32 x 21/32"
207	35692	1	Throttle Link
209	650821	2	Screw, 10-32 x 1/2"
212	30773A	1	Bushing
213	650930	1	Screw, 10-32 x 5/8"
215	35438	1	Control Knob
216	35679	1	R.P.M. Adjusting Lever
219	35689	1	Choke Rod
220	35440	1	Choke Knob
222	28820	2	Screw, 10-32 x 1/2"
223	650971	2	Screw, Torx T-30, 5/16-18 x 7/8"
224	33515A	1	* Intake Pipe Gasket
260	35694	1	Blower Housing
261	30063	1	Screw, Torx T-30, 1/4-20 x 1/2"
262	29747B	2	Screw, Torx T-40, 5/16-24 x 21/32"
265	35290	1	Cylinder Head Cover
266	650876	2	Screw, 5/16-18 x 1-1/4"
269	35762	2	* Exhaust Manifold Gasket
270	35292	1	Exhaust Manifold
271	35293	1	Locking Plate
275	35294	1	Muffler
276	35348	1	Locking Plate
277	650877	2	Screw, 5/16-18 x 4-1/2"
281	33013	1	Starter Bubble Cover
282	650760	1	Screw, 8-32 x 3/8"
285	35985	1	Starter Cup
287	29752	4	Nut & Lock Washer, 1/4-28
290	30962	1	Fuel Line
291	29774	1	Fuel Line
292	26460	4	Fuel Line Clamp
295	35857	1	Fuel Shut-Off Valve
298	650665	2	Screw, 1/4-15 x 3/4"
300	34156A	1	Fuel Tank (Incl. 292 & 301)
301	35355	1	Fuel Cap
305	35574	1	Oil Fill Tube
307	35499	1	"O" Ring
308	35539	1	Fill Tube Clip
310	35700	1	Dipstick
314	650873	2	Screw, 1/4-20 x 3/4"
321	611161	2	Diode
327	35392	1	Starter Plug
328	35062	2	Ignition Switch
329	610973	1	Terminal
334	650257	2	Screw, 8-32 x 5/16"
335	35698	1	Carburetor Cover
335A	35693	1	Carburetor Cover
336	650765	1	Screw, 10-32 x 1/2"
338	650821	2	Screw, 10-32 x 1/2"
340	35696	1	Fuel Tank Bracket
341	35697	1	Fuel Tank Bracket
342	792028	2	Screw, 5/16-18 x 7/8"
345	35699	1	Heat Baffle
350	570682	1	Primer Ass'y.
351	32180C	1	Primer Line
355	590574	1	Starter Handle
370A	34346	1	Instruction Decal
370B	36253	1	Control Decal
370C	34144	1	Primer Decal

Ref #	Part Number	Qty	Description
370D	34414	1	Warning Decal
370E	35703	1	Control Decal
370	34686	1	Name Decal
380	632536	1	Carburetor (Incl. 184)
390	590672	1	Rewind Starter
400	35331B	1	*Gasket Set (Incl. items marked PK in notes) Incl. part #'s 27272A (1),27896A (2),28264 (2),33263 (1),33481 (4),33484 (1),33509 (1),33515A (1), 33629 (2),34410 (1),34912 (1), 35295 (2),35299B (1),35306A (1), 35317 (1),35683 (1),35762 (2)
401	35332	1	"O" Ring Kit (Also incl. in 400) 28264 (2), 33481 (4), 33484 (1), 33509 (1), 34410 (1), 35295 (2), 35299B (1)
420	730226	1	SAE 5W30 4-Cycle Engine Oil (Quart)



Ref #	Part Number	Qty	Description
3	650820	2	Screw, 1/4-20 x 1/2"
62	650760	1	Screw, 8-32 x 3/8"
63	28545	1	Grommet
64	30063	1	Screw, Torx T-30, 1/4-20 x 1/2"
92	650880	1	Lock Washer
93	650881	1	Flywheel Nut
110	35234	1	Ground Wire
110A	35285	1	Ground Wire
182	650517	2	Screw, 1/4-20 x 27/32"
285	35985	1	Starter Cup
286	35446	1	Starter Screen
290	30962	1	Fuel Line
291	29774	1	Fuel Line
292	26460	4	Fuel Line Clamp
314	650873	2	Screw, 1/4-20 x 3/4"
315	611146	1	Alternator Coil (Incl.321,322,323) 2.5 Amp, 35 Watt
321	611161	2	Diode
322	611142	1	Connector Body
323	611118	1	Terminal
370E	35703	1	Control Decal
370D	34414	1	Warning Decal
380	632536	1	Carburetor (Incl. 184)
396	33329D	1	Electric Starter Motor Kit (120 Volt) (Opt.)