

ILLUSTRATION SHOWS TYPICAL PARTS ONLY. ORDER BY PART NUMBER. PARTS NOT LISTED ARE SUPPLIED BY OEM.

## VIEW 1 OF 2



## Engine Parts List #1

| Ref # | Part Number | Qty | Description                                   |
|-------|-------------|-----|-----------------------------------------------|
|       | 1 250288    | 1   | Cylinder (Incl. 67, 105, 106 & 138)           |
| 16A   | 490304      | 1   | Governor Lever                                |
| 16    | 490306      | 1   | Governor Lever                                |
| 19    | 490308      | 1   | Extension Spring                              |
| 19A   | 490307      | 1   | Throttle Link Spring                          |
| 20    | 510340      | 1   | Oil Seal                                      |
| 21    | 570673      | 3   | Ball Bearing                                  |
| 22    | 510338      | 1   | Slide Ring                                    |
| 23    | 530158      | 1   | Ball Bearing                                  |
| 24    | 530161      | 1   | Ball Bearing                                  |
| 27    | 530159      | 1   | Bearing Retainer                              |
| 29    | 530164      | 1   | Bearing Strip (31 Needles)                    |
| 30    | 290599A     | 1   | Crankshaft (Incl. 29)                         |
| 33    | 330179      | 1   | Adapter Plate                                 |
| 34    | 792067      | 3   | Screw, 5/16-18 x 1"                           |
| 35    | 29826       | 1   | Screw, 10-32 x 3/4"                           |
| 35A   | 650961      | 2   | Screw, 4-40 x 1/4"                            |
| 37    | 29216       | 1   | Lock Nut, 10-32                               |
| 39    | 310277B     | 1   | Piston & Rod Ass'y. (Incl. 29 & 42)           |
| 42    | 310278      | 1   | Ring Set                                      |
| 67    | 430233      | 1   | Fuel Filter                                   |
| 75A   | 510337      | 1   | Oil Seal                                      |
| 75    | 510339      | 1   | Oil Seal                                      |
| 80    | 490305      | 1   | Governor Shaft                                |
| 89    | 611107      | 1   | Flywheel Key                                  |
| 90    | 611144      | 1   | Flywheel                                      |
| 92    | 650815      | 1   | Belleville Washer                             |
| 93    | 650816      | 1   | Flywheel Nut                                  |
| 100   | 34443A      | 1   | Solid State Ignition                          |
| 101   | 610118      | 1   | Spark Plug Cover                              |
| 103   | 650814      | 2   | Screw, Torx T-15, 10-24 x 1"                  |
| 105   | 650892      | 2   | Screw, 5/16-18 x 2-3/16"                      |
| 106   | 650891      | 2   | Screw, 5/16-18 x 1-5/8"                       |
| 110   | 611106      | 1   | Ground Wire                                   |
| 135   | 35395       | 1   | Resistor Spark Plug (RJ19LM)                  |
| 138   | 570683      | 2   | Port Cover                                    |
| 164   | 510341      | 1   | "O" Ring                                      |
| 165   | 510342      | 1   | "O" Ring                                      |
| 182   | 792067      | 2   | Screw, 5/16-18 x 1"                           |
| 184A  | 27110       | 2   | Washer                                        |
| 185   | 570674      | 1   | Intake Pipe (Incl. 164 & 165)                 |
| 186   | 490309      | 1   | Governor Link                                 |
| 200   | 570675A     | 1   | Control Bracket (Incl. 202 thru 206)          |
| 202   | 32924       | 1   | Compression Spring                            |
| 203   | 31342       | 1   | Compression Spring                            |
| 204   | 650549      | 1   | Screw, 5-40 x 7/16"                           |
| 205   | 650606      | 1   | Screw, 10-32 x 1-1/8"                         |
| 206   | 610973      | 1   | Terminal                                      |
| 209   | 650735      | 1   | Screw, 10-24 x 3/8"                           |
| 209A  | 650867      | 2   | Screw, 10-24 x 1/2"                           |
| 210   | 27793       | 1   | Conduit Clip                                  |
| 211   | 650837      | 1   | Screw, 10-32 x 1/4"                           |
| 226   | 730575A     | 1   | Air Cleaner Kit (Incl. items marked # # sign) |
| 227   | 450249A     | 1   | ## A/C Elbow (Incl. items marked with # sign) |
| 228   | 650901      | 1   | # Stud, 1/4-20 x 4.89"                        |
| 229   | 650825      | 1   | ## Nut & Lock Washer, 1/4-20                  |
| 232   | xxxxxx      | 2   | # Pop Rivet (Can be purchased locally)        |
| 239A  | 34698A      | 1   | # Air Cleaner Gasket                          |

| Ref # | Part Number | Qty | Description                     |
|-------|-------------|-----|---------------------------------|
| 239   | 35815       | 1   | ## Air Cleaner Gasket           |
| 241   | 34699       | 1   | # Air Cleaner Collar            |
| 245A  | 34783       | 1   | ## Air Cleaner Filter           |
| 245   | 34782       | 1   | ## Air Cleaner Filter           |
| 250   | 34781       | 1   | ## Air Cleaner Cover            |
| 251   | 650513      | 1   | ## Wing Nut, 1/4-20             |
| 260   | 350430      | 1   | Blower Housing                  |
| 261   | 650894      | 4   | Screw, 5/16-18 x 5/8"           |
| 274   | 510343A     | 1   | Exhaust Gasket                  |
| 275   | 390316      | 1   | Muffler                         |
| 277   | 650893      | 2   | Screw, 5/16-18 x 3-13/64"       |
| 278   | 28537       | 1   | Spacer                          |
| 279   | 650837      | 3   | Screw, 10-32 x 1/4"             |
| 280   | 390307A     | 1   | Heat Shield                     |
| 283   | 390315      | 1   | E.G.R. Tube                     |
| 285   | 34449       | 1   | Starter Cup                     |
| 287   | 650884      | 4   | Screw, 8-32 x 1/2"              |
| 290   | 29774       | 1   | Fuel Line                       |
| 292   | 26460       | 2   | Fuel Line Clamp                 |
| 298   | 650895      | 3   | Screw, 10-32 x 5/8"             |
| 300   | 410258      | 1   | Fuel Tank                       |
| 301   | 410259A     | 1   | Fuel Cap                        |
| 327   | 35392       | 1   | Starter Plug                    |
| 344   | 450256      | 1   | # Air Cleaner Brace             |
| 344A  | 650894      | 1   | # Screw, 5/16-18 x 5/8"         |
| 370C  | 550234      | 1   | Bowl Nut Decal                  |
| 370A  | 35977       | 1   | Instruction Decal               |
| 370B  | 34704       | 1   | ## Instruction Decal            |
| 370   | 550230A     | 1   | Fuel Mix Decal                  |
| 380   | 632434      | 1   | Carburetor (Incl. 164)          |
| 390   | 590635      | 1   | Rewind Starter                  |
| 399   | 510334      | 1   | Gasket Eliminator (Loctite 515) |
| 420   | 730227A     | 1   | 2-Cycle Oil (8 oz.)             |



## Engine Parts List #2

| Ref # | Part Number | Qty | Description                          |
|-------|-------------|-----|--------------------------------------|
| 200   | 570675A     | 1   | Control Bracket (Incl. 202 thru 206) |
| 202   | 32924       | 1   | Compression Spring                   |
| 205   | 650606      | 1   | Screw, 10-32 x 1-1/8"                |
| 209A  | 650867      | 2   | Screw, 10-24 x 1/2"                  |
| 209   | 650735      | 1   | Screw, 10-24 x 3/8"                  |
| 238A  | 650940      | 2   | ## Screw, 10-32 x 3/4"               |
| 245A  | 34783       | 1   | ## Air Cleaner Filter                |
| 245   | 34782       | 1   | ## Air Cleaner Filter                |
| 287   | 650884      | 4   | Screw, 8-32 x 1/2"                   |
| 290   | 29774       | 1   | Fuel Line                            |
| 292   | 26460       | 2   | Fuel Line Clamp                      |
| 390   | 590635      | 1   | Rewind Starter                       |
| 416   | 390309      | 1   | Spark Arrestor Kit                   |