

No
Diagram
Available

Parts List
Only

Engine Parts List

Ref #	Part Number	Qty	Description
1	34172A		Cylinder Assy. (2-3/4" Bore)
2	27652		Pin, Dowel
3A	31462		Bushing, Crankshaft
3	31461		Bushing, Crankshaft
4	32630		Seal, Oil
5	32783		Valve, Intake (Standard)
5	32784		Valve, Intake (1/32" oversize)
6	27878A		Valve, Exhaust (Standard)
6	27880A		Valve, Exhaust (1/32" oversize)
7	27882		Cap, Upper valve spring
8	27881		Spring, Valve
8A	27881		Spring, Valve
9A	32581		Cap, Lower valve spring
9	32581		Cap, Lower valve spring
10	20810		Pin, Valve spring retaining
11	34916		Crankshaft Assy.
12	29783		Pin, Crankshaft gear
13	27884		Gear, Crankshaft
14	34517		Piston, Pin & Ring Assy. (Std.)
14	34518		Piston, Pin & Ring Assy. (.010 overs)
14	34519		Piston, Pin & Ring Assy. (.020 overs)
14A	32592B		Piston & Pin Assy. (Std.) (2-3/4")
14A	32593B		Piston & Pin Assy. (.010 oversize)
14A	32594B		Piston & Pin Assy. (.020 oversize)
15	32595		Ring Set, Piston (Std.) (2-3/4")
15	32596		Ring Set, Piston (.010 oversize)
15	32597		Ring Set, Piston (.020 oversize)
16	27888		Ring, Piston pin retaining
17	32591C		Rod Assy., Connecting
18	650662C		Screw, Connecting rod (Two pieces)
20	650625		Washer, Thrust
21	34034		Lifter, Valve
22	32114		Camshaft (Mech. Compression Release)
24	31471D		Flange, Mounting
25	31355		Screen, Oil strainer
26	30684		Gasket, Mounting flange
27	29117		Screw, Hex hd. shakeproof, 8-32 x 5/6
34	27897		Seal, Oil
35	650548		Screw, Hex washer hd., 8-32 x 5/16
36	31335		Clamp, Governor
37	27642		Plug, Drain (1/4-18 sq. hd.)
38	31356		Pump Assy., Oil
39	650488		Screw, Hex hd. Sems, 1/4-20 x 1-1/4
41	33013		Cover, Starter bubble
42	650760		Screw, Pan hd. taptite, 8-32 x 7/16
43	27275		Clip, Wire retaining
44	29443		Clip, Fuel line
47	32631		Gasket, Cylinder head
48	30938A		Head, Cylinder
49	30939A		Cover, Cylinder head
50	610118		Cover, Spark plug
51	650697A		Screw, Hex flange hd., 5/16-18 x 2-12
52	33636		Plug, Spark (Champion J-8C or equiva)
52	34251		Resistor Spark Plug
53	27896		Gasket, Breather
54	28423		Body, Breather
55	28424		Element, Breather
56	28425		Cover, Valve chamber

Engine Parts List

Ref #	Part Number	Qty	Description
57	27627		Tube, Breather
59	650128		Screw, Fil. hd., 10-24 x 1/2
60	27915		Gasket, Intake pipe
61	32632		Pipe, Intake
64	650378		Screw, Fil. hd. Sems, 5/16-18 x 1-1/8
65	26756		Gasket, Carburetor
66	29747B		Screw, Phil. Hex hd. Sems, 5/16-24 x2
67	32629B		Housing Assy., Blower (5.56 dia. star
69	32633		Stud, Intake pipe
69A	650372		Screw, Hex hd. Sems, 1/4-20 x 13/16
70	29752		Nut & Lockwasher, 1/4-28
71	33876		Gasket, Stator
76	27261		Washer, Flat
76	650168		Washer, Flat (1/4 Plain)
77	27656		Washer, Thrust
78	650690		Washer, Belleville
79	650691		Washer, Flat
84	27272		Gasket, Air cleaner
85	31691		Bracket, Air cleaner
86	28820		Screw, Fil. hd. Sems, 10-32 x 1/2
87	650152		Screw, Fil. hd. Sems, 8-32 x 3/8
88	30727		Element, Air cleaner (Paper)
89	730127		Cleaner Assy., Air (Poly)
89	730164		Cleaner Assy., Air (Paper)
90	31715		Body, Air cleaner
95	650489		Screw, Hex hd. Sems, 1/4-20 x 5/8 (S.
95	650516		Screw, Hex hd. Sems, 1/4-20 x 1-1/8 .
96	650561		Screw, Hex washer hd. Durlok, 1/4-208
97A	29536		Baffle, Blower housing (Without elecc
97A	35256A		Baffle, Blower housing (With electric
98	32589		Key, Flywheel
103	31361		Spring, Governor
104	32582		Link, Governor spring
105	30669		Rod, Governor
106	31357		Lever, Governor
107	28277		Washer, Flat
108	31823		Link, Throttle
109	31707A		Governor, Spacer Assy.
110	30668		Shaft, Mechanical governor
111	30591		Gear Assy., Governor
112	29193		Ring, Retaining
113	30588A		Spool, Governor
117	30622A		Extension, Blower housing
118	650128		Screw, Fil. hd. Sems, 10-24 x 1/2
119	30063		Screw, Hex hd. Sems, 1/4-20 x 1/2
119	30688		Screw, Hex hd. Sems, 1/4-20 x 1/2
120	29716		Screw, Pan hd. Sems, 1/4-28 x 7/16
121	30063		Screw, Hex washer hd., Sems, 1/4-20 2
121	30688		Screw, Hex hd. Sems, 1/4-20 x 1/2
124	26460		Clamp, Fuel line
125	29774		Line, Fuel (Braided 8.25")
125	30705		Line, Fuel (Braided 16")
125	30962		Line, Fuel (Braided 32")
126	32926		Tank Assy., Fuel (Charcoal Gray Poly2
127	33032		Cap, Fuel filler (Red Plastic) (Spurt
127	34118		Cap, Fuel filler (Red Plastic) (Spurt
127	34210		Cap, Fuel filler (Red Plastic) (Spurt
127	410144B		Cap, Fuel filler (White Plastic) (St)

Engine Parts List

Ref #	Part Number	Qty	Description
135	27930		Gasket, Exhaust
136F	391026		Muffler
139	8274		Lockwasher
153	31288		Kit, Muffler adapter
153A	730130		Kit, Muffler adapter
154	6021A		Screw, Hex flange hd., 5/16-18 x 1-12
155	650697A		Screw, Hex flange hd., 5/16-18 x 2-12
156	30196		Screw, Fil. hd., 5/16-18 x 3/4
158	34235		Wire, Ground (One female & one double
159	610973		Terminal Assy.
161	31342		Spring, Compression
162	650549		Screw, Fil. hd., 5-40 x 7/16
163	30200		Screw, Hex washer hd. self-tap, Sems4
164	32410		Knob, Speed control
165	27793		Clip, Conduit
166	28942		Screw, Hex hd. Sems, 10-32 x 3/8
167	32181A		Control Assy., Speed
168	33549		Clamp, Tank holddown
174	33598		"O" Ring
175	34178A		Dipstick, Oil (Twist Lock)
176B	35560		Tube, Oil filler (Plastic)
178	28749		Screw, Phil. rd. hd. w/neoprene wash,
179	28747		Gasket, Oil fill tube
209	33018		Harness Assy., Adapter
219	650815		Washer, Belleville
220	8116		Nut
221	32125		Cup, Starter
222	35009		Screen, Starter cup
236	34346		Decal, Instruction
237	30547A		Contact Assy., Breaker
238	30548B		Condenser
239	631021		Inlet Needle, Seat & Clip Assy.
240	631449		Carburetor
244	611043		Magneto, Tecumseh
245	590420		Starter, Rewind
247	32386		Starter Motor Kit (110-120 Volt)
247	32901		Starter Motor Kit (110-120 Volt)
247	33328		Starter Motor Kit (110-120 Volt)
247	33328A		Starter Motor Kit (110-120 Volt)
247	33328B		Starter Motor Kit (110-120 Volt)
247	33328C		Starter Motor Kit (110-120 Volt)
247	33518		Starter Motor Kit (110-120 Volt)
247	33518A		Starter Motor Kit (110-120 Volt)
247	33518B		Starter Motor Kit (110-120 Volt)
248	30811A		Flywheel (Std. Point) (V70 thru typer
248	611042		Flywheel (Std. Point) (V70 type lett)
248	611085		Flywheel (Solid state ignition)
249	33239		Gasket Set