


24A-657E766 6.5HP Leaf Blower (2006)
General Assembly

Page 1 of 4




24A-657E766 6.5HP Leaf Blower (2006)
General Assembly

Page 2 of 4

Ref #	Part Number	Qty	S/P/F	Description
1	749-0784	1	S	Upper Handle
2	726-0100	1	S	Push Nut 3/8
3	720-0171	1	S	Crank Knob
4	736-0117	1	S	Flat Washer.385 ID x.62 OD
6	710-0805	1	/P	Hex Bolt 5/16-18 x 1.50
7	16453	1		Engine Mounting Frame Assembly
8	736-0119	1	S	Lock Washer 5/16 ID
9	712-0267	1	S	Hex Nut 5/16-18
10	736-0187	1	/P	Flat Washer.63 ID x 1.25
11	714-0115	1	S	Cotter Pin
12	712-0206	1	S	Hex Nut 1/2-13
13	736-0921	1	S	Lock Washer 1/2
14	734-1036	1		Swivel Caster Wheel 5" Dia x 1.25
15	16273	1		Caster Arm Assembly
16	710-0726	1	/P	Hex Washer Screw 5/16x.75
17	14529	1		Caster Arm Bracket
18	747-0542	1		Height Adjustment Crank
19	736-0451	1	S	Saddle Washer.32 ID x.93 OD
20	736-0159	1	S	Flat Washer.34 ID x.87 OD
21	710-0170	1		Hex Lock Bolt 5/16-24 x.64
23	736-0300	1	S	Flat Washer.38 ID x.57 OD
24	750-0528	1	S	Spacer.382 ID x.50 OD x.180Lg
25	736-0169	1	S	Lock Washer 3/8 ID
26	712-0354	1	S	Hex Nut 3/8-8
27	710-0118	1	S	Hex Bolt 5/16-18 x.75
28	711-0797	1	S	Ferrule
29	720-04052	1	S	Hand Knob
30	710-1174	1	/P	Carriage Bolt 5/16-18 x 2.0
31	749-0785	1	/P	Lower Handle
32	734-1035	1		Wheel Assembly 12 x 3
33	738-0185	1		Rear Axle
34	710-0599	1	/P	Self Tap Screw 1/4-20 x.5 If Equipped
35	710-1502	1		Screw 8-18 x.375 If Equipped
36	712-3004A	1	/P	Hex Lock Nut 5/16-18 If Equipped
37	736-0329	1	S	Lock Washer If Equipped
38	751-0447	1		Deflector If Equipped
39	751-0632	1		Muffler Guard If Equipped
40	751-0646	1		Muffler Guard Bracket If Equipped
41	736-0162	1	/P	Flat Washer
42	712-3004A	1	/P	Hex Lock Nut 5/16-18

24A-657E766 6.5HP Leaf Blower (2006)
Impeller

Page 3 of 4



24A-657E766 6.5HP Leaf Blower (2006)
Impeller

Page 4 of 4

Ref #	Part Number	Qty	S/P/F	Description
1	14540B	1	S	Engine Housing Brace Assembly
2	710-0607	1	/P	Hex Self Tapping Screw 5/16 x .5
3	710-1260A	1	/P	Hex Bolt 5/16-18 x .75
4	736-0170	1	S	Special L-Washer 5/16" x.88 OD
5	14541	1	S	Right Angle Bracket
6	710-0672	1	/P	Hex Screw, 5/16-24 x 1.25
7	710-0260A	1	/P	Carriage Bolt 5/16-18 x .62
8	14479	1	/P	Directional Discharge Assembly
9	750-3198	1		Engine Spacer, 1.0 x.34Lg x.35
10	711-04221	1	S	Impeller Hub
11	736-0119	1	S	Lock Washer 5/16
12	712-3010	1	S	Hex Nut 5/16-18
13	731-0608	1		Blower Guard
14	711-0758	1	S	Hex Shoulder Nut .50"
15	14563A	1	/P	Nozzle Plate Assembly
16	710-1273	1		Hex Screw, 3/8-24 x 2.75
17	736-0217	1	S	Lock Washer 3/8
18	681-04015	1	S	Impeller Assembly
19	14496B	1		Blower Housing Assembly
20	714-0105	1	S	Square Key, 3/16 x 1.00
21	710-0259	1	/P	Hex Sems Bolt 5/16-18 x .62
22	736-0242	1	/P	Bell Washer .34 ID x .87 OD
23	710-3008	1	/P	Screw 5/16-18 x.75