


HS720r 41AJHS-B054
General Assembly

Page 1 of 2



HS720r 41AJHS-B054
General Assembly

Page 2 of 2

Ref #	Part Number	Qty	S/P/F	Description
1	791-181070	1		Screw
2	753-1220	1		Drive Shaft Housing Assembly
3	791-180869	1		Loop Handle Assembly
4	791-181840	1		Drive Shaft Assembly
5	753-1219	1		Housing Set
6	791-181629	1		Anti-Rotation Screw
7	791-181843	1		Nut
8	791-181844	1	/P	Housing Screw
9	791-181851	1		Insulator
10	791-181845	1		Pinion Gear
11	791-181846	1		Bevel Gear Assembly (includes items 12-14)
12	791-182169	1		Washer
13	791-181847	1		Cam Assembly (includes 14)
14	791-181848	1		Screw
15	791-181849	1		Bottom Plate
16	791-181827	1		Screw
17	791-181660	1		Cutting Blade Assembly
18	791-612605	1	/P	Hanger