


TB20DC 41ADT20C966
Boom and Trimmer

Page 1 of 5




TB20DC 41ADT20C966
Boom and Trimmer

Page 2 of 5

Ref #	Part Number	Qty	S/P/F	Description
1	753-04234	1		Throttle Housing Assembly (includes 2-4)
2	791-182405	1	/P	Switch
3	753-04119	1	/P	Throttle Trigger
4	791-182690	1		Throttle Trigger Spring
5	753-04405	1	S	Throttle Cable
6	753-04344	1	/P	Upper Drive Shaft Housing Assembly
7	791-180869	1		Deluxe D-Handle (includes 8 & 9)
8	753-05009	1		Deluxe D-Handle Base
9	791-181070	1		Screw
10	753-1190	1	/P	Split Boom Coupler (includes 11-14)
11	791-182057	1		Screw
12	791-181617	1		Bolt
13	791-181981	1		Adjustment Knob
14	753-04386	1	S	Knob Retaining Nut
15	753-04508	1		Lower Drive Shaft Housing Assembly
16	753-04282	1		Guard Mounting Hardware
17	753-04283	1		Guard Assembly (includes 18)
18	791-180553	1		Blade Assembly
19	753-04284	1		Outer Spool Assembly (includes 20)
20	791-610660	1		Retainer
21	791-610317B	1	/P	Spring
22	753-1155	1	/P	Inner Reel
23	791-153066B	1	/P	Bump Head Knob Assembly
	791-153577B	1	/P	Reel and Line Assembly (Optional Accessory) (not shown)

TB20DC 41ADT20C966
Engine

Page 3 of 5



TB20DC 41ADT20C966
Engine

Page 4 of 5

Ref #	Part Number	Qty	S/P/F	Description
1	753-04511	1	/P	Air Cleaner Cover Assembly (includes 2 & 39)
2	791-180350B	1	/P	Air Cleaner Filter
3	791-180351	1		Carburetor Mounting Screw Assembly
4	791-180226	1	S	Wavey Washer
5	791-182202	1	/P	Choke Knob w/Screw
6	753-04418	1	/P	Choke Lever (includes 5)
7	753-04419	1	/P	Choke Plate (includes 6)
8	753-05133	1		Carburetor Assembly (includes 9 & 20)
9	791-610675	1		Carburetor Gasket
10	791-181860	1		Carb Mount Screw
11	791-683974B	1	/P	Primer & Hose Assembly
12	753-1196	1	/P	Carb Mount Assembly (includes 10, 13 & 14)
13	791-684451	1		Reed Assembly
14	753-1208	1	/P	Carburetor Mount Gasket
15	753-04401	1		Crankcase Service Assembly (includes 10)
16	791-612134	1		Rear Mounting Pad
17	753-04307	1	/P	Fuel Tank Assembly (includes 18-20)
18	791-182529	1		Fuel Cap Assembly
19	791-181086	1	/P	Fuel Return Line
20	753-04233	1		Fuel Line Assembly
21	791-145308	1		Front Mounting Pad
22	753-04409	1	S	Shroud Extension & Stand (includes 39)
23	753-05240	1	/P	Flywheel Assembly
23	914-04016	1	/P	Woodruff Key.125 x .375 Not shown
24	791-181525	1		Spacer
25	753-04459	1	/P	Recoil Pulley Assembly (includes 28 & 30)
26	753-04286	1		Recoil Spring
27	753-1200	1		Rope Guide
28	753-04288	1	/P	Pulley Retainer
29	791-181079	1	S	Pull Handle
30	791-613103	1		Rope
31	753-04417	1	/P	Pressure Plate Assembly (includes 32)
32	753-1202	1		Plate Screw
33	753-04402	1		Starter Housing Assembly (includes 25-32, 34 & 39)
34	791-181862	1	/P	Housing Screw
35	791-182396	1	S	Clutch Washer
36	791-182369	1	S	Clutch Rotor Assembly Mfg date 09092007 and before
36	753-05722	1		Clutch Rotor Assembly Mfg date 09102007 and after
37	791-153592	1	/P	Clutch Drum Assembly Mfg date 09092007 and before
37	753-05723	1		Clutch Drum Assembly Mfg date 09102007 and after
38	753-04403	1		Clutch Cover Assembly (includes 39-42)
39	791-181345	1	/P	Cover Screw
40	791-182519	1		Anti-Rotation Screw
41	753-04003	1		Clamping Screw
42	791-180217	1	S	Clamping Nut
43	753-05025	1	/P	Wire Leads and Sleeve

TB20DC 41ADT20C966
Engine

Page 5 of 5

Ref #	Part Number	Qty	S/P/F	Description
44	791-611063	1	/P	Ground Tab
45	753-04336	1		Module Assembly
46	791-610311B	1	/P	Spark Plug
47	753-05169	1	/P	Muffler Assembly (includes 48, 49 & Spark Arrestor)
48	753-04619	1	/P	Exhaust Gasket
49	753-04620	1	S	Muffler Mounting Bolts
50	753-04323	1	S	Cylinder Assembly (includes 52 & 53)
51	753-04367	1	/P	Piston and Rod Assembly
52	753-04182	1		Cylinder Gasket
53	791-182723	1		Cylinder Bolt
	753-1209	1		Piston Ring Set Not Shown
	753-04812	1	/P	Short Block Assembly (includes 10, 15, 46 & 50-53) Not Shown