

TB4218CC 41AY28AR966
General Assembly Parts

Page 2 of 3

Ref #	Part Number	Qty	S/P/F	Description
1	MC-9238-MD0701	1		ENG ASSEMBLY
1-1	MC-9157-310502	1	/P	CAP, BEARING
1-2	MC-9DB-620101	1		BEARING
1-3	MC-9228-310505	1	/P	CRANK/ROD ASSEMBLY
1-4	MC-9290-310502	1	/P	PISTON
1-5	MC-9189-310502	1	/P	RING, PISTON
1-6	MC-9NB-K101410	1	/P	ROLLER, PISTON
1-7	MC-9PC-10-34.5	1	/P	PIN, PISTON
1-8	MC-9CA-10.3	1	/P	RING
1-9	MC-9072-310501F	1	/P	CASE, CRANK
1-10	MC-9295-310502	1		SPARK PLUG
1-11	MC-9292-310501F	1		CYLINDER
1-12	MC-9012-310502	1	/P	RUBBER, ISOLATOR
1-13	MC-9082-310505	1		SPACER
1-14	MC-9STDB-05-60	1	/P	SCREW
1-15	MC-9082-310504	1		ISOLATOR, CARBURETOR
1-16	MC-6WSB-06	1	/P	SPRING WASHER
1-17	MC-9SACB-06-25	1	/P	SCREW
1-18	MC-9082-310506	1		SPACER
1-19	MC-9287-310501	1	/P	CARBURETOR
1-20	MC-9228-310510	1		AIR FILTER ASS/Y
1-21	MC-9NHZ-05	1	/P	NUT
1-22	710-04290	1		SCREW
1-23	MC-9068-310501	1	/P	HANDLE, LEFT PART
1-24	MC-9028-310502	1	/P	TRIGGER, THROTTLE
1-25	MC-9028-310501	1		TRIGGER, RELEASE
1-26	MC-9024-310504	1		SPRING
1-27	9SKKBY10/14-0.68	1		SCREW
1-28	MC-9027-310101	1	/P	RUBBER
1-29	MC-9068-310502	1	/P	HANDLE, REAR
1-30	MC-9022-310501	1	/P	SWITCH
1-31	MC-9WFB-05-21	1	/P	WASHER
1-32	710-04494	1	/P	SCREW
1-33	MC-9068-MD0701	1	/P	HANDLE, FRONT
1-34	MC-9228-MD0701	1		STARTER HOUSING ASSEMBLY
1-35	MC-9NAB-5/16-24	1	/P	NUT
1-36	MC-9169-310501	1		FLYWHEEL
1-37	710-04232	1	/P	SCREW
1-38	MC-9010-310503	1	/P	WIRE ASSEMBLY
1-39	MC-9288-310501	1		IGNITION ASSEMBLY
1-40	MC-9051-310501	1	/P	CONDUCTIVE PLATE
1-41	MC-9228-310207	1	/P	OIL CAP ASSEMBLY
1-42	MC-9228-310514	1		SPRING ASSEMBLY
1-43	MC-9142-310002	1	/P	PRIMER
1-44	MC-9157-310501	1		FELT
1-45	MC-9024-310506	1	/P	SPRING
1-46	MC-9SFABJ06-55	1		SCREW
1-47	MC-6SDABB04-08	1	/P	SCREW
1-48	MC-9228-310511	1	/P	HOUSING ASSEMBLY
1-49	MC-9012-310503	1	/P	HOLDER, CABLE
1-50	MC-9114-310510	1		LEVER, CHOKE
1-51	MC-9012-310504	1		HOLDER, CHOKE LEVEL
1-52	MC-9024-310507	1		SPRING

TB4218CC 41AY28AR966
General Assembly Parts

Page 3 of 3

Ref #	Part Number	Qty	S/P/F	Description
1-53	MC-9124-310102	1		CONNECTOR
1-54	MC-9013-310501	1		OIL PIPE
1-55	MC-9228-310526	1		PUMP ASSEMBLY
1-56	MC-9073-310503	1	/P	WORM
1-57	MC-9082-310507	1	/P	SPACER
1-58	MC-9082-310502	1		BAFFLE
1-59	MC-9082-310501	1	/P	BAFFLE
1-60	MC-9228-310504	1	/P	MUFFLER ASSEMBLY
1-61	MC-9SXDB-06-70	1		SCREW
1-62	MC-9010-310502	1		CABLE, THROTTLE
1-63	MC-9129-310504	1	/P	FUEL PIPE
1-64	MC-9221-310001	1		WOODRUFF KEY
1-65	MC-9183-310502	1		MESH
1-66	MC-9252-310501	1	/P	FILTER, AIR
1-67	MC-9082-310508	1	/P	BAFFLE
1-68	710-04495	1	/P	SCREW
1-69	MC-9SKKBY8/16-1.4	1		SCREW
1-70	MC-9017-310509	1	/P	SHROUD
1-71	MC-9017-310508	1	/P	CAP, ANTI-DUST
1-72	710-04493	1	/P	SCREW
2	MC-9228-310515	1	/P	DRUM ASSEMBLY
3	MC-9228-310528	1	/P	CLUTCH ASSEMBLY
4	MC-9077-310501	1		CAP, ANTI-DUST
5	MC-9NHC-09	1	/P	NUT
6	MC-9228-MD0702	1	/P	BRAKE KIT ASSEMBLY
7	MC-9NAZ-5/16-18	1	/P	NUT
8	MC-9040-MD0702	1		BAR (TB4016CC)
8	MC-9040-MD0703	1		BAR (TB4218CC)
9	MC-6220-210816	1	/P	CHAIN (TB4016CC)
9	MC-6220-210805	1		CHAIN (TB4218CC)
10	710-04288	1		SCREW
11	MC-9228-310206	1	/P	FUEL CAP ASSEMBLY
12	MC-9182-310001	1	/P	FILTER
13	MC-9042-310201	1	/P	WRENCH
14	MC-9017-310214	1		SCABBARD
15	MC-9120-MD0701	1	/P	CARRY CASE