


TB425CS 41ADT42C063
Boom And Trimmer Parts

Page 1 of 5




TB425CS 41ADT42C063
Boom And Trimmer Parts

Page 2 of 5

Ref #	Part Number	Qty	S/P/F	Description
1	753-04234	1		Throttle Housing and Trigger Assembly (includes 2 & 3)
2	753-04119	1	/P	Throttle Trigger
3	791-182690	1		Throttle Trigger Spring
4	791-182405	1	/P	Switch Assembly
5	753-04297	1		Throttle Cable
6	791-180687	1		J-Handle Assembly
7	791-683295	1		Handle Bracket Assembly (includes 8-13)
8	791-181811	1		Screw
9	791-181812	1		Upper Handle Clamp
10	791-181813	1		Middle Handle Clamp
11	791-181814	1		Lower Handle Clamp
12	791-181815	1		Nut
13	791-145569	1	/P	Anti-Rotation Screw
14	791-610327	1		Harness Clip
15	753-1247	1	S	Upper Drive Shaft Housing Assembly
16	753-1190	1	/P	EZ-Link (TM) Coupler (includes 17-20)
17	791-182057	1		Screw
18	791-181617	1		Bolt
19	791-181981	1		Adjustment Knob
20	791-181886	1		Knob Retaining Nut
21	753-04304	1		Lower Drive Shaft Housing Assembly
22	791-181852	1	/P	Lower Flexible Drive Shaft
23	791-181560	1	S	Palnut
24	791-153597	1		Lower Clamp Assembly
25	791-145569	1	/P	Anti-Rotation Screw
26	791-180531	1	S	Shield Mounting Hardware
27	791-181659	1	/P	Shield and Blade Assembly (includes 28)
28	791-181823	1		Blade Assembly
29	791-181857	1		Bushing Housing Assembly
30	791-181457	1		Outer Spool Assembly (includes 31)
31	791-181458	1		Retaining Ring
32	791-181561	1		Thrust Washer
33	791-181459	1		Small Spring
34	791-181461	1	S	Slider
35	791-181532	1		E-Clip
36	791-181531	1		Spring
37	791-181462	1		Plunger
38	791-181463	1		C-Clip
39	791-181464	1	S	Inner Reel
40	791-181465	1		Large Spring
41	791-181467	1		Foam Seal
42	791-181468	1	S	Bump Head Knob Assembly (includes 40 & 41)
	791-180120	1	S	Replacement Line, 0.095 Diameter Optional Accessory; Not Shown
	753-04218	1		Reel and Line Assembly Optional Accessory; Not Shown
	791-682075	1	S	Shoulder Strap Assembly Optional Accessory; Not Shown

TB425CS 41ADT42C063
Engine Parts

Page 3 of 5



TB425CS 41ADT42C063
Engine Parts

Page 4 of 5

Ref #	Part Number	Qty	S/P/F	Description
1	753-04083	1		Engine Cover
2	791-182339	1	S	Engine Cover Screws
3	791-181025	1		Valve Cover Screw
4	791-182098	1		Valve Cover
5	791-182099	1	/P	Valve Cover Gasket
6	791-182340	1		Rocker Adjustment Nut
7	791-182101	1	/P	Rocker Arm Pivot
8	791-182100	1		Rocker Arm
9	791-182341	1		Rocker Arm Stud
10	791-182103	1		Valve Spring Retainer
11	791-181038	1		Valve Spring
12	791-182102	1		Push Rod Guide
13	791-181033	1		Push Rod
14	791-182745	1	S	Cylinder Assembly (includes 9 & 12)
15	791-182344	1	S	Cylinder Screw
16	791-182345	1		Intake Baffle
17	791-182749	1		Carburetor Mount Gasket
18	791-181034	1	S	Nut
19	791-182347	1		Carburetor Mount (includes 18)
20	791-182348	1		Carburetor Mount Screw
21	791-182732	1	/P	Carburetor Gasket
22	753-04296	1		Carburetor with Primer
23	791-181751	1		O-Ring, Carburetor
24	753-04305	1	/P	Air Filter/Choke Cover Assembly (includes 27)
25	791-182097	1		Breather Tube
26	791-181750	1		Air Filter Mounting Screw
27	791-181757	1		Air Filter
28	753-1229	1		Fuel Cap
29	791-182352	1		Fuel Return Line
30	791-182353	1		Fuel Pick-Up Line with Filter
32	791-181080	1		Screw
32	791-182354	1		Washer
33	753-1230	1		Fuel Tank Assembly (includes 28-30)
34	791-182356	1		Fuel Tank Shield
35	753-04297	1		Throttle Cable
36	791-182358	1		Muffler Baffle
37	791-181048	1		Muffler Gasket
38	791-182359	1	/P	Muffler (includes 37, 39-41)
39	791-180890	1		Spark Arrestor Screen
40	791-181045	1		Screen Cover
41	791-181046	1		Screw
42	791-182361	1		Muffler Mounting Screw
43	753-04092	1		Muffler Cover
44	791-182804	1		Switch Wire Assembly
45	791-181247	1	S	Palnut
46	753-1199	1		Recoil Pulley
47	753-04286	1		Recoil Spring
48	791-182366	1		Nut Clip
49	791-181079	1	S	Pull Handle
50	791-611061	1		Rope Guide
51	791-613103	1		Rope
52	791-181020	1		Starter Housing Screw

TB425CS 41ADT42C063
Engine Parts

Page 5 of 5

Ref #	Part Number	Qty	S/P/F	Description
53	753-1237	1	S	Starter Housing Assembly (includes 45-51)
54	791-182368	1	S	Clutch Washer
55	753-1238	1		Clutch with Spacer
56	791-153592	1	/P	Clutch Drum
57	753-1239	1		Clutch Cover
58	791-145569	1	/P	Anti-Rotation Screw
59	753-1240	1		Screw
60	753-1241	1		Nut
61	791-181345	1	/P	Clutch Cover Screw
62	753-04298	1		Ignition Module with Screws
63	791-181065	1		Spacer
64	753-04299	1		Flywheel
65	791-182743	1	/P	Shroud Assembly with Screws
66	791-182376	1	/P	Crankcase Assembly (includes 67 & 68)
67	791-182375	1		90° Elbow
68	791-182379	1	/P	Breather Hose
69	791-181015	1		Cam Gear
70	753-1242	1	S	Cam Follower Set
71	791-181013	1		Cam Bracket
72	791-181012	1		Cam Bracket Screw
73	791-181040	1		Valves, Intake and Exhaust
74	791-182374	1		Cylinder Gasket
75	791-181018	1		Oil Pan Gasket
76	791-182377	1		Oil Pan (includes 75 & 77)
77	791-181020	1		Oil Pan Screw
78	753-04041	1	S	Dipstick Assembly
79	791-182290	1		O-Ring
80	791-181009	1		Connecting Rod
81	791-181008	1		Wrist Pin Button
82	753-1243	1	S	Piston
83	791-181006	1		Wrist Pin
84	791-182295	1	S	Piston Ring Set
85	791-182409	1		Washer
86	791-181861	1		Shroud Screw
87	791-612468	1		Compression Spring
88	791-182537	1		Grommet
89	753-04316	1	S	Air Cleaner Cover
	791-180852B	1	/P	Spark Plug not shown
	753-1245	1		Short Block Assembly (includes 3-14, 65-84); not shown
	791-180142	1	S	Starter Pawl Repair Kit not shown
	791-182156	1	S	Carburetor Repair Kit not shown
	753-1248	1		Gasket Diaphragm Repair Kit not shown