


TB490BC 41BDT49C966
Boom

Page 1 of 5




TB490BC 41BDT49C966
Boom

Page 2 of 5

Ref #	Part Number	Qty	S/P/F	Description
1	791-00040	1		Throttle Housing Assembly (includes 2-4)
2	791-00041	1		Throttle Trigger Lock-Out
3	791-00042	1	S	Throttle Trigger
4	791-182690	1		Throttle Trigger Spring
5	791-182405	1	/P	Switch
6	791-610327	1		Harness Clip
7	753-04503	1	/P	Upper Drive Shaft Housing Assembly
8	791-181099	1		J-Handle Assembly
9	791-683295	1		Handle Bracket Assembly (includes 10-15)
10	791-181811	1		Screw
11	791-181812	1		Upper Handle Clamp
12	791-181813	1		Middle Handle Clamp
13	791-181814	1		Lower Handle Clamp
14	791-181815	1		Nut
15	791-145569	1	/P	Anti-Rotation Screw
16	753-1190	1	/P	Split Boom Coupler (includes 17-20)
17	791-182057	1		Screw
18	791-181617	1		Bolt
19	791-181981	1		Adjustment Knob
20	753-04386	1	S	Knob Retaining Nut
21	791-182541	1		Lower Drive Shaft Housing Assembly
22	791-613300	1		Lower Flexible Drive Shaft
23	791-182200	1		Shield Mount Screw Assembly
24	791-182193	1	/P	2 piece Gearbox Assembly (includes 25-35)
25	791-182195	1		Gearbox Mounting Hardware
26	791-145569	1	/P	Anti-Rotation Screw
27	791-182192	1	S	Right Housing
28	791-182191	1	/P	Left Housing
29	791-182194	1		Pinion Gear Assembly
30	791-182199	1		Output Shaft Bushing
31	791-182198	1		Output Shaft Gear
32	791-182197	1		Output Shaft Assembly (includes 30 & 31)
33	791-182196	1		Blade Driver
34	753-04348	1	/P	Palnut
35	791-147490	1		Retaining Washer
36	791-147492	1		Blade Shield/Shield Mount
37	791-683304	1		Shield Mounting Screw
38	753-1191	1		Shield Assembly (includes 39)
39	791-682061	1		Blade Assembly
40	791-612483	1		Spool Shaft
41	791-683301	1		Outer Spool Assembly (includes 42)
42	791-612026	1		Retainer
43	791-610636B	1	/P	Spring
44	791-147495	1		Inner Reel
45	791-180814B	1	/P	Bump Head Knob Assembly
46	791-145873B	1	/P	4-Tooth Blade
48	791-181699	1	S	Nut
	791-180014B	1		Blade Retaining Kit (includes 34 & 43) (not shown)
	791-613226	1		Locking Rod Tool (not shown)
	791-682075B	1	/P	Shoulder Harness (not shown)

TB490BC 41BDT49C966
Engine

Page 3 of 5



TB490BC 41BDT49C966
Engine

Page 4 of 5

Ref #	Part Number	Qty	S/P/F	Description
1	753-04083	1		Engine Cover
2	791-182339	1	S	Engine Cover Screws
3	791-181025	1		Valve Cover Screw
4	791-182098	1		Valve Cover
5	791-182099	1	/P	Valve Cover Gasket
6	791-182340	1		Rocker Adjustment Nut
7	791-182101	1	/P	Rocker Arm Pivot
8	791-182100	1		Rocker Arm
9	791-182341	1		Rocker Arm Stud
10	791-182103	1		Valve Spring Retainer
11	791-181038	1		Valve Spring
12	791-182102	1		Push Rod Guide
13	791-181033	1		Push Rod
14	753-04816	1	/P	Cylinder Assembly (includes 9, 12 & 73)
15	791-182344	1	S	Cylinder Screw
16	791-182345	1		Intake Baffle
17	791-182749	1		Carburetor Mount Gasket
18	791-181034	1	S	Nut
19	791-182347	1		Carburetor Mount (includes 18)
20	791-182348	1		Carburetor Mount Screw
21	791-182732	1	/P	Carburetor Gasket
22	753-04745	1		Carburetor w/Primer
23	791-181751	1		O-Ring, Carburetor
24	753-04305	1	/P	Air Filter/Choke Cover Assembly (includes 32)
25	791-182097	1		Breather Tube
26	791-181750	1		Air Filter Mounting Screw
27	791-181757	1		Air Filter
28	753-1229	1		Fuel Cap
29	791-182352	1		Fuel Return Line
30	791-182353	1		Fuel Pick-Up Line with Filter
31	753-04185	1		Screw
32	791-182409	1		Washer
33	753-1230	1		Fuel Tank Assembly (includes 28-30)
34	791-182356	1		Fuel Tank Shield
35	753-04746	1		Throttle Cable
36	791-182358	1		Muffler Baffle
37	791-181048	1		Muffler Gasket
38	791-182359	1	/P	Muffler (includes 37, 39-41)
39	791-180890	1		Spark Arrestor Screen
40	791-181045	1		Screen Cover
41	791-181046	1		Screw
42	791-182361	1		Muffler Mounting Screw
43	753-04092	1		Muffler Cover
44	791-182804	1		Switch Wire Assembly
45	791-181247	1	S	Palnut
46	753-1199	1		Recoil Pulley
47	753-04286	1		Recoil Spring
48	791-182366	1		Nut Clip
49	791-181079	1	S	Pull Handle
50	791-611061	1		Rope Guide
51	791-613103	1		Rope
52	791-181020	1		Starter Housing Screw

TB490BC 41BDT49C966
Engine

Page 5 of 5

Ref #	Part Number	Qty	S/P/F	Description
53	753-1237	1	S	Starter Housing Assembly (includes 45-52)
54	791-182396	1	S	Clutch Washer
55	753-1238	1		Clutch w/Spacer
56	791-153592	1	/P	Clutch Drum
57	753-1239	1		Clutch Cover
58	791-145569	1	/P	Anti-Rotation Screw
59	753-1240	1		Screw
60	753-1241	1		Nut
61	791-181345	1	/P	Clutch Cover Screw
62	753-04298	1		Ignition Module with Screws
63	791-181065	1		Spacer
64	753-04299	1		Flywheel
65	791-182743	1	/P	Shroud Assembly (includes 86)
66	791-182376	1	/P	Crankcase Assembly (includes 67 & 68)
67	791-182375	1		90° Elbow
68	791-182379	1	/P	Breather Hose
69	791-181015	1		Cam Gear
70	753-1242	1	S	Cam Follower Set
71	791-181013	1		Cam Bracket
72	791-181012	1		Cam Bracket Screw
73	791-181040	1		Valves, Intake and Exhaust
74	791-182374	1		Cylinder Gasket
75	791-181018	1		Oil Pan Gasket
76	791-182377	1		Oil Pan (includes 75 & 77)
77	791-181020	1		Oil Pan Screw
78	753-04041	1	S	Dipstick Assembly ((ncludes 79)
79	791-182290	1		O-Ring
80	791-181009	1		Connecting Rod
81	791-181008	1		Wrist Pin Button
82	753-1243	1	S	Piston (includes 84)
83	791-181006	1		Wrist Pin
84	791-182295	1	S	Piston Ring Set
85	791-181861	1		Shroud Screw
86	791-182537	1		Grommet
87	791-182360	1		Heat Sheild
88	753-04098	1		Wire Cover
89	791-160428	1		Cable Clamp
	791-180852B	1	/P	Spark Plug (not shown)
	753-04818	1		Short Block Assembly (includes 3-14, 65-84) (not shown)
	791-180142	1	S	Starter Pawl Repair Kit (not shown)