


TB575EC 41EDT57C966  
Engine Assembly

Page 1 of 4




TB575EC 41EDT57C966  
Engine Assembly

Page 2 of 4

| Ref # | Part Number | Qty | S/P/F | Description                                                      |
|-------|-------------|-----|-------|------------------------------------------------------------------|
| 1     | 753-06134   | 1   |       | Engine Cover Assembly (Incl. Ref No. 2 & 3)                      |
| 2     | 710-04194   | 1   | /P    | Cover Screw                                                      |
| 3     | 791-181003  | 1   | /P    | Screw                                                            |
| 4     | 753-05901   | 1   |       | Rocker Cover                                                     |
| 5     | 753-05902   | 1   |       | Rocker Cover O-Ring                                              |
| 6     | 753-06311   | 1   |       | Cylinder Assembly (Incl. Ref No. 3 & 5)                          |
| 7     | 753-05408   | 1   | /P    | Oil Plug (Incl. Ref No. 8)                                       |
| 8     | 791-182290  | 1   |       | Oil Plug O-Ring                                                  |
| 9     | 753-06111   | 1   |       | Crankcase Cover                                                  |
| 10    | 753-05238   | 1   |       | Crankcase Cover O-ring                                           |
| 11    | 753-06313   | 1   |       | Crankcase Assembly (Incl. Ref No. 10)                            |
| 12    | 753-06221   | 1   |       | Flywheel Assembly                                                |
| 13    | 753-05264   | 1   |       | Lead Wires                                                       |
| 14    | 753-05243   | 1   | S     | Module Assembly                                                  |
| 15    | 753-05244   | 1   |       | Muffler Gasket                                                   |
| 16    | 753-05245   | 1   |       | Muffler Assembly (Incl. Ref No. 15 & 17)                         |
| 17    | 753-05246   | 1   | S     | Muffler Screw                                                    |
| 18    | 794-00043   | 1   | /P    | Spark Plug                                                       |
| 19    | 753-05247   | 1   |       | Insulator Gasket                                                 |
| 20    | 712-04099   | 1   | /P    | Nut                                                              |
| 21    | 753-05249   | 1   |       | Insulator                                                        |
| 22    | 753-05366   | 1   | /P    | Carburetor Gasket                                                |
| 23    | 753-06220   | 1   |       | Carburetor                                                       |
| 24    | 791-181751  | 1   |       | O-Ring                                                           |
| 25    | 753-05252   | 1   |       | Air Cleaner Cover Assembly (Incl. Ref No. 26)                    |
| 26    | 753-05254   | 1   |       | Air Filter                                                       |
| 27    | 710-04517   | 1   | /P    | Screw                                                            |
| 28    | 753-06240   | 1   |       | Fuel Tank Assembly w/Fuel Lines (Incl. Ref No. 29)               |
| 29    | 753-1229    | 1   |       | Fuel Cap                                                         |
| 30    | 753-05259   | 1   |       | Fuel Tank Pads                                                   |
| 31    | 753-06314   | 1   |       | Starter Housing Assembly (Incl. Ref No. 3)                       |
| 32    | 753-06281   | 1   |       | Clutch Assembly                                                  |
| 33    | 753-05263   | 1   |       | Clutch Cover (Incl. Ref No. 2)                                   |
| 34    | 791-182519  | 1   |       | Anti-Rotation Screw                                              |
| 35    | 753-04003   | 1   |       | Clamp Screw                                                      |
| 36    | 791-180217  | 1   | S     | Nut                                                              |
| 37    | 791-181025  | 1   |       | Rocker Cover Screw                                               |
|       | 753-05297   | 1   | /P    | Spark Arrestor Assembly Not Shown                                |
|       | 753-06317   | 1   |       | Shortblock Assembly Not Shown(Incl. Ref No. 3-6, 8, 10, 11 & 18) |

TB575EC 41EDT57C966  
General Assembly

Page 3 of 4



TB575EC 41EDT57C966  
General Assembly

Page 4 of 4

| Ref # | Part Number | Qty | S/P/F | Description                                   |
|-------|-------------|-----|-------|-----------------------------------------------|
| 1     | 753-04234   | 1   |       | Throttle Housing Assembly (Incl. Ref No. 2-4) |
| 2     | 753-04119   | 1   | /P    | Throttle Trigger                              |
| 3     | 791-182690  | 1   |       | Throttle Trigger Spring                       |
| 4     | 791-182405  | 1   | /P    | Switch                                        |
| 5     | 753-05266   | 1   |       | Throttle Cable Assembly                       |
| 6     | 753-04236   | 1   | /P    | Upper Drive Shaft Housing Assembly            |
| 7     | 753-06039   | 1   |       | Deluxe D-Handle Assembly (Incl. Ref No. 8)    |
| 8     | 753-06040   | 1   |       | Bolt                                          |
| 9     | 753-1190    | 1   | /P    | Split Boom Coupler (Incl. Ref No. 10-13)      |
| 10    | 791-182057  | 1   |       | Screw                                         |
| 11    | 791-181617  | 1   |       | Bolt                                          |
| 12    | 791-181618B | 1   | /P    | Adjustment Knob (Incl. Ref No. 13)            |
| 13    | 712-04018A  | 1   | /P    | Knob Retaining Nut                            |
| 14    | 753-06139   | 1   |       | Lower Drive Shaft Housing Assembly            |
| 15    | 753-05267   | 1   |       | Lower Flexible Drive Shaft                    |
| 16    | 7039        | 1   | /P    | Anti-Rotation Screw                           |
| 17    | 753-06124   | 1   |       | Gear Box Assembly (Incl. Ref No. 16)          |
| 18    | 753-06125   | 1   |       | Shield Mounting Screws                        |
| 19    | 753-06123   | 1   |       | Shield Assembly (Incl. Ref No. 20)            |
| 20    | 753-06126   | 1   |       | Blade Assembly                                |
| 21    | 753-06129   | 1   |       | Cutting Head Assembly                         |