


TB70SS 41BDT70C711
Boom and Trimmer 1

Page 1 of 10




TB70SS 41BDT70C711
Boom and Trimmer 1

Page 2 of 10

Ref #	Part Number	Qty	S/P/F	Description
1	753-04234	1		Throttle Housing Assembly (includes 2-4)
2	753-04119	1	/P	Throttle Trigger
3	791-182690	1		Throttle Trigger Spring
4	791-182405	1	/P	Switch
5	753-04405	1	S	Throttle Cable Assembly
6	753-04344	1	/P	Upper Drive Shaft Housing Assembly
7	791-180869	1		Deluxe D-Handle Assembly (includes 8-10)
8	791-181070	1		Screw
9	791-182167	1		Deluxe D-Handle
10	791-182168	1		Bottom Clamp
11	753-1190	1	/P	Split Boom Coupler (includes 12-15)
12	791-182057	1		Screw
13	791-181617	1		Bolt
14	791-181981	1		Adjustment Knob
15	753-04386	1	S	Knob Retaining Nut
16	753-1212	1	S	Lower Drive Shaft Housing Assembly
17	791-181166	1		Lower Flexible Drive Shaft
18	791-153597	1		Lower Clamp Assembly (includes 19)
19	791-145569	1	/P	Anti-Rotation Screw
20	791-180549	1		Gear Box Assembly
21	791-180547	1		Shield Mounting Hardware
22	791-180548	1	/P	Shield Assembly (includes 23)
23	791-682061	1		Blade Assembly
24	791-153619	1		Outer Spool Assembly (includes 25)
25	791-610660	1		Retaining
26	791-610317B	1	/P	Spring
27	753-1155	1	/P	Inner Reel
28	791-153066B	1	/P	Bump Head Knob Assembly
	791-180120	1	S	Replacement Line, 0.095 Diameter (Optional Accessories)
	753-1156	1	S	Reel and Line Assembly (Optional Accessories)

TB70SS 41BDT70C711
Boom and Trimmer 2

Page 3 of 10




TB70SS 41BDT70C711
Boom and Trimmer 2

Page 4 of 10

Ref #	Part Number	Qty	S/P/F	Description
1	753-04234	1		Throttle Housing Assembly (includes 2-4)
2	753-04119	1	/P	Throttle Trigger
3	791-182690	1		Throttle Trigger Spring
4	791-182405	1	/P	Switch
5	753-04405	1	S	Throttle Cable Assembly
6	753-04344	1	/P	Upper Drive Shaft Housing Assembly
7	791-180869	1		Deluxe D-Handle Assembly (includes 8-10)
8	791-181070	1		Screw
9	791-182167	1		Deluxe D-Handle
10	791-182168	1		Bottom Clamp
11	753-1190	1	/P	Split Boom Coupler (includes 12-15)
12	791-182057	1		Screw
13	791-181617	1		Bolt
14	791-181981	1		Adjustment Knob
15	753-04386	1	S	Knob Retaining Nut
16	753-1212	1	S	Lower Drive Shaft Housing Assembly
17	753-05182	1		Lower Flexible Drive Shaft
18	791-145569	1	/P	Anti-Rotation Screw
19	753-05183	1		Gear Box Assembly (includes 23-27)
20	791-180547	1		Shield Mounting Hardware
21	791-180548	1	/P	Shield Assembly (includes 22)
22	791-682061	1		Blade Assembly
23	791-153619	1		Outer Spool Assembly (includes 24)
24	791-610660	1		Retaining
25	791-610317B	1	/P	Spring
26	753-1155	1	/P	Inner Reel
27	791-153066B	1	/P	Bump Head Knob Assembly
	791-180120	1	S	Replacement Line, 0.095 Diameter Optional Accessories
	753-1156	1	S	Reel and Line Assembly Optional Accessories

TB70SS 41BDT70C711
Engine 1

Page 5 of 10



TB70SS 41BDT70C711
Engine 1

Page 6 of 10

Ref #	Part Number	Qty	S/P/F	Description
1	753-04511	1	/P	Air Cleaner Cover Assembly (includes 2 & 37)
2	791-180350B	1	/P	Air Cleaner Filter
3	791-180351	1		Carburetor Mounting Screw Assembly
4	791-180226	1	S	Wavey Washer
5	791-182202	1	/P	Choke Knob w/Screw
6	753-04418	1	/P	Choke Lever (includes 5)
7	753-04419	1	/P	Choke Plate (includes 6)
8	753-05133	1		Carburetor Assembly (includes 9 & 20)
9	791-610675	1		Carburetor Gasket
10	791-181860	1		Carb Mount Screw
11	791-683974B	1	/P	Primer & Hose Assembly
12	753-1196	1	/P	Carb Mount Assembly (includes 10, 13 & 14)
13	791-684451	1		Reed Assembly
14	753-1208	1	/P	Carburetor Mount Gasket
15	753-04401	1		Crankcase Service Assembly (includes 10)
16	791-612134	1		Rear Mounting Pad
17	753-04307	1	/P	Fuel Tank Assembly (includes 18-20)
18	753-04084	1	/P	Fuel Cap Assembly
19	791-181086	1	/P	Fuel Return Line
20	753-04233	1		Fuel Line Assembly
21	791-145308	1		Front Mounting Pad
22	753-04702	1		Shroud Extension & Stand
23	791-182736	1	S	Flywheel Assembly
24	791-181525	1		Spacer
25	753-04459	1	/P	Recoil Pulley Assembly (includes 24, 26 & 28)
26	753-04286	1		Recoil Spring
27	753-1200	1		Rope Guide
28	753-04288	1	/P	Pulley Retainer
29	791-181079	1	S	Pull Handle
30	791-613103	1		Rope
31	753-04417	1	/P	Pressure Plate Assembly (includes 32)
32	753-1202	1		Plate Screw
33	753-04402	1		Starter Housing Assembly (includes 25-32, 34 & 39)
34	791-181862	1	/P	Housing Screw
35	791-182368	1	S	Clutch Washer
36	791-182369	1	S	Clutch Rotor Assembly
37	791-153592	1	/P	Clutch Drum Assembly
38	753-04403	1		Clutch Cover Assembly (includes 39-42)
39	791-181345	1	/P	Cover Screw
40	791-182519	1		Anti-Rotation Screw
41	753-04003	1		Clamping Screw
42	791-180217	1	S	Clamping Nut
43	753-05025	1	/P	Wire Leads and Sleeve
44	791-611063	1	/P	Ground Tab
45	753-04336	1		Module Assembly
46	791-610311B	1	/P	Spark Plug
47	753-05169	1	/P	Muffler Assembly (includes 48 & 49)
48	753-04619	1	/P	Exhaust Gasket
49	753-04620	1	S	Muffler Mounting Bolts
50	753-04323	1	S	Cylinder Assembly (includes 52 & 53)
51	753-04367	1	/P	Piston and Rod Assembly
52	753-04182	1		Cylinder Gasket


TB70SS 41BDT70C711
Engine 1

Page 7 of 10

Ref #	Part Number	Qty	S/P/F	Description
53	791-182723	1		Cylinder Bolt
	753-04689	1		Spark Arrestor Screen Not shown
	753-1209	1		Piston Ring Set Not shown
	753-04812	1	/P	Short Block Assembly (includes 10, 15, 46 & 50-53) Not shown
	791-181599	1		Clutch Springs (Qty. 2) Not shown

TB70SS 41BDT70C711
Engine 2

Page 8 of 10



TB70SS 41BDT70C711
Engine 2

Page 9 of 10

Ref #	Part Number	Qty	S/P/F	Description
1	753-04511	1	/P	Air Cleaner Cover Assembly (includes 2 & 38)
2	791-180350B	1	/P	Air Cleaner Filter
3	791-180351	1		Carburetor Mounting Screw Assembly
4	791-180226	1	S	Wavey Washer
5	791-182202	1	/P	Choke Knob w/Screw
6	753-04418	1	/P	Choke Lever (includes 5)
7	753-04419	1	/P	Choke Plate (includes 6)
8	753-05133	1		Carburetor Assembly (includes 9 & 19)
9	791-610675	1		Carburetor Gasket
10	791-181860	1		Carb Mount Screw
11	791-683974B	1	/P	Primer & Hose Assembly
12	753-1196	1	/P	Carb Mount Assembly (includes 10, 13 & 14)
13	791-684451	1		Reed Assembly
14	753-1208	1	/P	Carburetor Mount Gasket
15	791-612134	1		Rear Mounting Pad
16	753-04307	1	/P	Fuel Tank Assembly (includes 17-19)
17	791-182529	1		Fuel Cap Assembly
18	791-181086	1	/P	Fuel Return Line
19	753-04233	1		Fuel Line Assembly
20	791-145308	1		Front Mounting Pad
21	753-05091	1	/P	Shroud Extension & Stand (includes 38)
22	753-05240	1	/P	Flywheel Assembly
22	914-04016	1	/P	Woodruff Key.125 x .375 Not shown
23	791-181525	1		Spacer
24	753-04459	1	/P	Recoil Pulley Assembly (includes 27 & 29)
25	753-04286	1		Recoil Spring
26	753-1200	1		Rope Guide
27	753-04288	1	/P	Pulley Retainer
28	791-181079	1	S	Pull Handle
29	791-613103	1		Rope
30	753-04417	1	/P	Pressure Plate Assembly (includes 31)
31	753-1202	1		Plate Screw
32	753-04402	1		Starter Housing Assembly (includes 24-31, 33 & 38)
33	791-181862	1	/P	Housing Screw
34	791-182396	1	S	Clutch Washer
35	791-182369	1	S	Clutch Rotor Assembly Mfg date 09092007 and before
35	753-05722	1		Clutch Rotor Assembly Mfg date 09102007 and after
36	791-153592	1	/P	Clutch Drum Assembly Mfg date 09092007 and before
36	753-05723	1		Clutch Drum Assembly Mfg date 09102007 and after
37	753-04403	1		Clutch Cover Assembly (includes 38-41)
38	791-181345	1	/P	Cover Screw
39	791-182519	1		Anti-Rotation Screw
40	753-04003	1		Clamping Screw
41	791-180217	1	S	Clamping Nut
42	753-05025	1	/P	Wire Leads and Sleeve
43	791-611063	1	/P	Ground Tab

TB70SS 41BDT70C711
Engine 2

Page 10 of 10

Ref #	Part Number	Qty	S/P/F	Description
44	753-04336	1		Module Assembly
45	791-610311B	1	/P	Spark Plug
46	753-05169	1	/P	Muffler Assembly (includes 47, 48 & Spark Arrestor)
47	753-04619	1	/P	Exhaust Gasket
48	753-04620	1	S	Muffler Mounting Bolts
49	753-04814	1	/P	Cylinder Assembly (includes 51 & 52)
50	753-04367	1	/P	Piston and Rod Assembly
51	753-04182	1		Cylinder Gasket
52	791-182723	1		Cylinder Bolt
	753-1209	1		Piston Ring Set Not Shown
	753-04812	1	/P	Short Block Assembly (includes Crankcase, 10, 45 & 49-52) Not Shown