


TB90BC 41ADT90C711
Boom & Trimmer

Page 1 of 6



TB90BC 41ADT90C711
Boom & Trimmer

Page 2 of 6

Ref #	Part Number	Qty	S/P/F	Description
1	791-00040	1		Throttle Housing Assembly (includes 2-4)
2	791-00041	1		Throttle Trigger Lock-Out
3	791-00042	1	S	Throttle Trigger
4	791-182690	1		Throttle Trigger Spring
5	791-182405	1	/P	Switch Assembly
6	753-04136	1	S	Throttle Cable Assembly
7	791-610327	1		Harness Clip
8	753-04236	1	/P	Upper Drive Shaft Housing Assembly
9	791-180286	1		J-Handle Assembly
10	791-683295	1		Handle Bracket Assembly (includes 11-16)
11	791-181811	1		Screw
12	791-181812	1		Upper Handle Clamp
13	791-181813	1		Middle Handle Clamp
14	791-181814	1		Lower Handle Clamp
15	791-181815	1		Nut
16	791-145569	1	/P	Anti-Rotation Screw
17	791-181980	1		Split Boom Coupler (includes 18-21)
18	791-182057	1		Screw
19	791-181617	1		Bolt
20	791-181981	1		Adjustment Knob
21	791-181886	1		Knob Retaining Nut
22	791-180804	1		Lower Drive Shaft Housing Assembly
23	791-613300	1		Lower Flexible Drive Shaft
24	791-182200	1		Shield Mount Screw Assembly
25	791-182193	1	/P	2 piece Gearbox Assembly (includes 26-35)
26	791-182195	1		Gearbox Mounting Hardware
27	791-145569	1	/P	Anti-Rotation Screw
28	791-182191	1	/P	Left Housing
29	791-182192	1	S	Right Housing
30	791-182195	1		Gear Box Screw
31	791-182194	1		Pinion Gear Assembly
32	791-182199	1		Output Shaft Bushing
33	791-182198	1		Output Shaft Gear
34	791-182197	1		Output Shaft Assembly (includes 33 & 34)
35	791-182196	1		Blade Driver
36	N/A	1		Palnut
37	791-147492	1		Blade Shield/Shield Mount
38	791-683304	1		Shield Mounting Screw
39	791-683299	1		Shield Assembly (includes 40)
40	791-682061	1		Blade Assembly
41	791-147490	1		Retaining Washer
42	791-612483	1		Spool Shaft
43	791-683301	1		Outer Spool Assembly
44	791-612026	1		Retainer
45	791-610636	1	S	Spring
46	791-147495	1		Inner Reel
47	791-180814	1	S	Bump Head Knob Assembly
48	791-145873B	1	/P	4-Tooth Blade
49	791-181699	1	S	Nut
	791-180014B	1		Blade Retaining Kit (includes 41 & 49) (not shown)
	791-613226	1		Locking Rod Tool (not shown)
	791-682075	1	S	Shoulder Harness (not shown)


TB90BC 41ADT90C711
Boom & Trimmer

Page 3 of 6

Ref #	Part Number	Qty	S/P/F	Description
	791-180120	1	S	Replacement Line, 0.095 Diameter optional (not shown)
	791-147278	1	S	Reel and Line Assembly optional (not shown)
	791-147498	1	/P	Bump Head Assembly (includes 42-47) optional (not shown)

TB90BC 41ADT90C711
Engine Parts

Page 4 of 6



TB90BC 41ADT90C711
Engine Parts

Page 5 of 6

Ref #	Part Number	Qty	S/P/F	Description
1	753-04810	1		Air Cleaner Cover Assembly (includes 2 & 37)
2	791-180350B	1	/P	Air Cleaner Filter
3	791-180351	1		Carburetor Mounting Screw Assembly
4	753-0427	1		Choke Extension
5	753-1194	1	S	Choke Plate
6	753-04338	1	/P	Carburetor Assembly (includes 7 & 18)
7	791-610675	1		Carburetor Gasket
8	791-181860	1		Carb Mount Screw
9	791-683974B	1	/P	Primer & Hose Assembly
10	753-1196	1	/P	Carb Mount Assembly (includes 8, 11 & 12)
11	791-684451	1		Reed Assembly
12	753-1208	1	/P	Carburetor Mount Gasket
13	753-04609	1		Crankcase Service Assembly (includes 8)
14	791-612134	1		Rear Mounting Pad
15	753-04307	1	/P	Fuel Tank Assembly (includes 16-18)
16	753-04084	1	/P	Fuel Cap Assembly
17	791-181168	1	S	Fuel Return Line
18	753-04233	1		Fuel Line Assembly
19	791-145308	1		Front Mounting Pad
20	791-182064	1	S	Shroud Extension & Stand
21	791-182736	1	S	Flywheel Assembly
22	791-181525	1		Spacer
23	753-04459	1	/P	Recoil Pulley Assembly (includes 24, 26 & 28)
24	753-04286	1		Recoil Spring
25	753-1200	1		Rope Guide
26	791-181247	1	S	Pulley Retainer
27	791-181079	1	S	Pull Handle
28	791-613103	1		Rope
29	753-1201	1	S	Pressure Plate Assembly
30	753-1202	1		Plate Screw
31	753-04402	1		Starter Housing Assembly (includes 23-30, 32 & 37)
32	791-181862	1	/P	Housing Screw
33	791-182396	1	S	Clutch Washer
34	791-182369	1	S	Clutch Rotor Assembly
35	791-153592	1	/P	Clutch Drum Assembly
36	753-1204	1		Clutch Cover Assembly (includes 37-40)
37	791-181345	1	/P	Cover Screw
38	791-182519	1		Anti-Rotation Screw
39	753-04003	1		Clamping Screw
40	791-180217	1	S	Clamping Nut
41	753-04792	1	S	Wire Leads and Sleeve
42	791-611063	1	/P	Ground Tab
43	753-04337	1		Module Assembly (includes 42)
44	791-610311B	1	/P	Spark Plug
45	753-04618	1	S	Muffler Assembly (includes 46-51)
46	753-04619	1	/P	Exhaust Gasket
47	753-04689	1		Spark Arrestor Screen
48	753-04690	1		Exhaust Hood Diverter
49	753-04691	1		Exhaust Hood
50	753-04315	1	S	Screws
51	753-04620	1	S	Muffler Mounting Bolts
52	753-04814	1	/P	Cylinder Assembly (includes 54 & 55)

TB90BC 41ADT90C711
Engine Parts

Page 6 of 6

Ref #	Part Number	Qty	S/P/F	Description
53	753-04367	1	/P	Piston and Rod Assembly
54	753-04182	1		Cylinder Gasket
55	791-182723	1		Cylinder Bolt (Not Shown)
	753-1209	1		Piston Ring Set (Not Shown)
	753-04612	1	S	Short Block Assembly (includes 8, 13, & 52-55) (Not Shown)
	791-181599	1		Clutch Springs (Qty. 2) (Not Shown)