


TB90BC 41BDT90C063
Boom And Trimmer Parts

Page 1 of 6



TB90BC 41BDT90C063
Boom And Trimmer Parts

Page 2 of 6

Ref #	Part Number	Qty	S/P/F	Description
1	753-04118	1		Throttle Housing & Trigger Assembly (includes 2-5)
2	791-00041	1		Throttle Trigger Lock-Out
3	753-04119	1	/P	Throttle Trigger
4	791-182690	1		Throttle Trigger Spring
5	791-182405	1	/P	Switch Assembly
6	753-04136	1	S	Throttle Cable
7	791-610327	1		Harness Clip
8	753-04236	1	/P	Upper Drive Shaft Housing Assembly
9	791-181099	1		J-Handle Assembly (includes 10 & 11)
10	791-612831	1		Grip
11	791-612021	1		Tube Closure
12	791-683295	1		Handle Bracket Assembly (includes 13-18)
13	791-181811	1		Screw
14	791-181812	1		Upper Handle Clamp
15	791-181813	1		Middle Handle Clamp
16	791-181814	1		Lower Handle Clamp
17	791-181815	1		Nut
18	791-145569	1	/P	Anti-Rotation Screw
19	791-181980	1		Split-Boom Coupler (includes 20-23)
20	791-182057	1		Screw
21	791-181617	1		Bolt
22	791-181981	1		Adjustment Knob
23	791-181886	1		Knob Retaining Nut
24	791-180804	1		Lower Drive Shaft Housing Assembly
25	791-613300	1		Lower Flexible Drive Shaft
26	791-182200	1		Shield Mount Screw Assembly
27	791-182193	1	/P	2 piece Gearbox Assembly (includes 28-30)
28	791-182195	1		Gearbox Mounting Hardware
29	791-145569	1	/P	Anti-Rotation Screw
30	791-182196	1		Blade Driver
31	791-147492	1		Blade Shield/Shield Mount
32	791-683304	1		Shield Mounting Screw
33	791-683299	1		Shield and Blade Assembly (includes 34)
34	791-682061	1		Blade Assembly
35	791-147490	1		Retaining Washer
36	791-612483	1		Spool Shaft
37	791-683301	1		Outer Spool and Eyelet Assembly
38	791-612026	1		Retainer
39	791-610636	1	S	Spring
40	791-147495	1		Inner Reel
41	791-180814	1	S	Bump Head Knob Assembly
42	791-145873	1	S	4-Tooth Blade
43	791-181699	1	S	Nut
	791-180014	1		Blade Retaining Kit (includes 35 & 43); Not Shown
	791-613226	1		Locking Rod Tool Not Shown
	791-682075	1	S	Shoulder Harness Not Shown
44	791-182191	1	/P	Left Housing 2 Piece Gearbox Assembly Parts - Item 27


TB90BC 41BDT90C063
Boom And Trimmer Parts

Page 3 of 6

Ref #	Part Number	Qty	S/P/F	Description
45	791-182192	1	S	Right Housing 2 Piece Gearbox Assembly Parts - Item 27
46	791-182194	1		Pinion Gear Assembly 2 Piece Gearbox Assembly Parts - Item 27
47	791-182199	1		Output Shaft Bushing 2 Piece Gearbox Assembly Parts - Item 27
48	791-182198	1		Output Shaft Gear 2 Piece Gearbox Assembly Parts - Item 27
49	791-182197	1		Output Shaft Assembly (includes 46 & 47) 2 Piece Gearbox Assembly Parts - Item 27
50	753-04348	1	/P	Palnut 2 Piece Gearbox Assembly Parts - Item 27
	791-180120	1	S	Replacement Line, 0.095 Diameter Optional Accessory; Not Shown
	791-147345B	1	/P	Reel and Line Assembly Optional Accessory; Not Shown
	791-147498B	1	S	Bump Head Assembly (includes 36-41); Not Shown
	791-147543	1	S	Ryobi 2-Cycle Oil Optional Accessory; Not Shown

TB90BC 41BDT90C063
Engine Parts

Page 4 of 6



TB90BC 41BDT90C063
Engine Parts

Page 5 of 6

Ref #	Part Number	Qty	S/P/F	Description
1	753-1192	1		Air Cleaner/Muffler Cover Assembly (includes 2 & 37)
2	791-180350B	1	/P	Air Cleaner Filter
3	791-180351	1		Carburetor Mounting Screw Assembly
4	753-1193	1	S	Choke Extension
5	753-1194	1	S	Choke Plate
6	753-04338	1	/P	Carburetor Assembly (includes 7 & 18)
7	791-610675	1		Carburetor Gasket
8	791-181860	1		Carb Mount Screw
9	791-683974B	1	/P	Primer and Hose Assembly
10	753-1196	1	/P	Carb Mount Assembly (includes 8 & 11)
11	791-684451	1		Reed Assembly
12	753-1208	1	/P	Carburetor Mount Gasket
13	753-04369	1		Crank Case Service Assembly (includes 8)
14	791-612134	1		Rear Mounting Pad
15	753-04307	1	/P	Fuel Tank Assembly (includes 16-18)
16	791-182612	1	/P	Fuel Cap Assembly
17	791-181168	1	S	Fuel Return Line
18	753-04233	1		Fuel Line Assembly
19	791-145308	1		Front Mounting Pad
20	791-182064	1	S	Shroud Extension & Stand (includes 37)
21	791-182736	1	S	Flywheel Assembly
22	791-181065	1		Spacer
23	753-1199	1		Recoil Pulley
24	753-04286	1		Recoil Spring
25	753-1200	1		Rope Guide
26	791-181247	1	S	Pulley Retainer
27	791-181079	1	S	Pull Handle
28	791-613103	1		Rope
29	753-1201	1	S	Pressure Plate Assembly (includes 30)
30	753-1202	1		Plate Screw
31	753-1203	1		Starter Housing Assembly (includes 23-30, 32 & 37)
32	791-181862	1	/P	Housing Screw
33	791-182368	1	S	Clutch Washer
34	791-182369	1	S	Clutch Rotor Assembly
35	791-153592	1	/P	Clutch Drum Assembly
36	753-1204	1		Clutch Cover Assembly (includes 37-40)
37	791-181345	1	/P	Cover Screw
38	791-182519	1		Anti-Rotation Screw
39	753-04003	1		Clamping Screw
40	791-180217	1	S	Clamping Nut
41	791-182798	1		Wire Leads and Sleeve
42	791-611063	1	/P	Ground Tab
43	753-04337	1		Module Assembly
44	791-610311B	1	/P	Spark Plug
45	791-182066	1	S	Muffler Assembly (includes 46-48)
46	791-182747	1		Spark Arrestor Screen
47	753-04159	1	S	Exhaust Gasket
48	791-147575	1		Muffler Mounting Bolt Assembly
49	753-04323	1	S	Cylinder Assembly (includes 51 & 52)
50	753-1207	1	S	Piston and Rod Assembly

TB90BC 41BDT90C063
Engine Parts

Page 6 of 6

Ref #	Part Number	Qty	S/P/F	Description
51	753-1197	1		Cylinder Gasket
52	791-182723	1		Cylinder Bolt
	791-180090	1		O.E.M. Carburetor Repair Kit Not Shown
	791-180091	1		Gasket Diaphragm Repair Kit Not Shown
	753-1209	1		Piston Ring Set Not Shown
	753-04334	1	/P	Short Block Assembly (includes 8, 12, 13, 44, 47-52); Not Shown
	791-181599	1		Clutch Springs (Qty. 2) Not Shown