


TB90BC 41BDT90C711
Boom and Trimmer

Page 1 of 6



TB90BC 41BDT90C711
Boom and Trimmer

Page 2 of 6

Ref #	Part Number	Qty	S/P/F	Description
1	753-05192	1		Throttle Housing Assembly (includes 2-4)
2	753-04991	1	S	Throttle Trigger
3	753-05007	1	/P	Throttle Trigger Spring
4	753-05171	1	S	Throttle Trigger Lock-Out
5	791-182405	1	/P	Switch Assembly
6	753-05172	1		Throttle Cable Assembly
7	791-610327	1		Harness Clip
8	753-04236	1	/P	Upper Drive Shaft Housing Assembly
9	791-181099	1		J-Handle Assembly
10	791-683295	1		Handle Bracket Assembly (includes 11-16)
11	791-181811	1		Screw
12	791-181812	1		Upper Handle Clamp
13	791-181813	1		Middle Handle Clamp
14	791-181814	1		Lower Handle Clamp
15	791-181815	1		Nut
16	791-145569	1	/P	Anti-Rotation Screw
17	753-1190	1	/P	Split Boom Coupler (includes 18-21)
18	791-182057	1		Screw
19	791-181617	1		Bolt
20	791-181981	1		Adjustment Knob
21	753-04386	1	S	Knob Retaining Nut
22	791-182541	1		Lower Drive Shaft Housing Assembly
23	791-613300	1		Lower Flexible Drive Shaft
24	791-182200	1		Shield Mount Screw Assembly
25	791-182193	1	/P	2 piece Gearbox Assembly (includes 26-29)
26	791-182195	1		Gearbox Mounting Hardware
27	791-145569	1	/P	Anti-Rotation Screw
28	791-182196	1		Blade Driver
29	753-04348	1	/P	Palnut
30	791-147492	1		Blade Shield/Shield Mount
31	791-683304	1		Shield Mounting Screw
32	791-682061	1		Blade Assembly
33	791-683299	1		Shield Assembly (includes 32)
34	791-147490	1		Retaining Washer
35	791-612483	1		Spool Shaft
36	791-683301	1		Outer Spool Assembly
37	791-612026	1		Retainer
38	791-610636B	1	/P	Spring
39	791-147495	1		Inner Reel
40	791-180814B	1	/P	Bump Head Knob Assembly
41	791-145873B	1	/P	4-Tooth Blade
42	791-181699	1	S	Nut
	791-180014B	1		Blade Retaining Kit (includes 34 & 43) (not shown)
	791-613226	1		Locking Rod Tool (not shown)
	791-682075B	1	/P	Shoulder Harness (not shown)
	753-04216	1		Replacement Line, 0.105 Diameter (Optional Accessories) (not shown)
	753-1224	1	/P	Reel and Line Assembly (Optional Accessories) (not shown)


TB90BC 41BDT90C711
Boom and Trimmer

Page 3 of 6

Ref #	Part Number	Qty	S/P/F	Description
	753-1161	1	/P	Bump Head Assembly (includes 35-40) (Optional Accessories) (not shown)

TB90BC 41BDT90C711
Engine

Page 4 of 6



TB90BC 41BDT90C711
Engine

Page 5 of 6

Ref #	Part Number	Qty	S/P/F	Description
1	753-04511	1	/P	Air Cleaner Cover Assembly (includes 2 & 39)
2	791-180350B	1	/P	Air Cleaner Filter
3	791-180351	1		Carburetor Mounting Screw Assembly
4	791-180226	1	S	Wavey Washer
5	791-182202	1	/P	Choke Knob w/Screw
6	753-04418	1	/P	Choke Lever (includes 5)
7	753-04419	1	/P	Choke Plate (includes 6)
8	753-05133	1		Carburetor Assembly (includes 9 & 20)
9	791-610675	1		Carburetor Gasket
10	791-181860	1		Carb Mount Screw
11	791-683974B	1	/P	Primer & Hose Assembly
12	753-1196	1	/P	Carb Mount Assembly (includes 10, 13 & 14)
13	791-684451	1		Reed Assembly
14	753-1208	1	/P	Carburetor Mount Gasket
15	753-04401	1		Crankcase Service Assembly (includes 10)
16	791-612134	1		Rear Mounting Pad
17	753-04307	1	/P	Fuel Tank Assembly (includes 18-20)
18	791-182529	1		Fuel Cap Assembly
19	791-181086	1	/P	Fuel Return Line
20	753-04233	1		Fuel Line Assembly
21	791-145308	1		Front Mounting Pad
22	753-04409	1	S	Shroud Extension & Stand (includes 39)
23	791-182736	1	S	Flywheel Assembly
24	791-181525	1		Spacer
25	753-04459	1	/P	Recoil Pulley Assembly (includes 26, 28 & 30)
26	753-04286	1		Recoil Spring
27	753-1200	1		Rope Guide
28	753-04288	1	/P	Pulley Retainer
29	791-181079	1	S	Pull Handle
30	791-613103	1		Rope
31	753-04417	1	/P	Pressure Plate Assembly (includes 32)
32	753-1202	1		Plate Screw
33	753-04402	1		Starter Housing Assembly (includes 25-32, 34 & 39)
34	791-181862	1	/P	Housing Screw
35	791-182396	1	S	Clutch Washer
36	791-182369	1	S	Clutch Rotor Assembly
37	791-153592	1	/P	Clutch Drum Assembly
38	753-04403	1		Clutch Cover Assembly (includes 39-42)
39	791-181345	1	/P	Cover Screw
40	791-182519	1		Anti-Rotation Screw
41	753-04003	1		Clamping Screw
42	791-180217	1	S	Clamping Nut
43	753-05025	1	/P	Wire Leads and Sleeve
44	791-611063	1	/P	Ground Tab
45	753-04336	1		Module Assembly
46	791-610311B	1	/P	Spark Plug
47	753-05169	1	/P	Muffler Assembly (includes 48, 49 & spark arrestor)
48	753-04619	1	/P	Exhaust Gasket
49	753-04620	1	S	Muffler Mounting Bolts
50	753-04814	1	/P	Cylinder Assembly (includes 52 & 53)

TB90BC 41BDT90C711
Engine

Page 6 of 6

Ref #	Part Number	Qty	S/P/F	Description
51	753-04367	1	/P	Piston and Rod Assembly
52	753-04182	1		Cylinder Gasket
53	791-182723	1		Cylinder Bolt
	753-1209	1		Piston Ring Set (not shown)
	753-04812	1	/P	Short Block Assembly (includes 10, 15, 46 & 50-53) (not shown)
	791-181599	1		Clutch Springs (Qty. 2) (not shown)