



GENERAL PURPOSE ENGINE

GCV160LA

PARTS CATALOGUE

2

FOREWORD INDEX

1

ENGINE GROUP

2

PART NUMBER INDEX

3

PART NAME INDEX

4

For Discount Troy Bilt Parts Call 606-678-9623 or 606-561-4983

www.mymowerparts.com

Instruction for use of parts catalogue

- **This parts catalogue was prepared based on the latest information available as of December 08, 2006.**
- See the parts catalogue news for any revision that is made after December 08, 2006.
- **Always specify the part number when ordering a part.**
 - Check the model, type, serial numbers, color, maker, and the size as needed before ordering a part.
 - Note that the illustrations (part drawings) can differ from the actual parts in shape. They are given just to help you to refer to the parts.
- **When modifications or additions to this parts catalogue are made, a revised edition will be issued at an appropriate time, with successively progressing revision numbers on the cover. We recommend obtaining such revisions in order to keep your parts catalogue up-to-date at all times. To check whether a parts catalogue revision has been issued, please contact your Honda distributor.**


Initial version issue date October 18, 2006
Honda Motor Co., Ltd.

CONTENTS

	Page	Address No.	
• Instruction for use of parts catalogue	1	B 1	1
• How to refer to the part information	2	B 2	
• Part catalogue structure	3	B 3	
• When the parts were revised	4	B 4	
• Abbreviations used in the parts catalogue	4	B 4	
• How to check the part block and serial numbers	5	B 5	
• Models, parts catalogue codes and applicable serial numbers	6	B 6	
• Features of each type	7	B 7	
• Fuel hose, general purpose hoses and vinyl hose	8	B 8	
• Illustrated index	9	B 9	
• ENGINE GROUP	11	C 1	2
• PART NO. INDEX	33	E 1	3
• PART NAME INDEX	35	F 1	4

How to refer to the part information

A Reference with "Illustrated index"



B Reference with "Part number index"

PART NO. INDEX					
Part Number	Address	Page	Ref.	Part Number	Address
06000				15212-ZW9-000	1-C14
06316-ZW9-000	1-G9	88	1	15220-ZW9-003	1-C14
11000				15332-ZW9-000	1-E8
11300-ZW9-405	1-C11	27	1	15332-ZW9-A30	1-E11
11300-ZW9-406	1-C11	27	1	15400-PFB-004	1-C11
11340-ZW9-000	1-C11	27	2	15422-ZW9-000	1-C14
11342-ZW9-000	1-C11	27	3	15473-881-000	1-C14
11381-ZW9-003	1-C12	28	1	15474-ZW9-000	1-C14
				15611-921-000	1-C10
				15655-ZW9-000	1-C11
12000				16000	
12000-ZW9-405ZA	1-C11	27	4	16010-ZV4-005	1-D4
12155-ZV4-A00	1-C13	29	1	16011-ZV4-005	1-D4
12166-ZW9-000	1-C10	26	1	16013-ZW9-003	1-D4
12209-GB4-681	1-C16	32	1	16016-ZW9-003	1-D4
12210-ZW9-405ZA	1-C10	26	2	16016-ZW9-721	1-D4
12216-ZE2-300	1-E8	58	1	16023-ZW9-003	1-D4
	1-E11	58	1	16024-ZV4-650	1-D4
				16028-ZV4-650	1-D4

C Reference with "Part name index"

PART NAME INDEX					
Partname	Address	Page	Ref.		
[A]					
ABSORBER, FUEL	1-E15	62	5	BOLT,	
ARMATURE COMP.	1-D11	43	7	BOLT,	
ARM COMP., LINK JOINT	1-G6	85	18	BOLT,	
ARM COMP., SHIFT LINK	1-G6	85	14	BOLT,	
ARM COMP., TILT	1-F15	79	20		
ARM, FUEL PUMP ROCKER	1-C16	32	4		
ARM, REVERSE LOCK	1-F15	79	18		
ARM, SHIFT LINK	1-F11	74	7		
ARM, STOPPER	1-D1	33	12	BOLT,	
ARM, THROTTLE REMOTE	1-F11	74	6		
ARM, VALVE ROCKER	1-C16	32	3		
[B]					
BAG, TOOL, 160MM	1-G5	84	10		
BAND	1-G6	86	37		
BAND B1, WIRE	1-F6	69	1		
BAND, CORD	1-F3	67	18	BOLT,	
BAND, TUBE CLIP, 11MM	1-E15	63	20		
BAND, TUBE CLIP, 12.5MM	1-E15	63	19	BOLT,	

Address No. 1-C10

Block No. E-2

Ref No.

CYLINDER HEAD

Service item F.R.T.

Service item	F.R.T.
O-RING, 26X2.7	0.1
PLUG, SPARK	0.2
O-RING, 9.5X1.5	0.2
SENSOR ASSY., WATER TEMPERATURE	0.3
COVER COMP., HEAD	1.8
GASKET, CYLINDER HEAD	2.4
OIL SEAL, 20X32X6	3.1
HEAD COMP., CYLINDER	3.1


ZW83-EG200

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			9F 9F1 9F2 9F3 9F4 9F5 9F6 9F7 9F8 9F9		
1	12166-ZW9-000	STOPPER, ENGINE SIDE	2 2 2 2 2 2		
2	12210-ZW9-000ZA	HEAD COMP., CYLINDER	1 1 1 1 1 1		
3	12251-ZW9-003	GASKET, CYLINDER HEAD	1 1 1 1 1 1		
4	12310-ZW9-000	COVER COMP., HEAD	1 1 1 1 1 1		
5	12312-ZW9-000	PACKING, HEAD COVER	1 1 1 1 1 1		
6	15611-921-000	CAP, OIL (NO GAUGE)	1 1 1 1 1 1		
7	16617-ZW9-000	HOLDER, CABLE	1 1 1 1 1 1	SC,SG	
	16617-ZW9-010		1 1 1 1 1 1	1001800 LHC,LHD	
			1 1 1 1 1 1	1001801 LHC,LHD	
8	35673-ZW5-003	SENSOR ASSY., WATER TEMPERATURE	1 1 1 1 1 1		
9	90003-ZW9-000	BOLT, FLANGE, 6X22	4 4 4 4 4 4		
10	90007-ZW9-003	BOLT, FLANGE, 8X83	6 6 6 6 6 6		
11	90011-ZW9-000	BOLT, FLANGE, 6X14 (CT200)	1 1 1 1 1 1		
12	90020-ZW9-000	BOLT, FLANGE, 8X40	2 2 2 2 2 2		
13	91202-KJ9-003	OIL SEAL, 20X32X6	1 1 1 1 1 1		
14	91301-805-000	O-RING, 26X2.7	1 1 1 1 1 1		
15	91307-PK2-005	O-RING, 9.5X1.5 (HONDA KIKAKI)	1 1 1 1 1 1		
16	98059-55916	PLUG, SPARK (CR5EH-9)	2 2 2 2 2 2		
	98059-55926	PLUG, SPARK (U16FER9)	2 2 2 2 2 2		


2000.09.20 E

Page No.

Part catalogue structure



Ref. No.	Part No.	Description	Reqd. QTY						Serial No.	Parts catalogue code
			BF	BFP	BF	BFP	BF	BFP		
1	12166-ZW9-000	STOPPER, ENGINE SIDE	2	2	2	2	2	2		
2	12210-ZW9-000ZA	HEAD COMP., CYLINDER	1	1	1	1	1	1		
3	12251-ZW9-003	GASKET, CYLINDER HEAD	1	1	1	1	1	1		
4	12310-ZW9-000	COVER COMP., HEAD	1	1	1	1	1	1		
5	12312-ZW9-000	PACKING, HEAD COVER	1	1	1	1	1	1		
6	15611-921-000	CAP, OIL	1	1	1	1	1	1		
7	16617-ZW9-000	HOLDER, CABLE	1	1	1	1	1	1		
	16617-ZW9-010		1	1	1	1	1	1		



① Address number

- Address No. is provided (in place of the page No.) to help you refer to the part with the part No. or part name.

② Block title ③ Block number

④ Service item/Flat rate time

⑤ Reference number

- Title number marked with the parenthesis or parentheses indicates that it continues from the previous page.

⑥ Part number ⑦ Honda color code

⑧ Description

⑨ Assemblies

- Sections framed with broken lines in the exploded view drawings are available as complete assemblies. (Their individual parts can also be obtained.)

⑩ Color description

⑪ Note

- Notes are shown with the parentheses in the part name column.

⑫ Required quantity

- Required QTY shown in the parenthesis or parentheses indicates the optional part.
- Required QTY marked with "N" Indicates the optional part that should be selected as needed.
- Required QTY indicates the number of the part used in the block.

⑬ Serial number

⑭ Type

- When the type column is blank, it indicates that the part is applicable to all types.
- As the type of the actual unit may differ from the "parts catalogue, type" please refer to "Models, types and applicable serial numbers" for confirmation.

⑮

- Parts enclosed within a dotted line are covered in a different block.

⑯

- A hollow arrow indicates the block No. for the parts enclosed within a dotted line.

⑰

- A solid arrow indicates the block No. the part in question is connected to.

When the parts were revised



Be sure to check the serial number!!



Ref. No.	Part No.	Description	Reqd. QTY						Serial No.
			BF	BFP	BF	BFP	BF	BFP	
1	12166-ZW9-000	STOPPER, ENGINE SIDE	2	2	2	2	2	2	
2	12210-ZW9-000ZA	HEAD COMP., CYLINDER *NH8*.....DARK GRAY	1	1	1	1	1	1	
3	12251-ZW9-003	GASKET, CYLINDER HEAD	1	1	1	1	1	1	
4	12310-ZW9-000	COVER COMP., HEAD	1	1	1	1	1	1	
5	12312-ZW9-000	PACKING, HEAD COVER	1	1	1	1	1	1	
6	15611-921-000	CAP, OIL (NO GAUGE)	1	1	1	1	1	1	
7	16617-ZW9-000	HOLDER, CABLE (###).....	1	1	1	1	1	1	
	16617-ZW9-010		1	1	1	1	1	1	

The number has been used from the initial model without revision.

When shown at the left side, it is applicable to the models of No.1001801 and the subsequent numbers.

When shown at the right side, it is applicable to the models up to No.1001800.




• The parts listed with "###" at the end of the parts name have limited supply period (parts not for sale).

Abbreviations used in the parts catalogue

• The following abbreviations are used in the parts name column.

A Ampere	FR.Front
A.C. Alternating current	IN.Inlet
ASSY. Assembly	L (100L) .Link (100 Links)
AT. Automatic transmission	L.Left
C.D.I. Capacitive discharge ignition	MMMillimeter
COMP. ... Complete	MT.Manual Transmission
D.C. Direct current	P.T.O.Power take off
EX. Exhaust	R.Right
G.F.C.I ... Ground fault circuit interruptor	RR.Rear
HEX. Hexagonal	STD.Standard
H.S.T. Hydrostatic transmission	T (22T) ...Tooth (22 Teeth)
	VVolt
	WWatt

How to check the part block and serial numbers



Models, parts catalogue codes and applicable serial numbers

- Models, parts catalogue codes and applicable serial Nos. given in this parts catalogue can be identified as follows.

Model	Type	Parts catalogue type	Applicable engine serial No.	Applicable carburetor identification No.
GCV160LA	A1A	A1A	GJAEA-1000001~	BB62W A
	A1AF	A1AF		BB65A A
	A2R	A2R		BB62W A
	BHH	BHH		
	E1A2	E1A2		
	N1A	N1A		
	N1AF	N1AF		BB65A A
	N5AF	N5AF		
	N5MF	N5MF		
	N5R	N5R		BB62Y A
	N7A1	N7A1		
	N7S1	N7S1		BB62Z A
	R3A	R3A		
	S1A	S1A		BB65E A
	S1M	S1M		BB62Z A
	S3A	S3A		BB65E A
	S3H	S3H		

* Of carburetor identification numbers, only the portions underlined in the example below are used for registration.

BB 65A A KC +
 (A) (B)

Features of each type

- See the following table for the features of each type. (Items in brackets are optional)

Model Type		GCV160LA																
		A1A	A1AF	A2R	BHH	E1A2	N1A	N1AF	N5AF	N5MF	N5R	N7A1	N7S1	R3A	S1A	S1M	S3A	S3H
Specifications																		
Crankshaft	20mm Ø Straight (133.8mm)				●													
	22.2mm Ø Straight (100.4mm)								●	●	●							
	22.2mm Ø Straight (117.4mm)			●								●	●					
	22.2mm Ø Straight (135.7mm)	●	●			●	●	●							●	●		
	25mm Ø Straight (135.7mm)													●			●	●
Recoil starter				●			●	●	●	●	●	●	●					
Recoil starter (Long rope)		●	●		●	●								●	●	●	●	●
Flywheel brake		●	●			●								●	●	●	●	●
Starter motor						●								●				

Fuel hose, general purpose hoses and vinyl hose

- The standard part fuel hose, general purpose hose and vinyl hose may be substituted by the coiled bulk part.
- When ordering the standard part fuel hose, general purpose hose and vinyl hose use the bulk part number written in the parts catalog in brackets () underneath the part name.
- When exchanging the hose, cut and use at the specified length as mentioned in the part name.
(For the method of cutting the bulk part, and method of filling out orders etc., please refer to the instructions issued with the bulk part.)

Bulk part number of fuel hose, general purpose hose and vinyl hose.

Example: 9 5 0 0 1 - 7 5 0 0 1 - 5 0 M

Bulk part number:

Refers to the bulk part.

Marking code (fuel hose and general purpose hose)

Change code (Vinyl hose)

Indicates number mark or change sequence, however, the code for the bulk part must be strictly 0 (zero).

Types of code:

- Fuel hose
 - 2: Red outside braid (3 mm inside dia. only)
 - 5: Black inside braid
 - 3: Red (3 mm inside dia. only)
 - 4: Ash gray with red stripe (3 mm inside dia. only)
 - 6: Black

- General hose
 - 1: Ash gray
 - 2: Ash gray
 - 3: Black
 - 5: Black

- Vinyl hose
 - 1: Clear
 - 2: Black
 - 3: Light red
 - 6: Light red
 - 7: Pale black

Lengths:

001: 1 m (standard)
003: 3 m
008: 8 m

Application or specification of some parts is not settled.

I.D code: (fuel hose and general purpose hose)

30: 3.0 mm
35: 3.5 mm
45: 4.5 mm

50: 5.0 mm
55: 5.3 mm, 5.5 mm
65: 6.5 mm

70: 7.0 mm
75: 7.3 mm, 7.5 mm
80: 8.0 mm

11: 11 mm
91: 12 (outside dia. 15) mm
92: 12 (outside dia. 16) mm

12: 12 (outside dia. 17) mm
14: 14 mm
17: 17 mm

ID./OD. code: (vinyl hose)

01: ID. 2.9, OD. 6.8 mm
03: ID. 3.0, OD. 6.0 mm
05: ID. 3.5, OD. 6.5 mm
07: ID. 4.0, OD. 7.0 mm
08: ID. 4.5, OD. 6.5 mm
09: ID. 4.5, OD. 8.0 mm

12: ID. 5.0, OD. 7.0 mm
10: ID. 5.0, OD. 8.0 mm
11: ID. 5.0, OD. 9.0 mm
14: ID. 6.0, OD. 9.0 mm
17: ID. 7.0, OD. 9.0 mm
19: ID. 7.0, OD. 11.0 mm

21: ID. 8.0, OD. 9.0 mm
23: ID. 8.0, OD. 12.0 mm
25: ID. 9.0, OD. 11.0 mm
27: ID. 9.0, OD. 13.0 mm
33: ID. 10.0, OD. 14.0 mm
36: ID. 11.0, OD. 13.0 mm

37: ID. 11.0, OD. 15.0 mm
38: ID. 12.0, OD. 13.0 mm
39: ID. 12.0, OD. 14.0 mm
40: ID. 12.0, OD. 16.0 mm
43: ID. 13.0, OD. 15.0 mm
45: ID. 14.0, OD. 18.0 mm

50: ID. 16.0, OD. 19.0 mm
55: ID. 17.5, OD. 20.5 mm
60: ID. 22.0, OD. 27.0 mm

Hose type:

- 1: Fuel hose
- 3: Vinyl hose
- 5: General hose

⊙ **CAUTION:** It is **DANGEROUS** to confuse the fuel hose with the general purpose hose or vinyl hose.

Never use a general purpose hose or vinyl hose in place of a fuel hose or vice versa. Always use the correct bulk part in the parts catalogue, according to the service manual or the instructions issued with the bulk part.


ENGINE GROUP

B 9

E-3

CYLINDER BARREL


C 1



E-6

OIL PAN


C 2



E-7

CRANKSHAFT


C 4



E-8

PISTON/CONNECTING ROD


C 5



E-10

CAMSHAFT PULLEY


C 6



E-11

RECOIL STARTER


C 7



E-12

FAN COVER


C 8



E-14

CARBURETOR


C10



E-15

AIR CLEANER

C12



2


ENGINE GROUP

B10

E-16

C13


MUFFLER



E-19

C14


FLYWHEEL



E-21

C16


STARTER MOTOR



E-22

D 1


CONTROL(1)



E-22-1

D 2


CONTROL(2)



E-22-2

D 3


CONTROL(3)



E-22-3

D 4


CHOKE BASE



E-28

D 5


LABEL



E-40

D 6

BLADE HOLDER




2

E-3

CYLINDER BARREL

C 1



Service item

F.R.T.


Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			GCV 160 LA		
1	12000-ZL8-425	BARREL ASSY., CYLINDER	1	-----	A1A,A1AF,A2R,BHH,N1A,N1AF,N5AF,N5MF,N5R,N7A1,N7S1,S1A,S3A
2	12000-ZOL-405	BARREL ASSY., CYLINDER	1	-----	E1A2,R3A
	12000-ZOL-406		1	-----	S1M,S3H
3	12209-ZM0-003	SEAL, VALVE STEM	1		
4	12311-ZL8-000	COVER, HEAD	1		
5	12355-ZL8-000	COVER COMP., BREATHER	1		
6	14711-ZOJ-000	VALVE, IN.	1		
7	14721-ZL8-000	VALVE, EX.	1		
8	14751-ZL8-000	SPRING, VALVE	2		
9	14771-ZOJ-000	RETAINER, VALVE SPRING	2		
10	90013-883-000	BOLT, FLANGE, 6X12(CT200) ...	4		
11	90014-952-000	BOLT, FLANGE, 6X14(CT200) ...	1		
12	91201-ZL8-003	OIL SEAL, 25.4X62X6	1		
13	98079-56846	PLUG, SPARK (BPR6ES)(NGK) ...	1		

2

E-6

OIL PAN

C 2



Service item


F.R.T.

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			GCV 160 LA		
1	11300-ZM0-405	PAN ASSY., OIL	1	-----	A1A,A1AF,BHH,E1A2,R3A,S1A,S1M,S3A,S3H
	11300-ZM0-407		1	-----	A2R,N5R
	11300-ZOL-405		1	-----	N1A,N1AF,N5AF,N5MF
	11300-ZOM-405		1	-----	N7A1,N7S1
2	15625-ZE6-000	PACKING, OIL FILLER CAP	1	-----	BHH,E1A2,N7A1,N7S1,R3A,S1M,S3A,S3H
3	15625-Z2L-801	PACKING, OIL FILLER CAP	1	-----	A1A,A1AF,A2R,N1A,N1AF,N5AF,N5MF,N5R,S1A
4	15631-ZM0-000	EXTENSION, OIL FILLER	1	-----	BHH,N7A1,N7S1,S1M,S3A,S3H
	15631-ZOL-820		1	-----	E1A2,R3A
5	15639-ZM0-000	WASHER, EXTENSION LOCK	1	-----	BHH,E1A2,N7A1,N7S1,R3A,S1M,S3A,S3H
6	15650-ZM0-801	GAUGE ASSY., OIL LEVEL	1	-----	BHH,N7A1,N7S1,S1M,S3A,S3H
	15650-ZOL-820		1	-----	E1A2,R3A
7	15650-ZOL-000	GAUGE ASSY., OIL LEVEL	1	-----	A1A,A1AF,A2R,N1A,N1AF,N5AF,N5MF,N5R,S1A
8	16508-ZM0-010	SHAFT COMP., GOVERNOR HOLDER	1		
9	16510-ZM0-010	GOVERNOR ASSY.	1		
10	16511-ZL8-000	WEIGHT, GOVERNOR	2		
11	16512-ZM0-000	HOLDER, GOVERNOR WEIGHT	1		
12	16513-ZE1-000	PIN, GOVERNOR WEIGHT	2		
13	16531-ZE1-000	SLIDER, GOVERNOR	1		
14	16541-ZM0-000	SHAFT, GOVERNOR ARM	1		
15	90014-952-000	BOLT, FLANGE, 6X14(CT200) ...	1		
16	90121-952-000	BOLT, FLANGE, 6X25(CT200) ...	8		
17	90131-883-000	BOLT, DRAIN PLUG, 12X15	1	-----	N1A,N1AF,N5AF,N5MF
18	90451-ZE1-000	WASHER, THRUST, 6MM	1		
19	90602-ZE1-000	CLIP, GOVERNOR HOLDER	1		
20	91202-ZL8-003	OIL SEAL, 28X41.25X6	1	-----	A1A,A1AF,BHH,E1A2,N7A1,N7S1,R3A,S1A,S1M,S3A,S3H
	91202-ZM0-V31		1	-----	A2R,N1A,N1AF,N5AF,N5MF,N5R

E-6

OIL PAN

C 3




Ref. No.	Part No.	Description	Reqd. QTY		Serial No.	Parts catalogue code
			GCV	LA		
21	91231-891-003	OIL SEAL, 6X11X4	1	-----	N7A1,N7S1	
22	91303-KF0-003	O-RING, 14.8X2.4 (ARAI)	1	-----	BHH,E1A2,N7A1,N7S1,R3A,S1M,S3A,S3H	
23	94101-06800	WASHER, PLAIN, 6MM	1	-----		
24	94109-12000	WASHER, DRAIN PLUG, 12MM	1	-----	N1A,N1AF,N5AF,N5MF	
25	94251-08000	PIN, LOCK, 8MM	1	-----		
26	94301-08200	DOWEL PIN, 8X20	2	-----		

2

E-7

CRANKSHAFT

C 4



Service item

F.R.T.

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			GCV 160 LA		
1	13310-ZM0-000	CRANKSHAFT COMP.	1	-----	A1A,A1AF,E1A2,N1A,N1AF,S1A,S1M
2	13310-ZM0-600	CRANKSHAFT COMP.	1	-----	A2R
3	13310-ZM0-610	CRANKSHAFT COMP.	1	-----	R3A,S3A,S3H
4	13310-ZM0-640	CRANKSHAFT COMP.	1	-----	BHH
5	13310-ZOL-650	CRANKSHAFT COMP.	1	-----	N5AF,N5MF,N5R
6	13310-ZOL-780	CRANKSHAFT COMP.	1	-----	N7A1,N7S1
7	90402-ZL8-000	WASHER, THRUST	1		

C 5




F.R.T.

2006.12.08

E-10

CAMSHAFT PULLEY

C 6



Service item


F.R.T.

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			GCV 160 LA		
1	14320-ZL8-010	PULLEY COMP., CAMSHAFT	1		
2	14324-ZL8-000	SHAFT, CAM PULLEY	1		
3	14400-Z0J-014	BELT, TIMING (84HU7 G-200) ..	1		
4	14431-Z0J-000	ARM, IN. VALVE ROCKER	1		
5	14441-Z0J-000	ARM, EX. VALVE ROCKER	1		
6	14461-ZL8-000	SHAFT, ROCKER ARM	2		
7	90012-333-000	SCREW, TAPPET ADJUSTING	2		
8	90206-001-000	NUT, TAPPET ADJUSTING	2		
9	91301-ZM0-V31	O-RING, 6.8X1.9(ARAI)	1		

E-11

RECOIL STARTER

C 7



Service item

F.R.T.


Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			GCV 160 LA		
1	28400-ZL8-023ZA	STARTER ASSY., RECOIL	1	-----	N1AF,N5AF,N5MF,N7A1,N7S1
		NH1.....BLACK	1	-----	N5R
	28400-ZL8-023ZC	*R280*.....POWER RED	1	-----	
2	28400-ZL8-023ZA	STARTER ASSY., RECOIL	1	-----	A2R,N1A
		NH1.....BLACK	1	-----	
	28400-ZM0-633ZA	STARTER ASSY., RECOIL	1	-----	
		(LONG ROPE)	1	-----	A1A,A1AF,E1A2,R3A,S1A,S3H
		NH1.....BLACK	1	-----	R3A
	28400-ZM0-633ZC	*YR288R*.....WOLF ORANGE	1	-----	E1A2,R3A
	28400-ZM0-633ZD	*R280*.....POWER RED	1	-----	S1M,S3H
	28400-ZM0-633ZE	*T98*.....MTD RED	1	-----	BHH,S3A
	28400-ZOL-V20ZA	*NH1*.....BLACK	1	-----	S3A
	28400-ZOL-V20ZC	*T98*.....MTD RED	1	-----	
3	28461-ZL8-003	GRIP, STARTER	1	-----	
4	28462-ZL8-003	ROPE, RECOIL STARTER	1	-----	A2R,N1A,N1AF,N5AF,N5MF,N5R,N7A1,N7S1
	28462-ZL8-631	ROPE, RECOIL STARTER	1	-----	
		(LONG TYPE)	1	-----	A1A,A1AF,E1A2,R3A,S1A,S1M,S3H
	28462-ZOL-V20	ROPE, RECOIL STARTER (BLACK)	1	-----	BHH,S3A
		(LONG TYPE)	1	-----	
5	90201-ZM0-000	NUT, FLANGE, 6MM	3	-----	

2

E-12

FAN COVER

C 8



Service item

F.R.T.

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			GCV 160 LA		
1	16700-ZOM-782	PUMP ASSY., FUEL	1	-----	N7A1,N7S1
2	16711-ZOL-781	STAY, FUEL PUMP	1	-----	N7A1,N7S1
3	16854-ZH8-000	RUBBER, SUPPORTER (107MM) ..	1	-----	
4	16882-ZOL-780	TUBE, DIAPHRAGM	1	-----	N7A1,N7S1
5	16950-ZMO-003	COCK ASSY., FUEL	1	-----	
6	16952-ZA8-800	STRAINER, FUEL	1	-----	
7	17511-ZOL-000	TANK, FUEL	1	-----	
8	17514-ZOL-000	SEAL, FUEL FILLER NECK	1	-----	
9	17516-ZOL-000	CLIP, TANK MOUNTING	1	-----	
10	17532-ZOL-000	RUBBER A, TANK MOUNTING	1	-----	
11	17533-ZOL-000	RUBBER B, TANK MOUNTING	1	-----	
12	17534-ZOL-000	NUT, TANK MOUNTING	1	-----	
13	17620-ZOJ-800	CAP ASSY., FUEL TANK	1	-----	
14	17636-ZOL-000	GAUGE, FUEL LEVEL	1	-----	
15	17701-ZOL-780	TUBE, FUEL TANK	1	-----	N7A1,N7S1
16	17701-ZOL-810	TUBE, FUEL TANK	1	-----	A1A,A1AF,A2R,BHH,E1A2,N1A,N1AF,N5AF,N5MF,N5R,R3A,S1A,S1M,S3A,S3H
17	17702-ZMO-800	TUBE, FUEL	1	-----	
18	17703-ZOL-790	TUBE B, FUEL	1	-----	N7A1,N7S1
19	19610-ZOL-850ZA	COVER COMP., FAN	1	-----	
	NH1.....BLACK		1	-----	A1A,A1AF,A2R,BHH,N1A,N1AF,N5AF,N5MF,N7A1,N7S1,S3H
	19610-ZOL-850ZB	*T89*.....CRAFTSMAN RED	1	-----	BHH
	19610-ZOL-850ZC	*T93*.....HUSQVARNA GRAY	1	-----	BHH
	19610-ZOL-850ZD	*T98*.....MTD RED	1	-----	S1M,S3H
	19610-ZOL-850ZE	*R280*.....POWER RED	1	-----	N5R
	19610-ZOL-860ZA	*NH1*.....BLACK	1	-----	S1A,S3A
	19610-ZOL-860ZC	*T89*.....CRAFTSMAN RED	1	-----	S3A

E-12**FAN COVER****C 9**


Ref. No.	Part No.	Description	Reqd. QTY GCV 160 LA	Serial No.	Parts catalogue code
19)	19610-ZOL-860ZD	COVER COMP., FAN			
		T93.....HUSQVARNA GRAY	1	-----	S3A
	19610-ZOL-860ZE	*T98*.....MTD RED	1	-----	S3A
	19610-ZOL-870ZA	*NH1*.....BLACK	1	-----	E1A2
	19610-ZOL-870ZB	*R280*.....POWER RED	1	-----	E1A2
	19610-ZOL-880ZA	*NH1*.....BLACK	1	-----	R3A
	19610-ZOL-880ZB	*R280*.....POWER RED	1	-----	R3A
	19610-ZOL-880ZC	*T89*.....CRAFTSMAN RED	1	-----	R3A
	19610-ZOL-880ZD	*T90*.....EHP ORANGE	1	-----	R3A
	19610-ZOL-880ZE	*Y166R*.....WOLF YELLOW	1	-----	R3A
20	19619-ZL8-300	COLLAR, FAN COVER	3		
21	33609-GK4-620	COLLAR, FR. WINKER	1	-----	A1A,A2R,BHH,N1A,N7A1,N7S1
	91501-ZOL-800	COLLAR, FUEL COCK	1	-----	A1AF,E1A2,N1AF,N5AF,N5MF,N5R,R3A,S1A,S1M,S3A,S3H
22	90041-ZOM-780	BOLT, STUD	1	-----	N7A1,N7S1
23	90043-ZL8-000	BOLT, STUD	3		
24	90601-ZOM-003	CLIP, PURSE LOCK	1	-----	N7A1,N7S1
25	90659-680-013	CLIP, WIRE HARNESS	1	-----	N7A1,N7S1
26	93891-05010-08	SCREW-WASHER, 5X10	1		
27	93894-05014-00	SCREW-WASHER, 5X14	2	-----	N7A1,N7S1
28	94050-06000	NUT, FLANGE, 6MM	1	-----	N7A1,N7S1
29	95002-02080	CLIP, TUBE (B8)	2		
30	95002-02100	CLIP, TUBE (B10)	1	-----	A1A,A1AF,A2R,BHH,E1A2,N1A,N1AF,N5AF,N5MF,N5R,R3A,S1A,S1M,S3A,S3H
			3	-----	N7A1,N7S1
31	95002-45000	CLIP, TUBE (C8)	1	-----	N7A1,N7S1
32	95002-50000	CLIP, TUBE (C9)	1	-----	N7A1,N7S1
33	95002-70000	CLIP, TUBE (C11)	1		
34	95003-25021-20	TUBE, VINYL, 9X11X210 (95003-25001-10M)	1	-----	N7A1,N7S1
35	95003-43009-20	TUBE, VINYL, 13X15X90 (95003-43001-10M)	1	-----	N7A1,N7S1

2

E-14

CARBURETOR

C10



Service item


F.R.T.

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			GCV 160 LA		
1	16010-883-015	PACKING SET	1		
2	16013-ZL1-003	FLOAT SET	1		
3	16015-887-782	CHAMBER SET, FLOAT	1		
4	16016-ZG0-W00	SCREW SET	1	-----	A1A,A2R,BHH,E1A2,N1A,N7A1,N7S1
5	16024-ZE1-811	SCREW SET, DRAIN	1		
6	16028-ZE0-005	SCREW SET	1		
7	16029-ZG0-901	SCREW SET (THROTTLE STOP) ...	1	-----	A1A,A2R,BHH,E1A2,N1A,N7A1,N7S1
8	16100-ZOL-003	CARBURETOR ASSY. (BB62W A) ..	1	-----	A1A,A2R,BHH,E1A2,N1A
	16100-ZOL-851	CARBURETOR ASSY. (BB62Z A) ..	1	-----	R3A,S1A,S3A
	16100-ZOL-861	CARBURETOR ASSY. (BB65A A) ..	1	-----	A1AF,N1AF,N5AF,N5MF,N5R
	16100-ZOL-871	CARBURETOR ASSY. (BB65E A) ..	1	-----	S1M,S3H
	16100-Z1L-003	CARBURETOR ASSY. (BB62Y A) ..	1	-----	N7A1,N7S1
9	16155-ZM0-013	VALVE, FLOAT	1		
10	16166-ZM0-003	NOZZLE, MAIN	1	-----	A1A,A1AF,A2R,BHH,E1A2,N1A,N1AF,N5AF,N5MF,N5R,N7A1,N7S1,R3A,S1A,S3A
	16166-ZOL-841		1	-----	S1M,S3H
12	16210-ZOM-780	INSULATOR COMP., CARBURETOR ..	1	-----	N7A1,N7S1
13	16211-ZL8-000	INSULATOR, CARBURETOR	1	-----	A1A,A1AF,A2R,BHH,E1A2,N1A,N1AF,N5AF,N5MF,N5R,R3A,S1A,S3A
14	16212-ZL8-000	PACKING, INSULATOR	1		
15	16221-883-800	PACKING, CARBURETOR	2		
16	16228-ZL8-000	PACKING, CARBURETOR	1	-----	A1A,A1AF,A2R,BHH,E1A2,N1A,N1AF,N5AF,N5MF,N5R,N7A1,N7S1,R3A,S1A,S3A
	16228-ZOL-840	PACKING, CARBURETOR (CHOKE SIDE)	1	-----	S1M,S3H
18	16600-ZOL-840	CONTROL ASSY., CHOKE	1	-----	S1M,S3H
19	19650-ZM0-000	GUIDE COMP., AIR	1		
20	93500-05006-1H	SCREW, PAN, 5X6	1		

E-14

CARBURETOR

C11




Ref. No.	Part No.	Description	Reqd. QTY		Serial No.	Parts catalogue code
			GCV	LA		
22	99101-124-0600	JET, MAIN, #60	(1)	-----	-----	A1A,A1AF,A2R,BHH,E1A2,N1A,N1AF,N5AF,N5MF,N5R,N7A1,N7S1,R3A,S1A,S3A
	99101-124-0620	JET, MAIN, #62	(1)	-----	-----	A1A,A1AF,A2R,BHH,E1A2,N1A,N1AF,N5AF,N5MF,N5R,N7A1,N7S1,R3A,S1A,S3A
	99101-124-0650	JET, MAIN, #65	1	-----	-----	A1A,A1AF,A2R,BHH,E1A2,N1A,N1AF,N5AF,N5MF,N5R,N7A1,N7S1,R3A,S1A,S3A
			(1)	-----	-----	S1M,S3H
	99101-124-0680	JET, MAIN, #68	(1)	-----	-----	S1M,S3H
	99101-124-0700	JET, MAIN, #70	1	-----	-----	S1M,S3H

2

E-15

AIR CLEANER

C12



Service item

F.R.T.


Ref. No.	Part No.	Description	Reqd. QTY		Serial No.	Parts catalogue code
			GCV	160		
1	15721-ZM0-000	TUBE, BREATHER	1			
2	17211-ZL8-023	ELEMENT, AIR CLEANER	1			
3	17220-ZM0-000	CASE ASSY., AIR CLEANER	1			
4	17228-ZM0-000	PACKING, AIR CLEANER	1			
5	17231-Z0L-030	COVER, AIR CLEANER	1			
6	90003-ZM0-000	BOLT, FLANGE, 6X86(CT200) ...	2			
7	95701-06014-08	BOLT, FLANGE, 6X14	1			

2

E-16

MUFFLER

C13



Service item

F.R.T.


Ref. No.	Part No.	Description	Reqd. QTY		Serial No.	Parts catalogue code
			GCV 160 LA			
1	06180-Z0J-000	ARRESTER KIT, SPARK	(1)			
2	18310-ZM0-000	MUFFLER COMP.	1	-----	-----	A1AF,A2R,BHH,E1A2,N1A,N1AF,N5AF,N5MF,N7A1,N7S1,R3A,S1A,S1M,S3A
	18310-Z0Y-000		1	-----	-----	A1A,N5R,S3H
3	18320-Z0M-780	PROTECTOR COMP., MUFFLER ...	1	-----	-----	N7A1,N7S1
	18321-Z0L-J00	PROTECTOR, MUFFLER	1	-----	-----	BHH,R3A,S1M,S3A,S3H
	18321-Z0L-000		1	-----	-----	A1A,A1AF,A2R,E1A2,N1A,N1AF,N5AF,N5MF,N5R,S1A
4	18348-Z0L-000	CAP, MUFFLER	1	-----	-----	N5MF
5	18350-ZL8-000	ARRESTER COMP., SPARK	(1)			
6	18356-ZL8-000	PLATE, ARRESTER NUMBER	(1)			
7	18381-ZL8-305	GASKET, MUFFLER	(1)			
8	90004-ZL8-000	BOLT, FLANGE, 6X79(CT200) ...	2			
9	90013-883-000	BOLT, FLANGE, 6X12(CT200) ...	3			
10	90055-ZE1-000	SCREW, TAPPING, 4X6	2	-----	-----	N5MF
11	90055-ZE1-000	SCREW, TAPPING, 4X6	(1)			

2

E-19

FLYWHEEL

C14



Service item


F.R.T.

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			GCV 160 LA		
1	11344-MB0-000	GROMMET A, RR. COVER (8X16X6.6)	1	-----	S1A,S3A
2	13331-357-000	KEY, SPECIAL WOODRUFF, 25X18	1	-----	
3	19612-ZOL-000	PLATE, SIDE	1	-----	A2R,BHH,N1A,N1AF,N5AF,N5MF,N5R,N7A1,N7S1
4	30500-ZL8-004	COIL ASSY., IGNITION (TEC) (USE FOR F/W OF TEC)	1	-----	A1A,A1AF,N7A1,N7S1,S1A,S1M,S3A,S3H
	30500-ZOJ-003	COIL ASSY., IGNITION (PHELON) (USE FOR F/W OF PHELON)	1	-----	A2R,BHH,E1A2,N1A,N1AF,N5AF,N5MF,N5R,R3A
5	31105-ZM0-000	FLYWHEEL ASSY. (TEC) (USE FOR IGN. COIL OF TEC)	1	-----	A1A,A1AF,N7A1,N7S1,S1A,S1M,S3A,S3H
	31105-ZOJ-010	FLYWHEEL ASSY. (PHELON) (USE FOR IGN. COIL OF PHELON)	1	-----	BHH
6	31105-ZOL-821	FLYWHEEL ASSY. (PHELON) (USE FOR IGN. COIL OF PHELON)	1	-----	E1A2,R3A
7	31110-ZOJ-013	FLYWHEEL COMP. (PHELON) (USE FOR IGN. COIL OF PHELON)	1	-----	A2R,N1A,N1AF,N5AF,N5MF,N5R
8	32195-ZM0-800	CORD, STOP SWITCH	1	-----	A2R,BHH,N1A,N7A1,N7S1
9	32195-ZM0-800	CORD, STOP SWITCH	1	-----	S1A,S3A
	32195-ZOL-000		1	-----	A1A,A1AF,S1M,S3H
10	35120-ZM0-003	SWITCH ASSY., ENGINE STOP (N.C)	1	-----	A1A,A1AF,S1A,S1M,S3A,S3H
11	51125-ZOL-003	HOLDER, WIRE (FASTEX)	1	-----	A1A,A1AF,A2R,BHH,N1A,N5R,N7A1,N7S1,S1A,S1M,S3A,S3H
	90681-959-003	CLIP A, CABLE (NIFCO)	1	-----	A1A,A1AF,A2R,BHH,N1A,N5R,N7A1,N7S1,S1A,S1M,S3A,S3H
12	75100-ZM0-000	BRAKE ASSY.	1	-----	A1A,A1AF,S1M,S3H
13	75110-ZOL-800	BRAKE SUB ASSY.	1	-----	S1A,S3A
14	75110-ZOL-821	BRAKE SUB ASSY.	1	-----	E1A2,R3A
15	75113-ZM0-000	SPRING, BRAKE LEVER	1	-----	A1A,A1AF,E1A2,R3A,S1A,S1M,S3A,S3H

E-19

FLYWHEEL

C15



Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			GCV 160 LA		
16	90002-ZOL-820	BOLT, FLANGE, 6X23(CT200) ...	1	-----	E1A2,R3A
	90018-ZE1-000		1	-----	A1A,A1AF,S1A,S1M,S3A,S3H
17	90013-883-000	BOLT, FLANGE, 6X12(CT200) ...	2	-----	A2R,BHH,N1A,N1AF,N5AF,N5MF,N5R,N7A1,N7S1
18	90014-952-000	BOLT, FLANGE, 6X14(CT200) ...	1	-----	A1A,A1AF,E1A2,R3A,S1A,S1M,S3A,S3H
19	90022-888-010	BOLT, FLANGE, 6X20(CT200) ...	1		
20	90201-878-003	NUT, SPECIAL, 14MM	1		
21	93892-04012-00	SCREW-WASHER, 4X12	1	-----	A1A,A1AF,S1A,S1M,S3A,S3H
22	94103-04000	WASHER, PLAIN, 4MM	1	-----	A1A,A1AF,S1A,S1M,S3A,S3H

2


E-21

STARTER MOTOR

C16

Service item

F.R.T.




Ref. No.	Part No.	Description	Reqd. QTY		Serial No.	Parts catalogue code
			GCV	160		
1	22534-ZOL-820	HOLDER, WIRE	1	-----	-----	E1A2,R3A
2	30549-ZOL-820	CLAMPER, CORD	1	-----	-----	E1A2,R3A
3	31200-ZOL-821	MOTOR ASSY., STARTER	1	-----	-----	E1A2,R3A
4	32222-ZOL-820	CORD, TERMINAL EARTH	1	-----	-----	E1A2,R3A
5	51125-ZOL-003	HOLDER, WIRE (FASTEX)	1	-----	-----	E1A2
	90681-959-003	CLIP A, CABLE (NIFCO)	1	-----	-----	E1A2,R3A
6	90001-ZOL-820	BOLT, SPECIAL, 6MM	2	-----	-----	E1A2,R3A
7	90013-883-000	BOLT, FLANGE, 6X12(CT200) ...	3	-----	-----	E1A2,R3A
8	93500-05008-0A	SCREW, PAN, 5X8	1	-----	-----	E1A2,R3A

E-22

CONTROL(1)

D 1



Service item

F.R.T.

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			GCV 160 LA		
1	16551-ZM0-010	ARM, GOVERNOR	1	-----	A1A,BHH,N7A1,N7S1
2	16555-ZOL-800	ROD, GOVERNOR	1	-----	A1A,BHH,N7A1,N7S1
3	16561-ZM0-V30	SPRING, GOVERNOR	1	-----	N7A1,N7S1
	16561-ZOL-000		1	-----	A1A,BHH
4	16562-ZM0-000	SPRING, THROTTLE RETURN	1	-----	A1A,BHH,N7A1,N7S1
5	16576-ZE7-300	SPRING, LEVER	1	-----	A1A,BHH
6	16580-ZM0-J22	BASE COMP., CONTROL	1	-----	BHH
	16580-ZM0-020		1	-----	A1A
7	16580-ZOM-780	BASE COMP., CONTROL	1	-----	N7A1,N7S1
8	16584-883-300	SPRING, CONTROL ADJUSTING	1	-----	N7A1,N7S1
9	16593-ZM0-000	SPRING, CONTROL LEVER RETURN	1	-----	BHH
10	16599-ZG1-M10	COLLAR, STOPPER	1	-----	N7A1,N7S1
11	16617-VG3-000	HOLDER, CABLE	1	-----	A1A,N7A1,N7S1
12	16617-ZOL-800	HOLDER, CABLE	1	-----	BHH
13	16674-ZM0-000	ROD, CHOKE	1	-----	A1A,BHH,N7A1,N7S1
14	35120-ZL8-003	SWITCH ASSY., ENGINE STOP (N.O.)	1	-----	BHH,N7A1,N7S1
15	90015-ZE5-010	BOLT, GOVERNOR ARM	1	-----	A1A,BHH,N7A1,N7S1
16	90016-ZE7-W00	SCREW, RECESSED, 5X28	1	-----	N7A1,N7S1
17	90016-ZM0-000	BOLT, FLANGE, 6X45(CT200) ...	1	-----	A1A,BHH,N7A1,N7S1
18	93500-05008-0A	SCREW, PAN, 5X8	1	-----	BHH
19	93500-05016-0A	SCREW, PAN, 5X16	1	-----	A1A,N7A1,N7S1
20	93892-04012-00	SCREW-WASHER, 4X12	1	-----	BHH,N7A1,N7S1
21	94050-06000	NUT, FLANGE, 6MM	1	-----	A1A,BHH,N7A1,N7S1
22	94103-04000	WASHER, PLAIN, 4MM	1	-----	BHH,N7A1,N7S1

2


E-22-1

CONTROL(2)

D 2

Service item

F.R.T.




Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			GCV 160 LA		
1	16551-ZM0-010	ARM, GOVERNOR	1	-----	A2R,N1A
2	16555-ZOL-800	ROD, GOVERNOR	1	-----	A2R,N1A
3	16561-ZM0-V30	SPRING, GOVERNOR	1	-----	A2R,N1A
4	16562-ZM0-000	SPRING, THROTTLE RETURN	1	-----	A2R,N1A
5	16574-ZE1-000	SPRING, LEVER	1	-----	A2R,N1A
6	16575-ZE2-W00	WASHER, CONTROL LEVER	1	-----	A2R,N1A
7	16577-ZM0-V30	PLATE, LEVER CENTER	1	-----	A2R,N1A
8	16578-ZE1-000	SPACER, CONTROL LEVER	1	-----	A2R,N1A
9	16580-ZM0-V30	BASE COMP., CONTROL (###) ...	1	-----	A2R,N1A
10	16612-ZM0-V30	LEVER, CHOKE (###)	1	-----	A2R,N1A
11	16617-VG3-000	HOLDER, CABLE	1	-----	N1A
12	16674-ZM0-V30	ROD, CHOKE	1	-----	A2R,N1A
13	35120-ZL8-003	SWITCH ASSY., ENGINE STOP (N.O)	1	-----	A2R,N1A
14	87532-ZM0-V30	MARK, THROTTLE INDICATION ...	1	-----	A2R,N1A
15	90015-ZE5-010	BOLT, GOVERNOR ARM	1	-----	A2R,N1A
16	90016-ZM0-V30	BOLT, SPECIAL, 6X45	1	-----	A2R,N1A
17	90017-883-000	BOLT, FLANGE, 6X32	1	-----	A2R,N1A
18	90114-SAO-000	NUT, SELF-LOCK, 6MM	1	-----	A2R,N1A
19	90136-SM4-901	NUT, SELF-LOCK, 5MM	1	-----	A2R,N1A
20	93500-05016-0A	SCREW, PAN, 5X16	1	-----	N1A
21	93892-04012-00	SCREW-WASHER, 4X12	1	-----	A2R,N1A
22	94050-06000	NUT, FLANGE, 6MM	1	-----	A2R,N1A
23	94103-04000	WASHER, PLAIN, 4MM	1	-----	A2R,N1A

E-22-2

CONTROL(3)

D 3



Service item

F.R.T.

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			GCV 160 LA		
1	16551-ZM0-010	ARM, GOVERNOR	1	-----	A1AF,E1A2,N1AF,N5AF,N5MF,N5R,R3A,S1A,S1M,S3A,S3H
2	16555-ZOL-800	ROD, GOVERNOR	1	-----	A1AF,E1A2,N1AF,N5AF,N5MF,N5R,R3A,S1A,S1M,S3A,S3H
3	16561-ZM0-V30	SPRING, GOVERNOR	1	-----	N1AF,N5AF,N5MF,N5R
	16561-ZM0-000		1	-----	E1A2
	16561-ZOL-000		1	-----	A1AF,R3A,S1A,S1M,S3A,S3H
4	16562-ZM0-000	SPRING, THROTTLE RETURN	1	-----	A1AF,E1A2,N1AF,N5AF,N5MF,N5R,R3A,S1A,S1M,S3A,S3H
5	16578-ZOL-810	SPACER, CONTROL LEVER	1	-----	A1AF,E1A2
6	16580-ZOL-800	BASE COMP., CONTROL	1	-----	N1AF,N5AF,N5MF,N5R
	16580-ZOL-810		1	-----	A1AF,E1A2,R3A,S1A,S1M,S3A,S3H
7	16612-ZOL-810	LEVER, CHOKE	1	-----	A1AF,E1A2
8	16613-893-000	GROMMET, CHOKE ROD	1	-----	A1AF,E1A2
			2	-----	N1AF,N5AF,N5MF,N5R
9	16674-ZOL-800	ROD, CHOKE	1	-----	N1AF,N5AF,N5MF,N5R
10	16674-ZOL-810	ROD, CHOKE	1	-----	A1AF,E1A2
11	35120-ZOL-801	SWITCH ASSY., ENGINE STOP ...	1	-----	N1AF,N5AF,N5MF,N5R
12	51125-ZOL-003	HOLDER, WIRE (FASTEX)	1	-----	N1AF,N5AF,N5MF,N5R
	90681-959-003	CLIP A, CABLE (NIFCO)	1	-----	N1AF,N5AF,N5MF,N5R
13	90015-ZE5-010	BOLT, GOVERNOR ARM	1	-----	A1AF,E1A2,N1AF,N5AF,N5MF,N5R,R3A,S1A,S1M,S3A,S3H
14	90016-ZE8-000	BOLT, FLANGE, 6X45(CT200) ...	1	-----	A1AF,E1A2,N1AF,N5AF,N5MF,N5R,R3A,S1A,S1M,S3A,S3H
15	94050-06000	NUT, FLANGE, 6MM	1	-----	A1AF,E1A2,N1AF,N5AF,N5MF,N5R,R3A,S1A,S1M,S3A,S3H
16	94511-14000	CIRCLIP, EXTERNAL, 14MM	1	-----	A1AF,E1A2

2


E-22-3

CHOKE BASE

D 4

Service item

F.R.T.



Z880E2203

Ref. No.	Part No.	Description	Reqd. QTY		Serial No.	Parts catalogue code
			GCV	160		
1	16592-Z2D-800	SPRING, RETURN	1	-----	-----	R3A,S1A,S3A
2	16610-Z2D-801	LEVER ASSY., CHOKE	1	-----	-----	R3A,S1A,S3A
3	16614-Z2D-800	SPRING, CHOKE LEVER	1	-----	-----	R3A,S1A,S3A
4	16632-Z0L-800	ROD, STOP	1	-----	-----	R3A,S1A,S3A
5	90022-888-010	BOLT, FLANGE, 6X20(CT200) ...	1	-----	-----	R3A,S1A,S3A


E-28

LABEL

D 5

Service item

F.R.T.




Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			GCV 160 LA		
1	87101-ZM0-010	MARK, EMBLEM (GCV160 5.5) ...	1	-----	A1AF,A2R,E1A2,N1A,N1AF,N5AF,N5MF,S1A
	87101-ZM0-020		1	-----	A1A
2	87101-ZOL-780	MARK, EMBLEM (GCV160)	1	-----	N7A1,N7S1
3	87114-ZH7-821	LABEL, WARNING	1	-----	
		(NOT CERTIFIED FOR SALE)	1	-----	A1A,A1AF,A2R,BHH,E1A2,N1A,N1AF,N5AF,N5MF,N5R,N7A1,R3A,S1A,S1M,S3A,S3H
	87114-Z3E-000		1	-----	N7S1
4	87528-ZL8-000	MARK, CHOKE	1	-----	N1AF,N5AF,N5MF,N5R
5	87528-ZOL-V20	MARK, CHOKE INDICATION	1	-----	R3A,S3A
	87528-ZOL-800		1	-----	S1A

2

E-40

BLADE HOLDER

D 6



Service item

F.R.T.

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			GCV 160 LA		
1	72600-VE1-G00	HOLDER ASSY., BLADE	1	-----	BHH
2	75110-Z0L-000	PLATE ASSY., BALL CONTROL ...	1	-----	BHH
3	75111-VE1-G01	PLATE, BALL CONTROL	1	-----	BHH
4	75117-VE1-G00	BALL, STEEL	3	-----	BHH
5	75127-VE1-G00	PLATE, SPRING HOOK	1	-----	BHH
6	75130-Z0L-000	PLATE COMP., BRAKE	1	-----	BHH
7	75132-VE1-G00	SPRING, BALL PLATE	1	-----	BHH
8	75141-VE1-G00	DISK, DRIVE	1	-----	BHH
9	75150-VE1-G02	DISK COMP., DRIVEN	1	-----	BHH
10	75162-Z0L-000	PULLEY, DRIVE	1	-----	BHH
11	75183-VE1-G01	SPRING, CLUTCH	1	-----	BHH
12	90101-VE1-G00	BOLT, FLANGE, 10X24	1	-----	BHH
13	91051-VE1-R00	BEARING, RADIAL BALL, 6006	1	-----	BHH
		(TSB)			
14	91052-VE1-G00	BEARING, RADIAL BALL, 6204 ..	1	-----	BHH
15	94401-16150	KEY, WOODRUFF, 16X15	1	-----	BHH

PART NO. INDEX

E 1

Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.
06000				16000				16593-ZM0-000	D1	27	9	19610-ZOL-850ZD	C8	18	19	33000			
06180-Z0J-000	C13	23	1	16010-883-015	C10	20	1	16599-ZG1-M10	D1	27	10	19610-ZOL-850ZE	C8	18	19	33609-GK4-620	C9	19	21
11000				16013-ZL1-003	C10	20	2	16600-ZOL-840	C10	20	18	19610-ZOL-860ZA	C8	18	19	35000			
11300-ZOL-405	C2	12	1	16015-887-782	C10	20	3	16610-Z2D-801	D4	30	2	19610-ZOL-860ZC	C8	18	19	35120-ZOL-801	D3	29	11
11300-ZOM-405	C2	12	1	16016-ZG0-W00	C10	20	4	16612-ZOL-810	D3	29	7	19610-ZOL-860ZD	C9	19	19	35120-ZL8-003	D1	27	14
11300-ZM0-405	C2	12	1	16024-ZE1-811	C10	20	5	16612-ZM0-V30	D2	28	10	19610-ZOL-860ZE	C9	19	19	35120-ZM0-003	D2	28	13
11300-ZM0-407	C2	12	1	16028-ZE0-005	C10	20	6	16613-893-000	D3	29	8	19610-ZOL-870ZA	C9	19	19	35120-ZM0-003	C14	24	10
11344-MB0-000	C14	24	1	16029-ZG0-901	C10	20	7	16614-Z2D-800	D4	30	3	19610-ZOL-870ZB	C9	19	19	51000			
12000				16100-ZOL-003	C10	20	8	16617-VG3-000	D1	27	11	19610-ZOL-880ZA	C9	19	19	51125-ZOL-003	C14	24	11
12000-ZOL-405	C1	11	2	16100-ZOL-851	C10	20	8	16617-ZOL-800	D1	27	12	19610-ZOL-880ZB	C9	19	19	51125-ZOL-003	C16	26	5
12000-ZOL-406	C1	11	2	16100-ZOL-861	C10	20	8	16632-ZOL-800	D4	30	4	19610-ZOL-880ZC	C9	19	19	51125-ZOL-003	D3	29	12
12000-ZL8-425	C1	11	1	16100-ZOL-871	C10	20	8	16674-ZOL-800	D3	29	9	19610-ZOL-880ZE	C9	19	19	72000			
12209-ZM0-003	C1	11	3	16100-Z1L-003	C10	20	8	16674-ZOL-810	D3	29	10	19612-ZOL-000	C14	24	3	72600-VE1-G00	D6	32	1
12311-ZL8-000	C1	11	4	16155-ZM0-013	C10	20	9	16674-ZM0-000	D1	27	13	19619-ZL8-300	C9	19	20	75000			
12355-ZL8-000	C1	11	5	16166-ZOL-841	C10	20	10	16674-ZM0-V30	D2	28	12	19650-ZM0-000	C10	20	19	75100-ZM0-000	C14	24	12
13000				16166-ZM0-003	C10	20	10	16700-ZOM-782	C8	18	1	22000				75110-ZOL-000	D6	32	2
13010-ZOL-014	C5	15	1	16210-ZOM-780	C10	20	12	16711-ZOL-781	C8	18	2	22534-ZOL-820	C16	26	1	75110-ZOL-800	C14	24	13
13101-Z2A-010	C5	15	2	16211-ZL8-000	C10	20	13	16854-ZH8-000	C8	18	3	28000				75110-ZOL-821	C14	24	14
13111-ZE0-000	C5	15	3	16212-ZL8-000	C10	20	14	16882-ZOL-780	C8	18	4	28400-ZOL-V20ZA	C7	17	2	75111-VE1-G01	D6	32	3
13200-Z0J-000	C5	15	4	16221-883-800	C10	20	15	16950-ZM0-003	C8	18	5	28400-ZOL-V20ZC	C7	17	2	75113-ZM0-000	C14	24	15
13310-ZOL-650	C4	14	5	16228-ZOL-840	C10	20	16	16952-ZA8-800	C8	18	6	28400-ZL8-023ZA	C7	17	1	75117-VE1-G00	D6	32	4
13310-ZOL-780	C4	14	6	16228-ZL8-000	C10	20	16	17000				28400-ZL8-023ZC	C7	17	1	75127-VE1-G00	D6	32	5
13310-ZM0-000	C4	14	1	16508-ZM0-010	C2	12	8	17211-ZL8-023	C12	22	2	28400-ZM0-633ZA	C7	17	2	75130-ZOL-000	D6	32	6
13310-ZM0-600	C4	14	2	16510-ZM0-010	C2	12	9	17220-ZM0-000	C12	22	3	28400-ZM0-633ZC	C7	17	2	75132-VE1-G00	D6	32	7
13310-ZM0-610	C4	14	3	16511-ZL8-000	C2	12	10	17228-ZM0-000	C12	22	4	28400-ZM0-633ZD	C7	17	2	75141-VE1-G00	D6	32	8
13310-ZM0-640	C4	14	4	16512-ZM0-000	C2	12	11	17231-ZOL-030	C12	22	5	28400-ZM0-633ZE	C7	17	2	75150-VE1-G02	D6	32	9
13331-357-000	C14	24	2	16513-ZE1-000	C2	12	12	17511-ZOL-000	C8	18	7	28461-ZL8-003	C7	17	3	75162-ZOL-000	D6	32	10
14000				16531-ZE1-000	C2	12	13	17514-ZOL-000	C8	18	8	28462-ZOL-V20	C7	17	4	75183-VE1-G01	D6	32	11
14320-ZL8-010	C6	16	1	16541-ZM0-000	C2	12	14	17516-ZOL-000	C8	18	9	30000				87000			
14324-ZL8-000	C6	16	2	16551-ZM0-010	D1	27	1	17532-ZOL-000	C8	18	10	30500-Z0J-003	C14	24	4	87101-ZOL-780	D5	31	2
14400-Z0J-014	C6	16	3	16555-ZOL-800	D1	27	2	17533-ZOL-000	C8	18	11	30500-ZL8-004	C14	24	4	87101-ZM0-010	D5	31	1
14431-Z0J-000	C6	16	4	16561-ZOL-000	D1	27	3	17534-ZOL-000	C8	18	12	30549-ZOL-820	C16	26	2	87101-ZM0-020	D5	31	1
14441-Z0J-000	C6	16	5	16561-ZM0-000	D3	29	3	17620-Z0J-800	C8	18	13	31000				87114-Z3E-000	D5	31	3
14461-ZL8-000	C6	16	6	16561-ZM0-V30	D1	27	3	17636-ZOL-000	C8	18	14	31105-Z0J-010	C14	24	5	87114-ZH7-821	D5	31	3
14711-Z0J-000	C1	11	6	16562-ZM0-000	D2	28	4	17701-ZOL-780	C8	18	15	31105-ZOL-821	C14	24	6	87528-ZOL-800	D5	31	5
14721-ZL8-000	C1	11	7	16574-ZE1-000	D2	28	5	17701-ZOL-810	C8	18	16	31105-ZM0-000	C14	24	5	87528-ZOL-V20	D5	31	5
14751-ZL8-000	C1	11	8	16575-ZE2-W00	D2	28	6	17703-ZOL-790	C8	18	17	31110-Z0J-013	C14	24	7	87528-ZL8-000	D5	31	4
14771-Z0J-000	C1	11	9	16576-ZE7-300	D1	27	5	18000				31200-ZOL-821	C16	26	3	87532-ZM0-V30	D2	28	14
15000				16577-ZM0-V30	D2	28	7	18310-Z0Y-000	C13	23	2	32000				90001-ZOL-820	C16	26	6
15625-Z2L-801	C2	12	3	16578-ZOL-810	D3	29	5	18310-ZM0-000	C13	23	2	32195-ZOL-000	C14	24	9	90001-ZE1-000	C5	15	5
15625-ZE6-000	C2	12	2	16578-ZE1-000	D2	28	8	18320-ZOM-780	C13	23	3	32195-ZM0-800	C14	24	8	90002-ZOL-820	C15	25	16
15631-ZOL-820	C2	12	4	16580-ZOL-800	D3	29	6	18321-ZOL-000	C13	23	3	32222-ZOL-820	C16	26	4	90003-ZM0-000	C12	22	6
15631-ZM0-000	C2	12	4	16580-ZOL-810	D3	29	6	18348-ZOL-000	C13	23	4					90004-ZL8-000	C13	23	8
15639-ZM0-000	C2	12	5	16580-ZOM-780	D1	27	7	18350-ZL8-000	C13	23	5					90012-333-000	C6	16	7
15650-ZOL-000	C2	12	7	16580-ZM0-020	D1	27	6	18356-ZL8-000	C13	23	6					90013-883-000	C1	11	10
15650-ZOL-820	C2	12	6	16580-ZM0-J22	D1	27	6	18381-ZL8-305	C13	23	7								
15650-ZM0-801	C2	12	6	16580-ZM0-V30	D2	28	9	19000											
15721-ZM0-000	C12	22	1	16584-883-300	D1	27	8	19610-ZOL-850ZA	C8	18	19								
				16592-Z2D-800	D4	30	1	19610-ZOL-850ZB	C8	18	19								
								19610-ZOL-850ZC	C8	18	19								

3

PART NO. INDEX

E 2

Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.
90013-883-000	C13	23	9	93892-04012-00	C15	25	21												
	C15	25	17		D1	27	20												
	C16	26	7		D2	28	21												
90014-952-000	C1	11	11	93894-05014-00	C9	19	27												
	C2	12	15																
	C15	25	18	94000															
90015-ZE5-010	D1	27	15																
	D2	28	15	94050-06000	C9	19	28												
	D3	29	13		D1	27	21												
90016-ZE7-W00	D1	27	16		D2	28	22												
90016-ZE8-000	D3	29	14		D3	29	15												
90016-ZM0-000	D1	27	17	94101-06800	C3	13	23												
90016-ZM0-V30	D2	28	16	94103-04000	C15	25	22												
90017-883-000	D2	28	17		D1	27	22												
90018-ZE1-000	C15	25	16		D2	28	23												
90022-888-010	C15	25	19	94109-12000	C3	13	24												
	D4	30	5	94251-08000	C3	13	25												
90041-ZOM-780	C9	19	22	94301-08200	C3	13	26												
90043-ZL8-000	C9	19	23	94401-16150	D6	32	15												
90055-ZE1-000	C13	23	10	94511-14000	D3	29	16												
			11																
90101-VE1-G00	D6	32	12	95000															
90114-SA0-000	D2	28	18																
90121-952-000	C2	12	16	95002-02080	C9	19	29												
90131-883-000	C2	12	17	95002-02100	C9	19	30												
90136-SM4-901	D2	28	19	95002-45000	C9	19	31												
90201-878-003	C15	25	20	95002-50000	C9	19	32												
90201-ZM0-000	C7	17	5	95002-70000	C9	19	33												
90206-001-000	C6	16	8	95003-25021-20	C9	19	34												
90402-ZL8-000	C4	14	7	95003-43009-20	C9	19	35												
90451-ZE1-000	C2	12	18	95701-06014-08	C12	22	7												
90551-ZE0-000	C5	15	6																
90601-ZOM-003	C9	19	24	98000															
90602-ZE1-000	C2	12	19																
90659-680-013	C9	19	25	98079-56846	C1	11	13												
90681-959-003	C14	24	11																
	C16	26	5	99000															
	D3	29	12																
91000				99101-124-0600	C11	21	22												
				99101-124-0620	C11	21	22												
				99101-124-0650	C11	21	22												
91051-VE1-R00	D6	32	13	99101-124-0680	C11	21	22												
91052-VE1-G00	D6	32	14	99101-124-0700	C11	21	22												
91201-ZL8-003	C1	11	12																
91202-ZL8-003	C2	12	20																
91202-ZM0-V31	C2	12	20																
91231-891-003	C3	13	21																
91301-ZM0-V31	C6	16	9																
91303-KF0-003	C3	13	22																
91501-ZOL-800	C9	19	21																
93000																			
93500-05006-1H	C10	20	20																
93500-05008-0A	C16	26	8																
	D1	27	18																
93500-05016-0A	D1	27	19																
	D2	28	20																
93891-05010-08	C9	19	26																

PART NAME INDEX

F 1

Part name	Address	Page	Ref.	Part name	Address	Page	Ref.	Part name	Address	Page	Ref.
[A]				CHAMBER SET, FLOAT	C10	20	3	GAUGE ASSY., OIL LEVEL	C2	12	6
ARM, EX. VALVE ROCKER	C6	16	5	CIRCLIP, EXTERNAL, 14MM	D3	29	16	GAUGE, FUEL LEVEL	C8	18	14
ARM, GOVERNOR	D1	27	1	CLAMPER, CORD	C16	26	2	GOVERNOR ASSY.	C2	12	9
	D2	28	1	CLIP A, CABLE	C14	24	11	GRIP, STARTER	C7	17	3
	D3	29	1		C16	26	5	GROMMET A, RR. COVER	C14	24	1
ARM, IN. VALVE ROCKER	C6	16	4		D3	29	12	GROMMET, CHOKE ROD	D3	29	8
ARRESTER COMP., SPARK	C13	23	5	CLIP, GOVERNOR HOLDER	C2	12	19	GUIDE COMP., AIR	C10	20	19
ARRESTER KIT, SPARK	C13	23	1	CLIP, PISTON PIN, 13MM	C5	15	6				
[B]				CLIP, PURSE LOCK	C9	19	24	[H]			
				CLIP, TANK MOUNTING	C8	18	9	HOLDER ASSY., BLADE	D6	32	1
				CLIP, TUBE	C9	19	29	HOLDER, CABLE	D1	27	11
BALL, STEEL	D6	32	4								
BARREL ASSY., CYLINDER	C1	11	1								
BASE COMP., CONTROL	D1	27	6	CLIP, WIRE HARNESS	C9	19	25	HOLDER, GOVERNOR WEIGHT	C2	12	11
				COCK ASSY., FUEL	C8	18	5	HOLDER, WIRE	C14	24	11
	D2	28	9	COIL ASSY., IGNITION	C14	24	4		C16	26	1
	D3	29	6	COLLAR, FAN COVER	C9	19	20				5
BEARING, RADIAL BALL, 6006 ...	D6	32	13	COLLAR, FR. WINKER	C9	19	21		D3	29	12
BEARING, RADIAL BALL, 6204 ...	D6	32	14	COLLAR, FUEL COCK	C9	19	21	[I]			
BELT, TIMING	C6	16	3	COLLAR, STOPPER	D1	27	10	INSULATOR COMP., CARBURETOR ...	C10	20	12
BOLT, CONNECTING ROD	C5	15	5	CONTROL ASSY., CHOKE	C10	20	18	INSULATOR, CARBURETOR	C10	20	13
BOLT, DRAIN PLUG, 12X15	C2	12	17	CORD, STOP SWITCH	C14	24	8				
BOLT, FLANGE, 10X24	D6	32	12								
BOLT, FLANGE, 6X12	C1	11	10	CORD, TERMINAL EARTH	C16	26	4	[J]			
	C13	23	9	COVER COMP., BREATHER	C1	11	5	JET, MAIN,	C11	21	22
	C15	25	17	COVER COMP., FAN	C8	18	19				
	C16	26	7		C9	19	19	[K]			
BOLT, FLANGE, 6X14	C1	11	11	COVER, AIR CLEANER	C12	22	5	KEY, SPECIAL WOODRUFF, 25X18 ..	C14	24	2
	C2	12	15	COVER, HEAD	C1	11	4	KEY, WOODRUFF, 16X15	D6	32	15
	C12	22	7	CRANKSHAFT COMP.	C4	14	1	[L]			
	C15	25	18					LABEL, WARNING	D5	31	3
BOLT, FLANGE, 6X20	C15	25	19					LEVER ASSY., CHOKE	D4	30	2
	D4	30	5					LEVER, CHOKE	D2	28	10
BOLT, FLANGE, 6X23	C15	25	16						D3	29	7
BOLT, FLANGE, 6X25	C2	12	16	[D]				[M]			
BOLT, FLANGE, 6X32	D2	28	17	DISK COMP., DRIVEN	D6	32	9	MARK, CHOKE	D5	31	4
BOLT, FLANGE, 6X45	D1	27	17	DISK, DRIVE	D6	32	8	MARK, CHOKE INDICATION	D5	31	5
	D3	29	14	DOWEL PIN, 8X20	C3	13	26	MARK, EMBLEM	D5	31	1
BOLT, FLANGE, 6X79	C13	23	8								2
BOLT, FLANGE, 6X86	C12	22	6	[E]				MARK, THROTTLE INDICATION	D2	28	14
BOLT, GOVERNOR ARM	D1	27	15	ELEMENT, AIR CLEANER	C12	22	2	MOTOR ASSY., STARTER	C16	26	3
	D2	28	15	EXTENSION, OIL FILLER	C2	12	4	MUFFLER COMP.	C13	23	2
	D3	29	13					[N]			
BOLT, SPECIAL, 6MM	C16	26	6	[F]				NOZZLE, MAIN	C10	20	10
BOLT, SPECIAL, 6X45	D2	28	16	FLOAT SET	C10	20	2	NUT, FLANGE, 6MM	C7	17	5
BOLT, STUD	C9	19	22	FLYWHEEL ASSY.	C14	24	5		C9	19	28
									D1	27	21
BRAKE ASSY.	C14	24	12	FLYWHEEL COMP.	C14	24	7		D2	28	22
BRAKE SUB ASSY.	C14	24	13					[G]			
			14	[G]				GASKET, MUFFLER	C13	23	7
[C]											
CAP ASSY., FUEL TANK	C8	18	13								
CAP, MUFFLER	C13	23	4								
CARBURETOR ASSY.	C10	20	8								
CASE ASSY., AIR CLEANER	C12	22	3								

PART NAME INDEX

F 2

Part name	Address	Page	Ref.	Part name	Address	Page	Ref.	Part name	Address	Page	Ref.
NUT, FLANGE, 6MM	D3	29	15	RUBBER, SUPPORTER	C8	18	3	TUBE B, FUEL	C8	18	18
NUT, SELF-LOCK, 5MM	D2	28	19	[S]				TUBE, BREATHER	C12	22	1
NUT, SELF-LOCK, 6MM	D2	28	18					TUBE, DIAPHRAGM	C8	18	4
NUT, SPECIAL, 14MM	C15	25	20					TUBE, FUEL	C8	18	17
NUT, TANK MOUNTING	C8	18	12	SCREW-WASHER, 4X12	C15	25	21	TUBE, FUEL TANK	C8	18	15
NUT, TAPPET ADJUSTING	C6	16	8		D1	27	20				16
[O]					D2	28	21	TUBE, VINYL, 13X15X90	C9	19	35
OIL SEAL, 25.4X62X6	C1	11	12	SCREW-WASHER, 5X10	C9	19	26	TUBE, VINYL, 9X11X210	C9	19	34
OIL SEAL, 28X41.25X6	C2	12	20	SCREW-WASHER, 5X14	C9	19	27	[V]			
OIL SEAL, 6X11X4	C3	13	21	SCREW SET	C10	20	4	VALVE, EX.	C1	11	7
O-RING, 14.8X2.4	C3	13	22				6	VALVE, FLOAT	C10	20	9
O-RING, 6.8X1.9	C6	16	9				7	VALVE, IN.	C1	11	6
[P]				SCREW SET, DRAIN	C10	20	5	[W]			
PACKING SET	C10	20	1	SCREW, PAN, 5X16	D1	27	19	WASHER, CONTROL LEVER	D2	28	6
PACKING, AIR CLEANER	C12	22	4		D2	28	20	WASHER, DRAIN PLUG, 12MM	C3	13	24
PACKING, CARBURETOR	C10	20	15	SCREW, PAN, 5X6	C10	20	20	WASHER, EXTENSION LOCK	C2	12	5
			16	SCREW, PAN, 5X8	C16	26	8	WASHER, PLAIN, 4MM	C15	25	22
PACKING, INSULATOR	C10	20	14		D1	27	18		D1	27	22
PACKING, OIL FILLER CAP	C2	12	2	SCREW, RECESSED, 5X28	D1	27	16		D2	28	23
			3	SCREW, TAPPET ADJUSTING	C6	16	7	WASHER, PLAIN, 6MM	C3	13	23
PAN ASSY., OIL	C2	12	1	SCREW, TAPPING, 4X6	C13	23	10	WASHER, THRUST	C4	14	7
PIN, GOVERNOR WEIGHT	C2	12	12				11	WASHER, THRUST, 6MM	C2	12	18
PIN, LOCK, 8MM	C3	13	25	SEAL, FUEL FILLER NECK	C8	18	8	WEIGHT, GOVERNOR	C2	12	10
PIN, PISTON	C5	15	3	SEAL, VALVE STEM	C1	11	3				
PISTON	C5	15	2	SHAFT COMP., GOVERNOR HOLDER ..	C2	12	8				
PLATE ASSY., BALL CONTROL	D6	32	2	SHAFT, CAM PULLEY	C6	16	2				
PLATE COMP., BRAKE	D6	32	6	SHAFT, GOVERNOR ARM	C2	12	14				
PLATE, ARRESTER NUMBER	C13	23	6	SHAFT, ROCKER ARM	C6	16	6				
PLATE, BALL CONTROL	D6	32	3	SLIDER, GOVERNOR	C2	12	13				
PLATE, LEVER CENTER	D2	28	7	SPACER, CONTROL LEVER	D2	28	8				
PLATE, SIDE	C14	24	3		D3	29	5				
PLATE, SPRING HOOK	D6	32	5	SPRING, BALL PLATE	D6	32	7				
PLUG, SPARK	C1	11	13	SPRING, BRAKE LEVER	C14	24	15				
PROTECTOR COMP., MUFFLER	C13	23	3	SPRING, CHOKE LEVER	D4	30	3				
PROTECTOR, MUFFLER	C13	23	3	SPRING, CLUTCH	D6	32	11				
PULLEY COMP., CAMSHAFT	C6	16	1	SPRING, CONTROL ADJUSTING	D1	27	8				
PULLEY, DRIVE	D6	32	10	SPRING, CONTROL LEVER RETURN ..	D1	27	9				
PUMP ASSY., FUEL	C8	18	1	SPRING, GOVERNOR	D1	27	3				
[R]					D2	28	3				
RETAINER, VALVE SPRING	C1	11	9		D3	29	3				
RING SET, PISTON	C5	15	1	SPRING, LEVER	D1	27	5				
ROD ASSY., CONNECTING	C5	15	4		D2	28	5				
ROD, CHOKE	D1	27	13	SPRING, RETURN	D4	30	1				
	D2	28	12	SPRING, THROTTLE RETURN	D1	27	4				
	D3	29	9		D2	28	4				
			10		D3	29	4				
ROD, GOVERNOR	D1	27	2	SPRING, VALVE	C1	11	8				
	D2	28	2	STARTER ASSY., RECOIL	C7	17	1				
	D3	29	2				2				
ROD, STOP	D4	30	4	STAY, FUEL PUMP	C8	18	2				
ROPE, RECOIL STARTER	C7	17	4	STRAINER, FUEL	C8	18	6				
RUBBER A, TANK MOUNTING	C8	18	10	SWITCH ASSY., ENGINE STOP	C14	24	10				
RUBBER B, TANK MOUNTING	C8	18	11		D1	27	14				
					D2	28	13				
					D3	29	11				
				[T]							
				TANK, FUEL	C8	18	7				

For Discount Troy Bilt Parts Call 606-678-9623 or 606-561-4983

www.mymowerparts.com

1

FOREWORD INDEX

2

ENGINE GROUP

3

PART NUMBER INDEX

4

PART NAME INDEX

For Discount Troy Bilt Parts Call 606-678-9623 or 606-561-4983

www.mymowerparts.com

For Discount Troy Bilt Parts Call 606-678-9623 or 606-561-4983



January 18, 2007



PARTS CATALOG NEWS

Honda Motor Co., Ltd. Service Division

PARTS CATALOG - CORRECTED

Printed in Japan

CODE NO.	14Z8B702
PARTS CATALOG NEWS	GCV160LA
NEWS NO.	001


Block No.	Ref. No.	Note	Part No.	Description	Reqd. QTY GCV 160 LA	Serial No.	Parts catalog code
E-11	2	T	28400-ZM0-633ZA	STARTER ASSY., RECOIL (LONG ROPE)			
				NH1.....BLACK	1	-----	S1M
		T	28400-ZM0-633ZE	*T98*.....MTD RED	0	-----	S1M

NOTE A:PART NO. CHANGE D:NEWLY PROVIDED E:PART NO.DELETION K:REQUIRED NO. CORRECTION L:APPLICATION SERIAL NO. CORRECTION
T:APPLICATION CORRECTION Z:REMARKS CHANGE

PARTS CATALOG NEWS

BOOKNo. : 14Z8B702

Block No.	Ref. No.	Note	Part No.	Description	Reqd. QTY GCV 160 LA	Serial No.	Parts catalog code
E-28			LABEL				



E-28	1	E	87101-ZM0-020	*PARTS NO. DELETION			
	6	D	87101-ZM0-020	MARK, EMBLEM (GCV160)	1	-----	A1A

NOTE A:PART NO. CHANGE D:NEWLY PROVIDED E:PART NO.DELETION K:REQUIRED NO. CORRECTION L:APPLICATION SERIAL NO. CORRECTION
T:APPLICATION CORRECTION Z:REMARKS CHANGE

February 25, 2007



PARTS CATALOG NEWS

Honda Motor Co., Ltd. Service Division

PARTS CATALOG - CORRECTED

Printed in Japan

CODE NO.	14Z8B702
PARTS CATALOG NEWS	GCV160LA
NEWS NO.	002

Block No.	Ref. No.	Note	Part No.	Description	Reqd. QTY GCV 160 LA	Serial No.	Parts catalog code
E-19	1	D	11344-Z0L-800	GROMMET A, RR. COVER (8X16X8)	1	-----	S1A, S3A

NOTE A:PART NO. CHANGE D:NEWLY PROVIDED E:PART NO.DELETION K:REQUIRED NO. CORRECTION L:APPLICATION SERIAL NO. CORRECTION
T:APPLICATION CORRECTION Z:REMARKS CHANGE

April 08, 2007



PARTS CATALOG NEWS

Honda Motor Co., Ltd. Service Division

PARTS CATALOG - CORRECTED


Printed in Japan

CODE NO.	14Z8B702
PARTS CATALOG NEWS	GCV160LA
NEWS NO.	003

Block No.	Ref. No.	Note	Part No.	Description	Reqd. QTY	Serial No.	Parts catalog code
					GCV 160 LA		

E-28 LABEL

ILLUSTRATION CORRECTED



NOTE A:PART NO. CHANGE D:NEWLY PROVIDED E:PART NO.DELETION K:REQUIRED NO. CORRECTION L:APPLICATION SERIAL NO. CORRECTION
T:APPLICATION CORRECTION Z:REMARKS CHANGE