



# Supplement Sheet

Date: February 04, 2004

Subject: 21" Single Stage Auger Assemblies Comparison

Models Affected: 21" Single Stage Model Series 140, 150, 160, 170, 285 and 295

**PURPOSE:** This sheet is supplied to depict the two 21" single stage snow thrower augers that may be found on single stage snow throwers. Due to supply issues you may have been shipped a direct replacement auger or your snow thrower may have a different Auger Assembly as depicted in your Operator's Manual illustrated parts list. See **Discussion** section below.

**NOTE:** *Save this Instruction Sheet. Refer to it when ordering replacement parts.*

### Discussion:

Due to supply issues your snow thrower may have a different Auger Assembly than depicted in your Operator's Manual illustrated parts list.

When replacement of the rubber spirals and pads is required you will need to verify which auger assembly is on your snow thrower. The illustration shows which replacement kit is required for that auger configuration.

### 784-5485 Auger Assembly:

The Auger Assembly **784-5485** is depicted in the top illustration on the right. This configuration has metal spiral supports that the narrow rubber spirals mount to. The center paddle area is open.



### 684-04027A Auger Assembly:

The Auger Assembly **684-04027A** is depicted in the bottom illustration on the right. This configuration has heavy duty rubber spirals that mount to the metal end spokes. There are no metal spiral supports for the curved rubber spirals. The center paddle area is partially closed by the combination paddle support and spoke brackets.



**Rubber Replacement Kit P/N 753-0613**

**Complete Auger Assembly with rubber spirals and pads P/N 784-5485 (21'')**  
(784-5485 Replaced By 684-04027A)

---

**Rubber Replacement Kit P/N 753-04472**

**Complete Auger Assembly with rubber spirals and pads P/N 684-04027A (21'')**