



190-077-190 Convertible Grass Catcher (1988)
Grass Catcher

Page 2 of 2

Ref #	Part Number	Qty	S/P/F	Description
1	16129	1	S	Panel Support Brkt.
2	17196	1		Top Catcher Panel Ass'y.
3	17095	1	S	Top Discharge Door
4	732-0483	1	S	Torsion Spring
5	747-0514	1		Pivot Pin
6	710-0255	1	S	Truss Mach. Scr. 1/4-20 x .75" Lg.
7	710-0289	1	S	Hex Bolt 1/4-20 x .50n Lg.
8	710-0258	1	S	Hex Bolt 1/4-20 x .62n Lg.'
9	712-0287	1	S	Hex Nut 1/4-20 Thd.
10	736-0329	1	S	L-Wash. 1/4" I.D.
11	16702	1		Front Grass Catcher Frame
12	731-0801	1	/P	Grass Catcher Handle
13	764-0212	1		Grass Bag
14	747-0495	1		Upper Bag Handle
15	710-0969	1	/P	Hex AB-Tap Scr. #12 x 1.0"
16	720-0224	1	S	Grass Catcher Locking Knob
17	722-0134	1		Foam Strip 1" Lg.
18	731-0883	1		Panel Clip
19	736-0271	1	S	Spring Wash. 32" I.D.
20	710-0258	1	S	Hex Bolt 1/4-20 x .62 Lg.
21	720-0190	1	S	Door Grip
22	710-0429	1	S	Hex B-Tap Scr. #10 x .38
23	719-0279	1	/P	Rope Guide
24	731-0733	1		Top Discharge Chute Ass'y.