





13AA672F190 LT-13 (1999)
38" Deck Assembly

Page 2 of 24

Ref #	Part Number	Qty	S/P/F	Description
2	710-1260A	1	/P	Hex Wash. Hd. TT-Tap Scr. 5/16-18 x .75" Lg.
3	683-0129	1	S/F	38" Deck Ass'y.
	813-06980	1	S/F	38" Deck Ass'y. Comp. (For Service Only)
4	783-0343A	1	/P	Belt Guard Deck
7	712-0291	1	S	Hex L-Nut 1/4-20 Thd. (Optional)
8	710-0258	1	S	Hex Bolt 1/4-20 x .62"
10	711-0792	1	S	Hinge Pin
13	712-0181	1	S	Hex Top L-Nut 3/8-16 Thd.
14	712-3006	1	/P	Hex Nut 1/4-20 Thd. (Gr. 5)
17	734-0973	1	/P	Deck Wheel - 5"
18	736-0105	1	/P	Bell-Wash. .40" I.D. x .88" O.D.
22	738-0373	1	S	Shld. Bolt .498" Dia. x 1.53"
23	742-0610	1	S	3 in 1 Blade
26	754-0329A	1	S	V-Belt
27	736-0270	1	/P	Bell-Wash. 1/4" I.D.
28	783-0342	1	S	Brake Disc
?33	710-0157	1	/P	Hex Bolt 5/16-24 x .75" Lg.
35	712-0417A	1	/P/F	Hex Flange Nut 5/8-18 Thd.
?37	736-0158	1	S/F	L-Wash. 5/8" I.D.
39	618-0138	1	S	Blade Spindle Ass'y. Comp. (Incl. Ref. 28, 35, 42)
42	756-0969	1	F	5" Dia. Pulley
52	703-1693	1	S	Hinge Mtg. Brkt.
53	732-0602	1	S	Torsion Spring
54	726-0106	1	S	Push Nut
55	731-1032	1	S	Chute Ass'y. Comp. (Incl. Ref. 10, 52, 53, 54, 55)
56	710-0597	1	/P	Hex Bolt 1/4-20 x 1" Lg. (Optional)
57	712-3087	1	/P	Wing Nut 1/4-20 Thd.
58	731-1643A	1	S	Mulching Plug (Optional)
59	16606	1	S	Retainer Hook Brkt.
60	712-0271	1	/P	Hex Sems Nut 1/4-20 Thd.
61	710-0258	1	S	Hex Bolt 1/4-20 x .62" Lg.
62	736-0173	1	/P	Flat Washer .28 ID x .74 OD

13AA672F190 LT-13 (1999)
Deck Lift Assembly

Page 3 of 24




13AA672F190 LT-13 (1999)
Deck Lift Assembly

Page 4 of 24

Ref #	Part Number	Qty	S/P/F	Description
1	783-0103	1	S	Connecting Rod
2	683-0029A	1	S	Pivot Link Ass'y. - L.H.
3	683-0028A	1		Pivot Link Ass'y. - R.H.
4	17710	1	S	Deck Hanger Link Ass'y.
5	14800A	1	S	Deck Hanger Link Ass'y.
6	14804A	1		Deck Hanger Link Ass'y.
7	748-0331	1	S	Shld. Spacer .318" I.D.
8	736-0264	1	S	Fl-Wash. .344" I.D. x .62" O.D.
9	736-0119	1	S/F	L-Wash. 5/16" I.D.
10	712-3010	1	S	Hex Nut 5/16-18 Thd. (Gr. 5)
12	714-0470	1	S	Cotter Pin 1/8" Dia.
13	736-0256	1	S	Fl-Wash. .635" I.D. x 1.0" O.D.
14	683-0003	1	S	Height Adj. Stop Lever Ass'y.
15	08540	1	/P	Knob
16	710-0604	1	S	Hex Wash. TT-Tap Scr. 5/16-18 x .625
17	748-0176	1		Flange Brg. .63" I.D.
18	710-1238	1	/P	Hex Wash. Hd. Scr. 5/16-18 x .875"
19	710-0118	1	S	Hex Bolt 5/16-18 x .75" Lg.
20	17730	1	S	Index Brkt.
21	783-0042A	1	S	Upper Frame - R.H.
23	736-0267	1	S	Fl-Wash. .385" I.D. x .87" O.D.
24	736-0160	1	S	Fl-Wash. .531" I.D. x .93" O.D.
25	726-0272	1	/P	Clamp
26	738-0526	1		Running Board Rod
27	710-3007	1	/P	Hex Wash. Hd. Tap Scr.
28	14802A	1	S	Link Deck Lift Ass'y.
29	711-0723A	1	S	Adj. Ferrule 3/8-24 Thd.
30	17712	1	S	Adj. Deck Lift Link
31	712-3066	1	S	Hex Nut 1/2-20 Thd. (Gr. 5)
32	711-0841	1	S	Lift Link Adjuster
33	17637A	1		Lift Shaft Ass'y.
34	725-1657A	1	S	Safety Switch (Deck)
35	714-0145	1	S	Inter. Cotter Pin 3/8" Dia.
36	732-0637	1	S	Extension Spring
37	17636C	1	S	Stabilizer Bracket
38	738-0670	1	S	Shaft 1/2" Dia. x 10.28" Lg.
39	732-0638	1		Extension Spring
40	720-0233	1	S	Grip (Lift Handle)
41	97675A	1	S	Deck Lift Handle Ass'y.
42	738-0669	1		Shaft 3/8" Dia. x 9.34" Lg.
43	747-0598	1		Disengagement Rod
44	97624	1	S	Stabilizer Shaft Ass'y.
45	732-0556	1	S	Extension Spring 7.58" Lg.
46	783-0043	1	/P	Upper Frame - L.H.
47	741-0313	1	S	Flange Brg. .632" I.D.
48	17128A	1	S	Spring Retainer Brkt.
49	716-0104	1	S	"E"-Ring
50	736-0425	1	S	Bell-Wash. .325" I.D.

13AA672F190 LT-13 (1999)
Differential Assembly

Page 5 of 24



13AA672F190 LT-13 (1999)
Differential Assembly

Page 6 of 24

Ref #	Part Number	Qty	S/P/F	Description
1	732-0614	1		Wire Ring
2	716-0231	1	S	"E"-Ring
4	710-1325	1	/P	Hex Tap Scr. 1/4-20 x 1.625" Lg.
5	719-0367	1		Upper Housing
8	711-1109	1		Input Shaft
10	736-0335	1	S	Thrust Washer 5/8" I.D. x 1.25" O.D.
11	717-1464	1		Pinion Input 14T
12	716-0108	1	S	Retaining Ring
13	711-1003	1	S	Drive Shaft - R.H. Brake
14	741-0336	1	S/F	Flange Brg. 5/8" I.D. x 3/4" Lg.
15	717-1362	1	S	Bevel Gear 42T Small I.D.
16	717-1363	1	S	Bevel Gear 42T Large I.D.
17	718-0228	1		Clutch Collar
?21	710-0862A	1	/P	Pan Head Scr. 1/4-20 x .50" Lg. w/Patch
23	741-0340	1	S	Sleeve Bearing 3/4" I.D. x 1.0" Lg.
24	721-0338	1	S	Oil Seal 3/4" I.D.
26	736-0445	1	S	FI-Wash. .760" I.D. x 1.5" O.D.
32	736-0495	1	S	Thrust Wash. 5/8" I.D. x 1" O.D. x .025" Thk.
	736-0336	1	S	FI-Wash. 5/8" I.D. x 1" O.D. x .030" Thk.
	736-0494	1		Thrust Wash. 5/8" I.D. x 1" O.D. x .035" Thk.
	736-0337	1	S	FI-Wash. 5/8" I.D. x 1" O.D. x .040" Thk.
34	719-0313B	1	/P	Lower Housing
35	718-0150	1		Anti-Rotation Brkt.
37	736-0349	1	S	FI-Wash. 5/8" I.D. x 1" O.D. x .020" Thk.
	736-0336	1	S	FI-Wash. 5/8" I.D. x 1" O.D. x .030" Thk.
	736-0337	1	S	FI-Wash. 5/8" I.D. x 1" O.D. x .040" Thk.
38	712-0273	1	S	Hex Nut 5/16-24 Thd.
39	736-0371	1	/P	FI-Wash. .344" I.D. x .875" O.D.
40	717-0700	1	/P	Actuating Arm
41	761-0198	1	S	Brake Yoke
42	717-0682	1	S	Puck Plate
43	717-0678	1	S	Brake Puck
45	761-0202	1		Brake Disc
46	741-0337	1	S	Flange Bearing 5/8" I.D. x 15/16" Lg.
48	611-0011	1	S	Shift Fork Ass'y.
49	741-0862	1	/P	Ball Detent .250" Dia.
50	732-0863	1	S	Spring Detent
52	741-0335	1	S	Needle Brg. 5/8" I.D. x 1/2" Lg.
54	736-0349	1	S	FI-Wash. 5/8" I.D. x 1" O.D. x .020 Thk.
55	741-0343	1	S	Actuating Pin 5/16" Dia.
56	710-1206	1	/P	Hex Wash Hd. Self-Tap Scr. 1/4-20 Thd.
58	736-0349	1	S	FI-Wash. 5/8" I.D. x 1" O.D. x .020 Thk.
	736-0495	1	S	Thrust Wash. 5/8" I.D. x 1" O.D. x .025" Thk.
60	736-0492	1	S	Washer FI-Wash. .76" I.D. x 1.5" O.D. x .010" Thk.
	736-0493	1	S	FI-Wash. .76" I.D. x 1.5" O.D. x .020" Thk.
	736-0351	1	S	FI-Wash. .76" I.D. x 1.5" O.D. x .030" Thk.
	736-0445	1	S	FI-Wash. .76" I.D. x 1.5" O.D. x .060" Thk.
61	736-0519	1	S	Thrust Washer
62	618-0162	1	S	Differential Ass'y.
63	732-0742	1	S	R.H. - Brake Spring
	737-0148	1	S	Grease - Shell (15 oz.)


13AA672F190 LT-13 (1999)
Differential Assembly

Page 7 of 24

Ref #	Part Number	Qty	S/P/F	Description
	618-0163B	1	S	Single Speed Transaxle - R.H.

13AA672F190 LT-13 (1999)
Engine Accessories

Page 8 of 24




13AA672F190 LT-13 (1999)
Engine Accessories

Page 9 of 24

Ref #	Part Number	Qty	S/P/F	Description
1	710-0148	1	/P	Hex Slot Scr. #8-32 x .38" Lg.
2	710-0599	1	/P	Hex Wash. TT-Tap Scr. 1/4-20 x .5"
3	710-0604	1	S	Hex Washer TT-Tap Scr. 5/16-18 x .62"
4	710-1237	1		Scr. #10-32: .620 Hx. Slot Wash.
5	710-1314	1	S	Socket Hd. Bolt 5/16-18 x .62" Lg.
6	710-1315	1	/P	Scr. 3/8-16 x 1.25
7	712-0271	1	/P	Nut, Hex 1/4-20
8	721-0208	1	S	Exhaust Gasket
9	726-0205	1	/P	Hose Clamp .49 Dia.
10	726-0272	1	/P	Clamp 9/16 Dia.
11	731-1682A	1	/P	Oil Drain Sleeve
12	736-0119	1	S/F	L-Wash. 5/16" I.D.
14	751B213146	1	/P	Casing Clamp, Throttle, B&S
15	751-0535-13	1	S	Fuel Line Hose
16	751-0564	1	S	Muffler Deflector
17	751-0617	1	S	Muffler
18	751-0619	1	S	Exhaust Pipe
19	783-0615	1	S	Muffler Heat Shield

13AA672F190 LT-13 (1999)
Hood And Fender Assembly

Page 10 of 24




13AA672F190 LT-13 (1999)
Hood And Fender Assembly

Page 11 of 24

Ref #	Part Number	Qty	S/P/F	Description
1	783-0250	1		Hood
2	738-0952	1	S	Shld. Bolt .375" Dia. x .125" Lg.
6	712-0271	1	/P	Hex Sems Nut 1/4-20 Thd.
9	712-3027	1	S	Flange L-Nut 1/4-20 Thd.
10	783-0156A	1		Grille
13	725-0963	1	S	Lamp
14	725-1651	1	S	Socket
15	710-0703	1	/P	Carriage Bolt 1/4-20 x .75" Lg.
17	736-0173	1	/P	Fl-Wash. .281" I.D. x .73" O.D.
18	726-0233	1	/P	Bolt Retainer 1/4" I.D.
19	712-0185	1		Speed Nut 1/4-20 Thd.
20	710-0376	1	/P	Hex Bolt 5/16-18 x .1" Lg. (Gr.5)
21	17632A	1	S	Gas Tank Support Brkt.
22	731-1692	1		Dash w/Ammeter Hole
23	725-0267	1	S	Ignition Switch
24	725-0201	1	S	Ignition Key
25	746-0616A	1	S	Choke Control 23" Lg.
26	725-0634	1	S	Light Switch
27	725-0925	1	S	Ammeter
32	710-0924	1	/P	Pan Hd. Scr. 1/4-20 x .75" Lg.
34	783-0350	1		Fender
38	710-0726	1	/P	Hex Wash. Hd. AB-Tap Scr. 5/16
40	17286B	1	S	Shift Cover
41	831-0823A	1	/P	Throttle Box Ass'y.
42	710-0779A	1	/P	Truss Mach. AB-Tap Scr. #10 x .5"
43	746-0776	1	S	Throttle Control Wire 18.5" Lg.
45	710-0603	1	/P	Hex Wash. Hd. B-Tap Scr.
46	17782	1		Choke Retainer
47	710-0642	1	/P	Hex TT-Tap Scr. 1/4-20 x .75" Lg.
49	731-1503A	1	S	Lens
49	726-04077	1		Nut, Push 3/32 Not shown
51	783-0367	1		Side Panel L.H. Not shown
51	783-0366	1		Side Panel R.H.
71	726-0211	1	S	U-Nut 5/16-18 Thd.
72	710-0286	1	/P	Truss Mach. Scr. 1/4-20 x .5" Lg.
73	749-0722B	1	S	Grille Support
74	732-0699	1		Hood Spring
75	726-0130	1	S	Speed Nut
76	710-0751	1	/P	Hex Bolt 1/4-20 x 5/8" Lg.
77	736-0342	1		Fl-Wash. .283" I.D. x .75" O.D.
78	710-0589	1	/P	Hex Hd. Tap Scr. #10-16 x .75"
	629-0309	1	S	Headlight Harness Not shown

13AA672F190 LT-13 (1999)
Lower Frame Assembly And Wheels

Page 12 of 24



IMPORTANT: For a proper working machine, use Factory Approved Parts.

V-BELTS are specially designed to engage and disengage safely. A substitute (non OEM) V-belt can be dangerous by not disengaging completely.

13AA672F190 LT-13 (1999)
Lower Frame Assembly And Wheels

Page 13 of 24

Ref #	Part Number	Qty	S/P/F	Description
2	17840	1	S	Transaxle Mtg. Brkt.
5	736-0119	1	S/F	L-Wash. 5/16" I.D.
6		1		UNKNOWN
10	710-1315	1	/P	Hex TT-Tap Scr. 3/8-16 x 1.5" Lg.
11	783-0310C	1	S	Lower Frame Ass'y.
13	712-3006	1	/P	Hex Nut 1/4-20 Thd. (Gr. 5)
14	736-0329	1	S/F	L-Wash. 1/4" I.D.
17	736-0242	1	/P	Bell-Wash. .345" I.D. x .88"
18	712-3010	1	S	Hex Nut 5/16-18 Thd. (Gr. 5)
19	711-1044	1	S	Belt Guard Stud 4.75" Lg.
21	756-0982	1	S	Engine Pulley
22	736-0322	1	/P	FI-Wash. 7/16" I.D. x 1.25"
23	736-0171	1	S/F	L-Wash. 7/16" I.D.
24	710-3029	1	/P	Hex Bolt 7/16-20 x 1.25" Lg.
25	754-0280	1	S	Variable-Speed Belt
26	710-0118	1	S	Hex Bolt 5/16-18 x .75" Lg.
27	17963	1		Bearing Shaft Bracket Ass'y.
28	741-0495	1	/P	Flanged Nyliner Brg. 5/8" I.D. x .88" Lg.
29	712-0241	1	/P/F	Hex Nut 3/8-24 Thd.
30	17643	1	S	Idler Bracket
31	736-0169	1	S/F	L-Wash. 3/8" I.D.
32	712-0241	1	/P/F	Hex Nut 3/8-24 Thd.
33	17629A	1	S	Transaxle Support Brkt.
34	732-0556	1	S	Ext. Spring .94" O.D. x 7.58"
35	714-0149B	1	S	Inter. Cotter Pin
36	750-0802	1		Spacer .63" I.D.
39	712-0138	1	S	Hex Nut 1/4-28 Thd.
40	710-0776	1	S	Hex AB-Tap Scr. 1/4" x .62" Lg.
42	736-0222	1	S	Ext. L-Wash. 1/4" I.D.
43	710-0599	1	/P	Hex Wash. Hd. S-Tap Scr. 1/4-20 x .50" Lg.
44	683-0123	1		Clutch/Brake Pedal Ass'y.
45	736-0140	1	S	FI-Wash. .344" I.D. x .62"
47	747-0755A	1		Brake Rod Ass'y.
48	735-0196	1	S	Foot Pad
51	17705	1	/P	Shift Lever Ass'y.
54	732-0413	1	S	Ext. Spring .59" O.D. x 7.08"
55	710-0189	1	/P/F	Hex Bolt 5/16-18 x 3" Lg.
56	734-1675	1		Wheel Ass'y. Comp.
	734-1596	1		Tire Only
57	634-0070	1	/P	Wheel Rim Only
58	734-0255	1	S	Air Valve (Service Only)
59	710-0627	1	/P/F	Hex Bolt 5/16-24 x .75" Lg.
63	736-0275	1	S	FI-Wash. .34" I.D. x .68" O.D.
64	710-0428	1	F	Hex Bolt 1/4-28 x 1.25" Lg.
65	732-0568	1	S	Ext. Spring
66	732-0384	1	S	Ext. Spring .62" O.D. x 6.12"
67	16554A	1	S	Variable Speed Torque Brkt. Ass'y.
68	741-0419	1		Flanged Bearing
69	714-0111	1	S/F	Cotter Pin 3/32" Dia.
70	748-0234	1	/P	Shoulder Spacer .27" Lg.
71	747-0530A	1	/P	Speed Control Link
72	741-0405	1	S	Truss Bearing .56 Dia. x 1.25"
73	720-0232	1	S	Shift Knob


13AA672F190 LT-13 (1999)
Lower Frame Assembly And Wheels

Page 14 of 24

Ref #	Part Number	Qty	S/P/F	Description
74	756-0643	1	S	FI-Idler Pulley 3.12" Dia.
75	656-0004	1		"V" Pulley
76	736-0427	1	S	Bell-Wash. .56" I.D. x 1.125"
77	712-3035	1	/P	Hex Jam Nut 5/16-18 Thd.
78	710-0539	1	/P	Hex Bolt 3/8-24 x 1.75" Lg.
79	754-0370	1	S	Variable Speed Belt
80	716-0114	1	S	Snap Ring .56" Dia.
81	736-0355	1	/P	FI-Wash.
82	717-0800A	1	S	Variable Speed Pulley Ass'y. 5" O.D.
84	16354B	1	S	Variable Speed Brkt. Ass'y.
85	732-0525	1		Comp. Spring - Clip
86	17668	1	S	Axle Support Brkt. - R.H.
	17669	1	S	Axle Support Brkt. - L.H. (Not Shown)
88	725-1426	1	S	Solenoid
89	17630	1	S	Shift Lever Bracket
90	736-0414	1	S	Teflon Washer .565" I.D.
91	750-0956	1		Spacer 1" I.D. x 1.25" Lg.
92	711-1000	1	S	Belt Keeper 3" Lg.
93	725-1657A	1	S	Safety Switch (Clutch)
94	738-0755	1	S	Shld. Bolt 3/8-24 x 3.12" Lg.
96		1		UNKNOWN
97	736-0105	1	/P	Bell-Wash. .38" I.D. x .88"
98	738-0569	1	S	Shaft .56" Dia. x 3.875" Lg.
99	736-0331	1	/P	Bell-Wash. .39" I.D. x 1.12"
100	736-0256	1	S	FI-Wash. .64" I.D. x .94"
101	714-0470	1	S	Cotter Pin 1/8" Dia. x 1.25"
102	710-0604	1	S	Hex Wash. Hd. Scr. 5/16-18 x .62" Lg.
103	734-1784A	1	S	Hub Cap - Grey
107	17860	1	S	Pedal Bracket
109	711-0198	1	S	Ferrule
111	710-0195	1	S	Hex Bolt 1/4-28 x .50" Lg.
112	736-0270	1	/P	Bell-Wash. .265" I.D. x .75"
113	17707	1		Shift Lever Link Ass'y.
115	736-0140	1	S	FI-Wash. .385" I.D. x .62"
116	741-0404	1	S	Needle Brgs.
117	727-0425A	1	S	Spring Clip (Used w/Ref. No. 103)
128	710-1238	1	/P	Hex Wash. TT-Tap Scr. 5/16-18 x .75" Lg.
129	710-0726	1	/P	Hex Wash. AB-Tap Scr. 5/16-18 x .75" Lg.
130	712-0265	1	/P	Hex Sems Nut 5/16-18 Thd.
131	732-0750A	1	S	Spring Switch

13AA672F190 LT-13 (1999)
Schematic

Page 15 of 24



13AA672F190 LT-13 (1999)
Schematic

Page 16 of 24

Ref #	Part Number	Qty	S/P/F	Description
725-0634	725-0634	1	S	Light Sw.
725-1426	725-1426	1	S	Solenoid
725-1657A	725-1657A	1	S	Deck Sw.
725-1396	725-1396	1	S	Key Sw.
725-1657A	725-1657A	1	S	Clutch Sw.
725-1381	725-1381	1	S	Fuse
725-0925	725-0925	1	S	Ammeter
725-1643	725-1643	1		Reverse Sw.
725-1303	725-1303	1	S	Seat Sw.
725-1439	725-1439	1		Seat Sw.



13AA672F190 LT-13 (1999)

Page 18 of 24

Seat, Fuel Tank, And Frame Assembly

Ref #	Part Number	Qty	S/P/F	Description
2	710-1208	1	/P	Hex Tap Scr. 5/16-18 x 3.25"
6	783-0039A	1	/P	Seat Pivot Bracket
7	751-0603	1	S	Fuel Cap
8	751-0555	1	S	Fuel Tank (1.5 Gal)
9	726-0209	1	/P	Tie Strap
10	751-0535-15	1	S	Fuel Line
11	726-0205	1	/P	Hose Clamp
13	712-0287	1	S	Hex Nut 1/4-20 Thd.
14	736-0329	1	S	L-Wash. 1/4" I.D.
16	732-0735	1	/P	Compression Spring
21	738-0526	1		Running Board Rod
22	710-0227	1	/P	Hex AB-Tap Scr. #8 x .50" Lg.
?23	726-0139	1	/P	Speed Nut #10Z
24	783-0041A	1	S	Front Pivot Brkt.
25	710-0870	1	/P	Hex Tap Scr. 3/8-16 x .62" Lg.
26	710-0726	1	/P	Hex Wash. Hd. AB-Tap Scr. 5/16 x .75"
28	710-0134	1	/P	Carriage Bolt 1/4-20 x .62
29	17770C	1	S	Running Board (R.H. & L.H.)
30	761-0168B	1	S	Blade Brake Ass'y.
32	731-0909	1	S	Rubber Foot Pad - L.H.
	731-0910	1	S	Rubber Foot Pad - R.H.
33		1		UNKNOWN
34	783-0310C	1	S	Lower Frame
36	726-0278	1		Insulator Boss Plate
?37	736-0264	1	S	Fl-Wash. .344" I.D. x .625" O.D.
38	710-3008	1	/P/F	Hex Bolt 5/16-18 x .75" Lg.
39	783-0042A	1	S	Upper Frame - R.H.
42	732-0581B	1	S	Extension Spring 5.31" Lg.
44	725-1750	1	S	12-V Battery
45	783-0043	1	/P	Upper Frame - L.H.
46		1		Shift Cover See "Shift Cover" illustration and parts list.
47	725-1643	1		Reverse Safety Switch
48	726-0279	1		Insulator Plate
49	17951	1	S	Seat Pivot Brkt. Support - L.H.
50	783-0355A	1	/P	Hitch Plate
51	712-0267	1	S/F	Hex Nut 5/16-18 Thd.
52	736-0119	1	S/F	L-Wash. 5/16" I.D.
53	17239A	1	S	Seat Lift Brkt.
54	757-0371A	1	S	Seat - Grey
55	17950	1	S	Seat Pivot Brkt. Support - R.H.
56	738-0296	1	S	Shld. Bolt .437" Dia. x .268"
57	725-1303	1	S	Spring Switch (Seat - Outer)
?59	710-0650	1	/P	Hex TT-Tap Scr. 5/16-18 x 7/8"
62	726-0320	1	S	Insulatop Nut Plate
63	725-1439	1		Safety Switch (Seat - Inner)
65	783-0345	1	S	Battery Tray
66	710-0351	1	/P	Truss Mach. B-Tap Scr. #10 x .5" Lg.
67	748-0347	1	S	Spring Spacer
68	710-0323	1	/P	Truss Mach. Scr. 5/16-18 x .75"
69	710-3008	1	/P	Hex Bolt 5/16-18 x .75" Lg.
?70	731-0405	1		Snap Bushing

13AA672F190 LT-13 (1999)


Page 19 of 24

Seat, Fuel Tank, And Frame Assembly

Ref #	Part Number	Qty	S/P/F	Description
71	723-3064	1		Battery Retainer Strap
72	712-3010	1	S	Hex Nut 5/16-18 Thd.
73	712-0265	1	/P	Hex Sems Nut 5/16-18 Thd.
74	712-0271	1	/P	Hex Sems Nut 1/4-20 Thd.

13AA672F190 LT-13 (1999)
Speed Selector Lever Assembly

Page 20 of 24




13AA672F190 LT-13 (1999)
Speed Selector Lever Assembly

Page 21 of 24

Ref #	Part Number	Qty	S/P/F	Description
1	710-0924	1	/P	Truss Mach. Scr. 1/4-20 x .75" Lg.
2	16194	1	S	7-Speed Selector Plate
3	720-0218	1	/P	Shift Knob
4	16192A	1	/P	Speed Selector Lever Ass'y.
5	736-0192	1	S	Flat Washer .53" I.D. x .93"
6	711-0198	1	S	Ferrule 3/8-24 x .37" Dia.
7	738-0155	1	S	Shoulder Bolt
8	747-0503A	1		Speed Control Link
9	714-0111	1	S/F	Cotter Pin 3/32" Dia. x 1.0"
10	736-0226	1	S	Fl-Wash. .469" I.D. x .88"
11	736-0119	1	S/F	L-Wash. 5/16" I.D.
12	712-3010	1	S	Hex Nut 5/16-18 Thd. (Gr. 5)
14	732-0303	1	S	Spring .38" O.D. x 3.18" Lg.
17	736-0300	1	S	Fl-Wash. .385" I.D. x 7/8"
19	736-0329	1	S/F	L-Wash. 1/4" I.D.
20	712-3006	1	/P	Hex Nut 1/4-20 Thd. (Gr.5)

13AA672F190 LT-13 (1999)
Steering Assembly

Page 22 of 24



13AA672F190 LT-13 (1999)
Steering Assembly

Page 23 of 24

Ref #	Part Number	Qty	S/P/F	Description
1	731-1509A	1	/P	Steering Wheel Cap
2	710-0643	1	/P	Hex Bolt 5/16-18 x 1" Lg.
3	736-0242	1	/P	Belleville Wash. .345" I.D.
4	731-1686	1	S	Steering Wheel
5	731-0954	1	S	Steering Bellow - 9"
9	17198A	1	S	Retainer Plate
10	738-0141	1	S	Shoulder Bolt .437" Dia. x .35 Lg. 5/16-18
11	710-0152	1	S	Hex Bolt 3/8-24 x 1.0" Lg. (Gr. 5)
13	750-0535	1	S	Spacer .380" I.D. x .625" O.D. x .227
14	736-0217	1	S	L-Wash. 3/8" I.D. (H.D.)
15	710-0726	1	/P	Hex Wash. Hd. Self-Tap Scr.
16	711-1107	1	S	Steering Drag Link
17	783-0041B	1	/P	Front Pivot Brkt.
18	738-0527	1	S	Shoulder Bolt .498" Dia. x 2.04 Lg. 3/8-16
19	712-0431	1	S	Flanged L-Nut 3/8-16 Thd.
21	712-0411	1	S	Hex L-Nut 5/16-24 Thd.
22	16481A	1	S	Steering Arm Front Axle
23	710-0772	1	/P	Hex Bolt 5/16-24 x 2.00" Lg. (Gr.5)
24	741-0659	1	S	Hex Flg. Brg. .632 I.D.
25	683-0128	1	S	Pivot Bar Ass'y.
26	683-0127	1	S	Front Axle Ass'y. - L.H.
27	712-0241	1	/P	Hex Nut 3/8-24 Thd.
28	736-0169	1	S/F	L-Wash. 3/8" I.D.
29	723-3018	1	S	Ball Joint 3/8-24 Thd.
30	747-0753	1		Tie Rod (Adjustable)
31	712-0711	1	/P	Hex Jam Nut 3/8-24 Thd.
32	683-0126	1	S	Front Axle Ass'y. - R.H.
33	634-0059	1		Wheel Ass'y. Comp.
34	634-0051	1	S	Front Wheel Rim Only
35	741-0569	1	S	Bearing
36	736-0285	1	/P	Fl-Wash. .635 I.D. x 1.59" O.D.
37	731-1783A	1		Front Wheel Hub Cap
38	714-0470	1	S	Cotter Pin 1/8" Dia. x 1.25"
39	736-0366	1	/P	Fl-Wash. 5/8" x 1.004 x .120
40	726-0214	1	/P	Push Cap 5/8" Dia. Rod
42	712-0262	1	/P	Hex Jam Nut 3/8-24 Thd.
43	710-1309	1	/P	Hex Patch Bolt 5/16-18 x .62
46	748-0389	1	S	Cap
47	712-0214	1	S	Hex Cent. L-Nut 3/8-24 Thd.
48	736-0217	1	S	L-Wash. 3/8" I.D.
49	712-0158	1	S	Hex Cent. L-Nut 5/16-18 Thd.
51	717-0622A	1	S	Steering Gear Segment
52	741-0656	1	S	Hex Flg. Brg. .634 I.D.
53	736-0187	1	/P	Fl-Wash. (Hardened)
54	738-0919	1	S	Steering Shaft
58	736-0271	1	S	Wave-Wash. .32" I.D. x .62" O.D.
59	736-0187	1	/P	Fl-Wash. (Hardened)
60	723-0448	1	S	Drag Link Ball Joint 7/16-20 Thd.
64	736-0356	1	S	Bell-Wash. .39" I.D. x 1.38" O.D.
65	731-1291A	1	S	Pivot Bar End Cap
67	734-0255	1	S	Valve - Air
68	734-0864	1	/P	Tire Only
69	737-0280	1	S	Grease Fitting

13AA672F190 LT-13 (1999)
Steering Assembly

Page 24 of 24

Ref #	Part Number	Qty	S/P/F	Description
70	712-0240	1	S	Jam Nut 7/16-20