


13A-344-190 LR-927 (2004)
Deck Assembly

Page 1 of 30



NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part, numbered 700-xxxx, is painted Oyster Gray, the part number to order would be 700-xxxx-0662.

Oyster Gray: 0662

Powder Black: 0637

Red Metallic: 0650


13A-344-190 LR-927 (2004)
Deck Assembly

Page 2 of 30

Ref #	Part Number	Qty	S/P/F	Description
1	618-0250	1	S	Spindle Assembly
2	683-0150E	1	S	Deck Assembly
3	683-0159	1	S	Brake Bracket Assembly
4	683-0173	1		Deck Belt Cover
5	710-0134	1	/P	Carriage Screw 1/4-20 x .62"
6	710-0191	1	/P	Hex Bolt 3/8-24 x 1.25"
7	710-0347	1	/P	Hex Screw 3/8-16 x 1.75"
8	710-0599	1	/P	Self-Tapp. Screw 1/4-20 x .5"
9	710-0650	1	/P	Self-Tapp. Screw 5/16-18 x .75"
10	710-0672	1	/P	Hex Cap Scr. 5/16-24 x 1.25"
11	710-0932	1	/P	Carriage Screw
12	710-1611B	1	/P	Torx Screw 5/16-18 x .75"
13	712-0241	1	/P	Hex Nut 3/8-24
14	712-0287	1	S	Hex Nut 1/4-20
15	712-0417A	1	/P	Flange Nut 5/8-18
16	712-3017	1	S	Hex Nut 3/8-16
17	712-3057	1	S	Hex Nut 5/16-24
18	714-0115	1	S	Cotter Pin
19	726-0201	1		Speed Nut
20	726-0233	1	/P	Push Nut
21	732-0429A	1	S	Extension Spring
22	736-0101	1	S	Flat Washer 3/8 x 1.00 x .030"
23	736-0119	1	S	Lock Washer 5/16
24	736-0169	1	S	Lock Washer 3/8
25	736-0173	1	/P	Flat Washer
26	736-0289	1	S	Bushing
27	736-0300	1	S	Flat Washer .406 x .875 x .059"
28	736-0343	1	/P	Flat Washer .330 x 1.25 x .120"
29	736-3020	1	S	Flat Washer
30	738-0968	1	S	Spacer
31	742-0578	1	S	Blade: 27.5" Bagging
32	742-0651	1	S	Three-in-one Blade
33	747-0957	1		Link Rod
34	747-0972	1		Belt Keeper
35	747-1172	1	S	Belt Keeper
36	754-0221	1	S	V Belt
37	756-0627	1	S	Flat Idler Pulley
38	783-0463A	1	S	Idler Bracket
39	783-0529	1	S	Cable Bracket
40	783-0569B	1	S	Deck Plate
41	783-0594	1	S	Deck Cable Plate

13A-344-190 LR-927 (2004)
Differential Assembly

Page 3 of 30



13A-344-190 LR-927 (2004)
Differential Assembly

Page 4 of 30


Ref #	Part Number	Qty	S/P/F	Description
1	618-0232	1	S	Differential Assembly: Single Speed
2	618-0248	1	S	Drive Shaft assembly: LH Brake
3	618-0072B	1	S	Upper Housing Assembly
4	611-0114	1		Detent Shaft Assembly
5	661-0006	1	S	Brake Yoke Assembly: LH
6	710-1206	1	/P	Hex Washer Hd. TT Screw 1/4-20 x 2.37
7	710-1325	1	/P	Hex Washer Hd. TT Screw 1/4-20 x 1.65
8	717-0678	1	S	Brake Puck
9	719-0313B	1	/P	Lower Housing
10	732-0863	1	S	Spring Detent
11	737-0148	1	S	Grease
12	741-0862	1	/P	Ball Detent
13	761-0202	1		Brake Disc
14	777-6318	1		Label
15	618-0251C	1	S	Transmission Assembly, Complete

13A-344-190 LR-927 (2004)
Drive Assembly

Page 5 of 30

IMPORTANT: For a proper working machine, use Factory Approved Parts.

V-BELTS are specially designed to engage and disengage safely. A substitute (non OEM) V-Belt can be dangerous by not disengaging completely.




13A-344-190 LR-927 (2004)
Drive Assembly

Page 6 of 30

Ref #	Part Number	Qty	S/P/F	Description
1	683-0147A	1	S	Idler Bracket Assembly
2	710-0191	1	/P	Hex Screw (Special)
3	710-0314	1	/P	Hex Screw 7/16-20 x 1.0"
4	710-0902	1		Hex Screw 3/8-24 x 3.75"
5	710-1611B	1	/P	TT Screw
6	710-3096	1	/P	Hex Screw 3/8-16 x 2.0"
7	712-0116	1	S	Jam Lock Nut
8	712-0241	1	/P	Hex Nut 3/8-24
9	712-3017	1	S	Hex Nut 3/8-16
10	712-3035	1	/P	Jam Nut 9/16-18
11	714-0114	1	S	Sq. Key
12	717-0884	1		Variable Speed Pulley Assembly
13	732-0814	1		Extension Spring
14	732-0815A	1		Extension Spring
15	736-0169	1	S	Lock Washer
16	736-0171	1	S	Lock Washer
17	736-0219	1	S	Bell Washer
18	736-0247	1	/P	Flat Washer
19	736-0427	1	S	Beleville Washer
20	737-0167	1		Grease
21	737-0288	1		Grease
22	738-0968	1	S	Shoulder Spacer
23	741-0405	1	S	Thrust Bearing
24	750-0705	1		Slv. Spacer
25	754-0453	1	S	V-Belt
26	756-0116	1	S	Idler Pulley
27	756-0650	1		Transmission Pulley
28	756-0658	1	S	Engine Pulley
29	756-0981A	1	S	Flat Idler Pulley
30	783-0528	1		Idler Bracket: Variable Speed
31	783-0529	1	S	Cable Bracket
32	683-0149B	1	/P	Frame Assembly

13A-344-190 LR-927 (2004)
Electrical

Page 7 of 30




13A-344-190 LR-927 (2004)
Electrical

Page 8 of 30

Ref #	Part Number	Qty	S/P/F	Description
1	629-04055	1	S	Harness Assembly w/o
2	710-0134	1	/P	Carriage Screw 1/4-20 x 0.62"
3	710-3021	1		D Screw 5/16-18 x 0.625"
4	712-0271	1	/P	Sems Nut 1/4-20
5	725-0267	1	S	Ignition Switch: 5 Pin
6	725-04040	1	S	Seat Switch
7	725-1426	1	S	Solenoid 12 volt, 100 amp.
8	725-1643	1		Spring Switch
9	725-1657A	1	S	Switch: Interlock
10	736-0607	1	/P	Lock Washer 5/16
11	725-1704	1	S	Battery (not shown)

13A-344-190 LR-927 (2004)
Frame Assembly

Page 9 of 30




NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part, numbered 700-xxxx, is painted Oyster Gray, the part number to order would be 700-xxxx-0662.

Oyster Gray: 0662
Powder Black: 0637
Red Metallic: 0650

13A-344-190 LR-927 (2004)
Frame Assembly

Page 10 of 30

Ref #	Part Number	Qty	S/P/F	Description
1	683-0142	1		Pivot Bar Assembly
2	683-0160	1		Bracket Assembly: Hood Pivot
3	683-0163A	1	S	Steering Support Bracket
4	683-0264A	1	S	Channel Assembly: Front Frame
5	710-0599	1	/P	TT screw 1/4-20 x 0.5"
6	710-1017	1	/P	AB Screw 1/4-14 x 0.625"
7	710-1611B	1	/P	TT Screw 5/16-18 x 0.75"
8	711-0332	1	S	Clevis Pin
9	711-1165	1		Clevis Pin
10	714-0104	1	S	Cotter Pin
11	714-0147	1		Hairpin Clip
12	714-0470	1	S	Cotter Pin
13	725-0157	1	/P	Cable Tie
14	732-0829	1	S	Extension Spring
15	735-0199A	1	S	Rubber Bumper
16	735-0271	1	S	Bumper
17	736-0101	1	S	Flat Washer
18	736-0187	1	/P	Flat Washer
19	736-0275	1	S	Flat Washer
20	736-3019	1		Flat Washer
21	747-0985	1		Deck Rod
22	783-04231	1		Rail: Rear Frame
23	783-04248	1		Rail: Frame RH
24	783-04252	1		Rail: Frame LH
25	783-0554	1		Cam Bracket
26	783-0564A	1		Frame: Upper Front
27	783-0605	1	S	Stabilizing Bracket: Deck
28	783-0811A	1	/P	Front Bumper




13A-344-190 LR-927 (2004)
Fuel Tank & General Assembly

Page 12 of 30

Ref #	Part Number	Qty	S/P/F	Description
1	683-0190B	1	S	Rail Support: Frame Assembly RH
2	683-0191B	1	S	Rail Support: Frame Assembly LH
3	683-0401B	1		Frame Assembly
4	710-0157	1	/P	Hex Bolt 5/16-24 x 0.75"
5	710-0599	1	/P	TT Screw 1/4-20 x 0.5"
6	710-0604A	1	/P	TT Screw 5/16-18 x 0.625"
7	710-0654A	1	/P	TT Sems Screw 3/8-16 x 1.0"
8	710-1237	1		T Screw #10-32 x 0.625"
9	710-1314A	1	/P	Soc. Hd. Screw 5/16-18 x 0.75"
10	710-1611B	1	/P	TT Screw 5/16-18 x 0.75"
11	710-1502	1		AB Screw 8-18 x 0.375"
12	711-04143	1		Battery Hold -Down Rod
13	712-0271	1	/P	Sems Nut
14	712-0291	1	S	Hex Lock Nut 1/4-20
15	712-0397	1	S	Wing Nut
16	721-0208	1	S	Exhaust Gasket
17	721-0331	1		Sealant: Loctite (TM) (not serviceable)
18	722-3022	1	S	Foam Tape: 0.625 x 0.25 thk.
19	725-0157	1	/P	Cable Tie
20	726-0205	1	/P	Hose Clamp
21	726-0209	1	/P	Cable Tie
22	731-04282	1	S	Plen
23	731-0707A	1		Battery Cover
24	731-1682A	1	/P	Oil drain Sleeve
25	736-0119	1	S	Lock Washer 5/16
26	736-0222	1	S	External Lock Washer
27	736-0123	1	S	Flat Washer
28	736-0607	1	/P	Lock Washer 1/4
29	737-0169	1		SAE 30W Oil (not serviceable)
30	737-0125	1		Elbow Fitting
31	741-0516	1	S	Flange Bearing
32	751-0535	1		Fuel Line Hose
33	751-3071	1	S	Fuel Cap
34	751-3214	1	S	Fuel Tank
35	751-9986	1	S	Muffler
36	751B213146	1	/P	Clamp Casing: Throttle
37	751B222261	1		Muffler Deflector
38	783-04100	1	S	Tank Bracket
39	783-04144	1	S	Support Bracket RH
40	783-04260	1	S	Support Bracket LH
41	783-08098	1		Support Bracket: Transaxle
42	710-3008	1	/P	Hex Screw 5/16-18 x 0.75"
43	712-0267	1	S	Hex Nut 5/16-18
44	726-0201	1		Speed Nut
45	783-0561	1	S	Hitch Plate
46	725-1704	1	S	Battery (not shown)

13A-344-190 LR-927 (2004)
Grass Bag Assembly

Page 13 of 30



NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Powder Black, the part number to order would be 700-xxxx-0637.

Powder Black: 0637
Oyster Gray: 0662
Metallic Red: 0650

13A-344-190 LR-927 (2004)
Grass Bag Assembly

Page 14 of 30

Ref #	Part Number	Qty	S/P/F	Description
1	631-0084	1	S	Grass Bag Assembly
2	710-0286	1	/P	Pan Hd. Machine Screw 1/4-20 x 0.5
3	710-0564	1	/P	Hex Screw 1/4-20 x 2.75
4	710-0825	1	/P	Hex Screw 1/4-20 x 3.75
5	712-0298	1	S	Jam Nut
6	712-0397	1	S	Wing Nut
7	726-0271	1	S	Push Nut
8	731-1743A	1	/P	Chute: Bagger
9	731-1744	1		Discharge Chute: Side-Discharge
10	731-1745A	1	/P	Mulching Plug
11	736-0173	1	/P	Flat Washer
12	736-0329	1	S	Lock Washer
13	783-0645A	1	S	Deflector Plate: Bagger Chute




13A-344-190 LR-927 (2004)
Lift Assembly

Page 16 of 30

Ref #	Part Number	Qty	S/P/F	Description
1	683-0152	1		Pivot Link Assembly
2	683-0194A	1	S	Lift Arm Assembly
3	710-0376	1	/P	Hex Screw 5/16-18 X 1.00 Gr.5
4	710-3230	1		Hex Bolt 1/2-13 X 2.75 Gr.5 Spec.
5	711-0332	1	S	Lift Bracket Pin
6	711-04158	1		Lift Rod
7	711-3319	1	S	Ferrule
8	712-0266	1	S	Jam Nut
9	712-3008	1	S	Jam Nut 3/8-16 Gr. 5
10	712-3010	1	S	Hex Nut 5/16-18
11	712-3048	1	S	Jam Nut
12	714-0104	1	S	Cotter Pin
13	714-0147	1		Cotter Pin
14	714-3010	1	/P	Cotter Pin
15	720-0298	1		Handle Grip
16	732-0829	1	S	Extension Spring
17	732-0837	1		Torsion Spring
18	736-0119	1	S	Lock Washer 5/16
19	736-0140	1	S	Flat Washer .385 I.D. x .620 O.D.
20	736-0169	1	S	Lock Washer
21	736-0257	1	S	Flat Washer
22	736-0275	1	S	Flat Washer 5/16
23	736-3019	1		Flat Washer
24	738-0145	1	S	Shoulder Screw
25	738-0183	1	S	Shoulder Screw
26	738-0958	1	S	Shoulder Spacer
27	783-0435	1		Upper Deck Link
28	783-04320	1		Axle Bracket: Rear
29	783-0440	1	S	Lower Link
30	783-0442A	1	S	Crossbar Link: Lift

13A-344-190 LR-927 (2004)
Pedal & Controls

Page 17 of 30



NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part, numbered 700-xxxx, is painted Oyster Gray, the part number to order would be 700-xxxx-0662.

Oyster Gray: 0662
Powder Black: 0637
Red Metallic: 0650


13A-344-190 LR-927 (2004)
Pedal & Controls

Page 18 of 30

Ref #	Part Number	Qty	S/P/F	Description
1	683-0155A	1	S	Brake Pedal Assembly
2	683-0161	1	S	Shift Cam Assembly
3	683-0275A	1		Deck Pedal Assembly
4	683-0310A	1	S	Variable Pedal Assembly
5	710-1017	1	/P	Ab Screw 1/4-14 X .625
6	711-0701	1	S	Clevis Pin
7	711-1156	1		Shaft
8	712-0287	1	S	Hex Nut 1/4-20
9	712-0324	1	/P	Lock Nut 1/4-20
10	712-3017	1	S	Hex Nut 3/8-16
11	714-0104	1	S	Internal Cotter Pin
12	714-0111	1	S	Hairpin Clip
13	714-0470	1	S	Hairpin Clip
14	720-0166	1	/P	Ball Knob
15	726-0100	1	S	Push Cap
16	726-0450	1		Plug Cap
17	731-0405	1		Snap-on Bushing
18	731-1913	1		Stop Lever
19	732-0815A	1		Extension Spring
20	732-0865	1		Torsion Spring
21	735-0261	1		Drive Pad
22	735-0262	1		Deck Pad
23	735-0263	1		Brake Pad
24	736-0117	1	S	Flat Washer 3/8 X .620 X .033
25	736-0133	1	S	Flat Washer.411 x 1.25" x .100
26	736-0159	1	S	5/16 Washer
27	736-0169	1	S	Lock Washer
28	736-0187	1	/P	Flat Washer
29	736-0262	1	/P	Flat Washer
30	736-0272	1	S	Flat Washer .510 X 1.00 X .060
31	736-0300	1	S	Flat Washer
32	736-0329	1	S	Lock Washer
33	736-0608	1	S	Spring Washer
34	736-3000	1		Flat Washer
35	736-3019	1		Flat Washer .531 X 1.062 X .134
36	736-3020	1	S	Flat Washer .271 X .630 X .065
37	738-0255	1	S	Shoulder Screw .375 Dia X .18
38	738-0373	1	S	Shoulder Screw
39	738-0974	1	S	Shoulder Screw .375 X .380 X 1/4-20
40	741-0591	1	S	Flange Bearing
41	746-0935A	1	S	Shift Cable
42	746-0936	1	S	Variable Drive Cable
43	746-0937	1	S	Brake Cable
44	746-0940	1	S	Deck Cable
45	746-0964	1	S	Throttle Choke Cable: 67"
46	747-0963A	1		Brake Rod
47	747-0964	1		Brake Lock Out Rod
48	750-0736	1	S	Shoulder Spacer
49	783-0473	1	S	Brake Lock Out Bracket
50	783-0525	1	S	Self-Propelled Pedal Link
51	783-0593A	1		Shift Lever
52	783-0794	1	S	Bracket: Lock-Out Pedal
53	726-0157			

13A-344-190 LR-927 (2004)
Safety & Decorative Labels Assembly

Page 19 of 30



Ref #	Part Number	Qty	S/P/F	Description
777I20777	777I20777	1		LABEL-HT ADJ DX70
777S30199	777S30199	1		LABEL-FLOORBOARD
777S30145	777S30145	1	S	USE 977S30145
777D03399	777D03399	1		LABEL-FENDER DX70
777D07397	777D07397	1		
777I20497	777I20497	1		LABEL-FNR S
777I20489	777I20489	1	/P	LABEL-THROTTLE STEER
777CX00001	777CX00001	1		
777D03401	777D03401	1		LABEL-FRONT BMPR
777D03402	777D03402	1		LABEL-SIDE PNL RH
777I20463	777I20463	1		LABEL-PEDAL/GRASS
777S32204	777S32204	1		LABEL-SAFETY M
777I20808	777I20808	1		LABEL-HOOD RH
777D03403	777D03403	1		LABEL-SIDE PNL LH
777S30200	777S30200	1		LABEL-DECK DANGER
777S32205	777S32205	1		
777I22129	777I22129	1		LABEL-INSTR
777S32206	777S32206	1		
777I22130	777I22130	1		LABEL-INSTR
777S30503	777S30503	1	/P	LABEL-DANGER CHUTE
777I20778	777I20778	1		LABEL-IGNITION

13A-344-190 LR-927 (2004)
Seat & Hood Assembly


Page 21 of 30

NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part, numbered 700-xxxx, is painted Oyster Gray, the part number to order would be 700-xxxx-0662.

Oyster Gray: 0662

Powder Black: 0637


Red Metallic: 0650



13A-344-190 LR-927 (2004)
Seat & Hood Assembly

Page 22 of 30

Ref #	Part Number	Qty	S/P/F	Description
1	710-0599	1	/P	TT Screw 1/4-20 x 0.5
2	710-1315	1	/P	TT Screw 3/8-16 x 1.25
3	710-1017	1	/P	Torx AB Screw 1/4-14 x 0.625
4	720-0238	1		Rod End Grip
5	731-0511	1	/P	Trim Strip
6	731-1691A	1	/P	Grass Bag Lens
7	783-0410	1	S	Bracket Reinforcement: Hood
8	783-0445	1		Hood
9	783-0446	1	S	Plate: Hood
10	783-0447	1		Hood Bracket
11	783-0448	1	S	Hood Bracket: Reinforcement
12	783-0449A	1	S	Hinge Bracket: Rear
13	783-0451A	1	S	Pivot Plate: Rear Hood
14	783-0545	1		Hood Screen
15	783-0562	1	S	Hinge Bracket: Front
16	757-04016	1	S	Seat: Low Back
17	738-04008	1	S	Spacer




13A-344-190 LR-927 (2004)
Steering

Page 24 of 30

Ref #	Part Number	Qty	S/P/F	Description
1	17962	1		Switch Plate
2	650-0007	1	S	Steering Tube Assembly
3	683-0033A	1		Steering Support Bracket
4	683-0178A	1	/P	Front Axle Assembly: RH
5	683-0179A	1	S	Front Axle Assembly: LH
6	710-0224	1	S	Hex Screw AB
7	710-0459A	1	/P	Hex Screw 3/8-24 x 1.5" Gr.5 Sp.
8	710-0643	1	/P	Lock Screw 5/16-18 x 1.0" Gr.5
9	710-0689	1	/P	Hex Screw 1/2-13 x 0.75"
10	710-0837	1		Oval C-Sunk Screw #10-16 x 0.625"
11	710-0958	1	/P	Hex Screw 1/4-20 x 1.25 Gr.5 Sp.
12	710-1017	1	/P	AB Screw 1/4-14 x 0.625"
13	710-1611B	1	/P	Self-Tapping Screw 5/16-18 x 0.75"
14	710-3008	1	/P	Hex Screw 5/16-18 x 0.75"
15	712-0116	1	S	Lock Nut 3/8-24
16	712-0206	1	S	Hex Nut 1/2-13
17	712-0241	1	/P	Hex Nut
18	712-0267	1	S	Hex Nut
19	712-0324	1	/P	Lock Nut 1/4-20
20	712-0411	1	S	Lock Nut
21	712-0711	1	/P	Jam Nut
22	714-0470	1	S	Cotter Pin
23	723-0156	1	S	Ball Joint
24	726-3046	1	/P	Ratchet Clip
25	731-0511	1	/P	Trim Strip
26	735-0674	1		Floor Pad: LH
27	735-0266A	1	/P	Floor Pad: RH
28	736-0105	1	/P	Bell Washer
29	736-0119	1	S	Lock Washer
30	736-0160	1	S	Flat Washer
31	736-0169	1	S	Lock Washer
32	736-0187	1	/P	Flat Washer
33	736-0196	1		Flat Washer
34	736-0242	1	/P	Beleville Washer
35	736-0272	1	S	Flat Washer
36	736-0320	1	/P	Flat Washer
37	736-3078	1	/P	Flat Washer
38	737-3007	1		Grease
39	738-0541	1	S	Spacer
40	738-3089A	1	/P	Steering Adapter
41	741-0225	1	S	Hex Flange Bearing
42	741-0356	1		Bearing: Steering Column
43	747-0955	1		Tie Rod
44	748-0290	1	S	Pinion Gear
45	750-0532	1	S	Spacer
46	783-0411	1		Gear: Steering Segment
47	783-0565C	1	/P	Upper Frame Cover
48	783-1013	1		Lift Plate

13A-344-190 LR-927 (2004)
Steering Column

Page 25 of 30




13A-344-190 LR-927 (2004)
Steering Column

Page 26 of 30

Ref #	Part Number	Qty	S/P/F	Description
1	731-2624	1		Steering Wheel: 3Spoke
2	731-2625	1		Steering Wheel Cap
3	731-1919	1		Steering Column: Black
4	731-1857	1		Control Knob
5	712-0142	1	/P	Hex Nut 8-32
6	710-3217	1	/P	Pan Head Machine Screw #8-32
7	710-0599	1	/P	Hex Screw TT 1/4-20 x .50"
8	749-1099	1		Bumper Tube: Front
9	712-0431	1	S	Lock Nut
10	710-0514	1	/P	Hex Screw 3/8-16 x 1.0"

13A-344-190 LR-927 (2004)
Transaxle Bracket Assembly

Page 27 of 30



NOTE: For painted parts, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part, numbered 700-xxxx, is painted Oyster Gray, the part number to order would be 700-xxxx-0662.

Oyster Gray: 0662


Powder Black: 0637

Red Metallic: 0650

13A-344-190 LR-927 (2004)
Transaxle Bracket Assembly

Page 28 of 30

Ref #	Part Number	Qty	S/P/F	Description
1	629-0865	1		Harness Assembly Adapter
2	710-1208	1	/P	Hex TT Screw 5/16-18 x 3.50
3	710-0227	1	/P	Hex Washer Head Self-Tap. ScREW
4	710-0805	1	/P	Hex Screw 5/16-18 x 1.5 Gr. 5
5	710-0642	1	/P	Thd. Forming Scr. 1/4-20x .75
6	712-3010	1	S	Hex Nut 5/16-18
7	714-0115	1	S	Cotter Pin
8	726-0320	1	S	Insulator Nut Plate
9	736-0289	1	S	Shoulder Bushing
10	736-0119	1	S	Lock Washer 5/16
11	736-3000	1		Flat Washer
12	750-1064	1	S	Spacer
13	783-0591	1	S	Transaxle Bracket
14	783-0433A	1	/P	Shift Lever



13A-344-190 LR-927 (2004)
Wheels

Page 30 of 30

Ref #	Part Number	Qty	S/P/F	Description
1	634-0139	1		Rear Wheel Compl.
2	634-0169A	1	/P	Front Wheel Compl.
3	734-1727	1	/P	Rear Tire
4	734-1382	1	S	Front Tire
5	734-0255	1	S	Valve: Tubeless Air
6	737-0211A	1	/P	Grease Fitting
7	741-0353	1	S	Flange Bearing
8	634-0138	1	/P	Rim Assembly
9	634-0170A	1		Rim Assembly
10	710-0627	1	/P	Hex Bolt 5/16-24 x .75"
11	736-0242	1	/P	Beleville Washer
12	714-0115	1	S	Cotter Pin
13	736-0285	1	/P	Flat Washer
14	736-0156	1	/P	Flat Washer
15	731-0484A	1	S	Hub Cap (not shown)