


12A-285D790 (2005)
General Assembly

Page 1 of 5



12A-285D790 (2005)
General Assembly

Page 2 of 5

Ref #	Part Number	Qty	S/P/F	Description
1	747-1214	1		Drive Control Handle
2	747-1161A	1	S	Blade Control Handle
3	746-1114	1	S	Blade Control Cable - 50.56"
4	746-1093A	1	S	Drive Control Cable
5	749-1092A	1	/P	Upper Handle
6	710-1205	1	/P	Eye Bolt
7	720-0279	1	/P	Wing Nut 1/4-20
10	710-1174	1	/P	Carriage Bolt 5/16-18 x 2.0
11	720-0284	1	S	Wing Nut 5/16-18
12	736-0451	1	S	Shoulder Washer.320 ID x.93 OD
13	731-0074	1		Transmission Cover
14	725-0157	1	/P	Cable Tie
15	749-04037	1	/P	Lower Handle
16	756-1169	1		Transmission Pulley
17	712-0240	1	S	Jam Nut 7/16-20
18	736-0407	1		Bell Washer.45 ID x 1.00 OD
19	754-0484	1	S	V-Belt
20	710-0642	1	/P	Hex Washer Screw 1/4-20 x.75
21	738-1002	1		Shoulder Screw.375 x.25
22	732-0993	1		Extension Spring
23	782-9061	1		Transmission Belt Bracket
24	682-3073	1		Handle Bracket Assembly - LH
25	618-0607A	1	S	Transmission Assembly
26	710-0654A	1	/P	Hex Washer Screw 3/8-16 x 1.0
27	782-9063	1	S	Engine Belt Keeper Bracket
28	687-02049	1	/P	22" Deck Assembly
29	712-0431	1	S	Flange Lock Nut 3/8-16
30	731-0981A	1	S	Hub Cap
31	748-04016A	1	/P	One Piece Blade Adapter
32	742-0742A	1	S	22" Mulching Blade
33	736-0524B	1	/P	Bell Blade Support
34	710-1044	1	/P	Hex Cap Screw 3/8-24 x 2.5
35	736-3013	1	S	Flat Washer 1/2 x 1.00 x.030 If Equipped
36	736-0741	1	/P	Bell Washer.401 ID x.870 OD
37	734-04158	1		Front Wheel
38	682-02094	1		Pivot Arm Assembly
39	741-0751	1	/P	Height Adjuster Bearing
40	720-0426	1	/P	Height Knob
41	732-1026	1		Spring Lever
42	738-1172	1	/P	Shoulder Screw 3/8-16
43	17032A	1	/P	Deflector Chute Adapter
44	710-0599	1	/P	Hex Washer Screw 1/4-20 x.50
45	736-0270	1	/P	Bell Washer.265 ID x.75 OD
46	682-3072	1		Handle Bracket Assembly - RH
47	732-1014	1		Torsion Spring
48	747-0710	1	S	Hinge Pin
49	731-1034B	1	S	Side Discharge Chute Assembly
50	734-2042	1	S	Rear Wheel
51	717-1762	1		Spur Gear 14T RH
	717-1761	1		Spur Gear 14T LH
52	715-0221	1	S	Pin
53	731-04643	1	/P	Wheel Cover
54	748-0455	1		Parts Support


12A-285D790 (2005)
General Assembly

Page 3 of 5

Ref #	Part Number	Qty	S/P/F	Description
55	728-0199	1		Plastic Rivet
56	710-1802	1		Screw 1/4-20
57	741-0710	1	/P	Sleeve Bearing
58	731-04859	1		Snap-On Bail Cover
59	716-0198	1		Retainer Ring
60	731-04019	1	/P	Trail Shield
61	750-1210	1	/P	Sleeve Spacer.550 ID x 9.0 OD
62	750-1209	1		Sleeve Spacer.550 ID x 2.44 OD
63	631-04045	1	/P	Snap Mulching Plug
64	748-0390	1		Bearing Spacer
65	712-0431	1	S	Hex Lock Nut 3/8-16
66	710-0216	1	/P	Hex Cap Screw 3/8-16 x 1.0
67	716-0865	1	/P	Snap Ring.500

12A-285D790 (2005)
Transmission

Page 4 of 5



12A-285D790 (2005)
Transmission

Page 5 of 5

Ref #	Part Number	Qty	S/P/F	Description
1	618-0392	1		Upper Housing Assembly
2	721-0329	1	S	Oil Seal.500 ID x.687 OD
3	741-0673	1	S	Flange Bearing.503 ID x.689 OD
4	736-0520	1	S	Flat Washer.504 ID x.700 OD x.030
	736-0711	1		Flat Washer.504 ID x.700 OD x.035
	736-0712	1		Flat Washer.504 ID x.700 OD x.040
	736-0713	1		Flat Washer.504 ID x.700 OD x.045
5	717-1723	1	S	Bevel Gear 44T
6	715-0139	1	S	Roll Pin
7	711-1649	1	S	Output Shaft
8	719-0538	1		Lower Housing
9	710-1276	1	/P	Hex Washer Screw 1/4-20 x.75
10	716-0231	1	S	E-Ring.750
11	736-0336	1	S	Flat Washer.625 ID x 1.0 OD x.030
	736-0337	1	S	Flat Washer.625 ID x 1.0 OD
	736-0349	1	S	Flat Washer.63 ID x 1.0 OD x.020
	736-0494	1		Flat Washer.632 ID x 1.0 OD x.035
	736-0495	1	S	Flat Washer.632 ID x 1.0 OD x.035
12	741-0735	1		Needle Bearing.625 x.813
13	719-0537	1		Upper Housing
14	736-0336	1	S	Flat Washer.625 ID x 1.0 OD x.030
	736-0494	1		Flat Washer.632 ID x 1.0 OD x.035
15	711-1390A	1	/P	Input Shaft
16	750-1242	1		Spacer.505 x.75 x.9765