


14A9816P790 GT-950H (2005)
Carburetor

Page 2 of 31

Ref #	Part Number	Qty	S/P/F	Description
	TC-640333	1		Carburetor
1	TC-640216	1		Throttle Shaft & Lever Assembly
5	TC-640037	1		Dust Seal
6	TC-640038	1		Throttle Shutter
7	TC-650506	1		Throttle & Choke Shutter Screws
10	TC-640217	1		Choke Shaft & Lever Assembly
11	TC-632785	1		Choke Return Spring
14	TC-64077	1		Choke Shutter
17	TC-651025	1		Throttle Crack Screw/Idle Speed Screw
18	TC-630766	1		Tension Spring
25	TC-640220	1		Float Bowl Assembly
25A	TC-640335	1	/P	Float Bowl Repair Kit
27	TC-632544	1		Float Shaft
28	TC-632543	1	/P	Float
29	TC-640336	1		Float Bowl to Body Gasket
30	TC-632709	1	/P	Inlet Needle & Seat
32	TC-640041	1		Bowl Drain Screw
33	TC-640042	1		Bowl Drain Washer
36	TC-640067	1		Main Nozzle Tube
37	TC-632547	1		O-Ring
38	TC-632545	1	/P	Spring, Main Nozzle Tube
38A	TC-36918	1		Spring
39	TC-640218A	1		Float Bowl Retainer
40	TC-640219	1		Main Fuel Jet
47	TC-630748	1		Welch Plug, Idle Mixing Well




14A9816P790 GT-950H (2005)
Deck Assembly

Page 4 of 31

Ref #	Part Number	Qty	S/P/F	Description
1	16606	1	S	Hook, Retainer
2	618-04126	1	S	Spindle Assembly
	756-1171	1		Pulley, 5.39"
	741-0919	1	S	Ball Bearing, .787 x 1.85 x .551
	738-1010A	1	/P	Shaft, Spindle, 5.75
	750-1349	1	S	Spacer, 79 x 1.84 x .55 lower
	736-0315	1	/P	Washer, Flat, .760 x 1.5 x .120
	712-0417A	1	/P	Nut, Hex, Flange, 5/8-18
3	683-0254B	1	/P	Hanger Bracket Assembly
4	683-04098	1		Idler Bracket
5	683-04109B	1		Weldment, 50-inch Deck
6	703-3279	1		Chute Stop
7	710-0347	1	/P	Screw, 3/8-16, 1.75
8	710-3103	1	/P	Screw, 5/16-18 x 2.00
9	710-0528	1	/P	Screw, 5/16-18, 1.25, Gr5
10	710-0599	1	/P	Screw, 1/4-20 x 0.5
11	710-0607	1	/P	Screw, 5/16-18 x.625
12	710-1260A	1	/P	Screw, 5/16-18 x.75
13	710-3168	1	/P	Screw, Carriage, 3/8-16 x 1.0
14	710-3178	1	/P	Screw, Carriage, 3/8-16 x.75
15	736-0300	1	S	Washer, Flat,.406 x.875 x.059
16	712-04065	1	/P	Nut, Nylon Lock, 3/8-16
17	712-0417A	1	/P	Nut, Hex, Flange, 5/8-18
18	712-04063	1	/P	Nut, Nylon Lock, 5/16-18
19	712-0431	1	S	Nut, Flange Lock, 3/8-16
20	712-3010	1	S	Nut, Hex, 5/16-18, Gr5
21	712-3019	1	S	Nut, 7/16-14
22	631-04070	1	S	Chute Assembly, Side Discharge
23	714-0470	1	S	Pin, Cotter, 1/8 x 1.25
24	714-0111	1	S	Pin, Cotter, 3/32 x 1.25
25	717-04074	1	S	Deck Adjustment Gear
26	712-3083	1	/P	Lock Nut, Hex, 1/2-13, Nylon
27	732-0306A	1	S	Spring, Compression,.531 x 1.75
28	732-0459B	1	S	Spring, Extension,.94 x 6.74
29	734-04039	1	S	Deck Wheel, 5.0
30	734-0973	1	/P	Deck Wheel, 5.0
31	736-0119	1	S	Washer, Lock, 5/16, Regular Duty
32	736-0407	1		Washer, Bell,.45 x 1.0 x.062
33	736-0406	1	S	Washer, Flat,.442 x 1.38 x.060
34	737-3000	1	S	Fitting, Lube, 3/16
35	738-0373	1	S	Shoulder Screw
36	738-3005A	1	S	Screw, Shoulder,.68 x 1.59
37	742-04053A	1	S	Blade
38	747-1116	1	/P	Rod, Handle, Deck Release.375 Via
39	750-0151	1	S	Spacer,.550 x.755 x 1.1
40	754-04077	1	S	Belt, V-Type, Aramid
41	756-04129	1	S	Pulley, Idler, 3.5"
42	747-1324	1		Rod, Deck Adjustment
43	783-04399	1		LH Belt Cover
44	783-04400	1		RH Belt Cover
45	783-04414	1	S	Deck Skirt, Center
46	783-04415	1		Deck Skirt, RH
47	711-1737	1		Deck Skirt, LH

14A9816P790 GT-950H (2005)
Deck Assembly

Ref #	Part Number	Qty	S/P/F	Description
48	731-3005	1	/P	Front Roller
49	738-04146	1		Screw Plug




14A9816P790 GT-950H (2005)
Deck Chute Assembly

Page 7 of 31

Ref #	Part Number	Qty	S/P/F	Description
	631-04070	1	S	Chute Assembly, Complete
1	711-1762	1		Pin, Hinge, .375 Dia x 14.06
2	731-3131A	1	S	Deflector, Chute
3	732-3070A	1	/P	Spring, Torsion
4	777S30145	1	S	Graphic, Danger
5	783-04470	1	/P	Bracket, Mounting

14A9816P790 GT-950H (2005)
Drive & Rear Wheels



14A9816P790 GT-950H (2005)
Drive & Rear Wheels

Page 9 of 31

Ref #	Part Number	Qty	S/P/F	Description
1	712-3050	1	/P	Lug Nut, 3/4-16
2	629-0949A	1		Reverse/Ground Wire Harness Adapter
3	783-04442	1		Double Idler Bracket
4	710-0176	1	/P	Hex Cap Screw, 5/16-18 x 2.75
5	710-0216	1	/P	Hex Cap Screw, 3/8-16 x.75
6	710-0227	1	/P	Screw, #8-18 x.5
7	710-1007	1	/P	Hex Cap Screw, 3/8-16 x 1.5
8	710-0599	1	/P	Self-tapping Screw, 1/4-20 x.50
9	710-0726	1	/P	Self-tapping Screw, 5/16-12 x.75
10	710-3011	1	/P	Hex Cap Screw, 3/8-16 x 2.25
12	711-0832	1	S	Ferrule, 3/8-24
13	712-0431	1	S	Flange Lock Nut, 3/8-16
14	712-04063	1	/P	Flange Lock Nut, 5/16-18
15	712-3017	1	S	Hex Nut, 3/8-16
16	714-0104	1	S	Internal Cotter Pin
17	714-0111	1	S	Cotter Pin
18	725-0157	1	/P	Cable Tie
19	725-1644	1		Short Spring Switch
20	726-0154	1	S	Push-mount Cable Tie
21	726-0320	1	S	Insulator Nut Plate
22	732-0716	1	S	Extension Spring,.59 x 4.0
23	732-0429A	1	S	Extension Spring,.5 x 3.97
24	732-3118	1		Extension Spring, 3/8 x 1.44
26	736-0169	1	S	Lock Washer, 3/8
27	736-3008	1	S	Flat Washer,.344 x.750 x.120
28	736-3010	1		Flat Washer,.407 x.812 x.135
29	738-0372B	1	/P	Shoulder Spacer,.38
30	747-1119	1		Hydrostatic Control Rod
31	747-1121	1	S	Hydrostatic Bypass Rod
32	747-04140	1		Hydrostatic Brake Rod
34	754-0349	1	S	Drive Belt
35	756-0116A	1	S	V-idler Pulley, 3.06
36	756-0981B	1	S	Flat Idler Pulley, 2.75
37	783-0667B	1		Transmission Torque Bracket
38	783-0745	1	S	Speed Control Bracket
39	783-0782	1	S	Switch Actuator Bracket
40	647-0031B	1	S	Brake Control Assembly
41	647-0049A	1	S	Drive Control Assembly
42	683-0267C	1	/P	Hydro Pedal Assembly
43	710-0650	1	/P	Self-tapping Screw, 5/16-18 x.875
44	710-1260A	1	/P	Self-tapping Screw, 5/16-18 x.75
46	711-04159B	1		Pin, 3/8-16 x 2.43
47	732-0335	1		Compression Spring,.40 OD x 1.17
48	732-0955	1		Extension Spring,.50 OD x 1.41
49	732-0963	1		Extension Spring,.50 OD x 6.37
50	735-0662	1		Drive Pedal Pad
51	735-3049	1	S	Brake Pedal Pad
54	736-0187	1	/P	Flat Washer,.64 x 1.24 x.06
56	736-3004	1	S	Flat Washer,.406 x.875 x.105
57	738-0155	1	S	Shoulder Screw,.437 x 1.62
59	741-0225	1	S	Hex Flange Bearing
60	741-3065B	1	/P	Split Hex Flange Bearing
61	747-04096	1		Control Rod

14A9816P790 GT-950H (2005)
Drive & Rear Wheels

Page 10 of 31

Ref #	Part Number	Qty	S/P/F	Description
62	747-04093	1		Brake Lock Control Rod
63	748-04039B	1	/P	Cruise Latch
64	748-0415B	1	/P	Spacer, 5/16 x 1.54
65	783-04612	1	S	Steering Support Bracket
66	783-0663E	1	/P	Drive Lockout Bracket
67	783-0773A	1		Brake Pedal
68	783-0693	1		Transmission Axle Bracket
69	634-0202A	1		Wheel Assembly Comp., 23 x 9.5 x 12
69	634-3178	1		Rim Only 12.0 x 7.0 (Not Shown)
69	734-0255	1	S	Air Valve (Not Shown)
69	734-04147	1	S	Tire Only 23.0 x 10.5 x 12 Sq. Shoulder (Not Shown)
70	731-2290A	1	/P	Hub Cap
71	710-1611B	1	/P	Self-tapping Screw, 5/16-18 x.75
72	756-0978A	1	S	Engine Pulley
73	712-04065	1	/P	Flange Lock Nut 3/8-16
74	710-0344	1	/P	Hex Cap Screw, 3/8-16 x 1.5
75	736-0320	1	/P	Flat Washer.38 x 1.38 x.125
76	738-0380	1	S	Shoulder Screw 3/8-16.50 x.27
	618-0379	1	S	Hydrostatic Transmission Assembly not shown

14A9816P790 GT-950H (2005)
Engine

Page 12 of 31

Ref #	Part Number	Qty	S/P/F	Description
1	N/A	1		UNKNOWN
2	TC-27652	1		Dowel Pin
11	TC-36302	1		Check Valve
11A	TC-36303	1		Breather Plate
11B	TC-650902	1		Screw, 10-32 x 7/16"
14	TC-37363	1		Washer
15	TC-37364	1		Governor Rod
15B	TC-650738	1		Screw, 1/4-20 x 5/8"
16	TC-37413	1		Governor Lever
16A	TC-37414	1		Governor Spring Bracket
17C	TC-37429	1		Breather Tube Clamp
30	TC-37818	1		Crankshaft
35	TC-651069	1		Screw, Carriage 1/4-20 x 1-1/2"
37	TC-650456	1		Lock Nut, 1/4-20
38	TC-37365	1		Retaining Ring
40	TC-40049	1		Piston, Pin & Ring Set (Std.)
40	TC-40050	1		Piston, Pin & Ring Set (.010" OS)
41	N/A	1		Piston & Pin Ass'y. (Std.) (Incl. 43)
41	N/A	1		Piston & Pin Ass'y.(.010" OS) (Incl. 43)
42	TC-40013	1		Ring Set (Std.)
42	TC-40014	1		Ring Set (.010"OS)
43	TC-27888	1		Piston Pin Retaining Ring
45	TC-37372	1		Connecting Rod Ass'y. (Incl. 46)
46	TC-651063	1		Connecting Rod Bolt
48	TC-37373	1		Valve Lifter
50	TC-37773	1		Camshaft (MCR)
52	TC-37305	1		Oil Pump Ass'y.
52A	TC-37382	1		Oil Pump Shaft
52B	TC-36333	1		O Ring
52C	TC-36334	1		Oil Pump Cover (Incl. 52B)
52D	TC-650888	1		Screw, T-30 1/4-20 x 43/64"
52E	TC-37383	1		Oil Pump Gear
52F	TC-37384	1		Oil Pump Gear Retaining Ring
60A	TC-650773	1		Screw, 1/4-20 x 1/2"
69	TC-37377	1	/P	Mounting Flange Gasket Kit (P)
70	TC-37378	1		Mounting Flange (Incl.72,72A,75,80,381-387)
72A	TC-28534	1		Oil Drain Plug
	TC-31927	1		Oil Drain Pipe Plug
	TC-37651	1		Oil Drain Valve
75	TC-36301	1	/P	Oil Seal (1 in Ref 1, 1 in Ref 70)
75A	TC-37369	1		Oil Seal (Governor Shaft)
80	TC-37379	1		Governor Shaft
81	TC-37381	1		Washer (Governor Shaft)
82	TC-37380	1		Governor Gear Ass'y.
83	TC-35322	1		Governor Spool
84	TC-29193	1		Retaining Ring
86	TC-651064	1		Screw, 5/16-18 x 1-15/32"
89	TC-650592	1		Flywheel Key
90	TC-611254	1		Flywheel (Incl. 91 & 91A)
91	TC-611241A	1	/P	Flywheel Fan
91A	TC-611242	1		Flywheel Retainer
92	TC-651082	1		Belleville Washer
93	TC-650594	1		Belleville Washer

14A9816P790 GT-950H (2005)
Engine


Page 13 of 31

Ref #	Part Number	Qty	S/P/F	Description
100	TC-37395	1	/P	Solid State Ignition (Incl. 101)
101	TC-610118	1		Spark Plug Cover
102	TC-651024	1		Solid State Mounting Stud
103	TC-651007	1		Screw, T-15 10-24 x 15/16"
119	TC-37388A	1	S	Cylinder Head Gasket Kit (P)
120	TC-37782	1		Cylinder Head, Opp. Breather Side
120A	TC-37783	1		Cylinder Head, Breather Side
125	TC-37780	1		Exhaust Valve (Std.)
126	TC-37779	1		Intake Valve (Std)
127	TC-650691	1		Flat Washer
128	TC-650690	1		Belleville Washer
130	TC-650697A	1		Screw, 5/16-18 x 2-1/2"(Head Mount)
135	TC-34645	1	/P	Spark Plug (RN4C)
143	TC-37774	1		Rocker Arm Housing
143A	TC-37771	1		Rocker Arm Pin
145	TC-651088	1		Lock Washer
146	TC-651091	1		Screw, T-45 5/16-24 X 29/32"
150	TC-27881	1		Valve Spring
151	TC-37781	1		Valve Keeper Retainer & Cap Set
151A	TC-40016A	1		Valve Seal
155	TC-37769	1		Rocker Arm
156	TC-650755	1		Adjusting Screw
157	TC-650864	1	/P	Lock Nut
158	TC-37772	1	/P	Push Rod
159	TC-35952	1	/P	Rocker Arm Cover Gasket Kit (P)
160	TC-37770	1		Rocker Arm Cover
160A	TC-37770	1		Rocker Arm Cover
161	TC-30063	1		Screw, T-30 1/4-20 x 1/2"
161A	TC-651034	1		Stud, Valve Cover Mounting
166	TC-37777	1		Engine Shroud
169	TC-37367	1		Valve Cover Gasket Kit (P)
171	TC-37366	1		Breather Element
173	TC-37393	1	S	Breather Tube
212	TC-37370	1		Bushing
253	TC-37376	1		Compression Release Weight
253A	TC-37424	1		Compression Release Pin
254	TC-37375	1		Compression Release Spring
260	TC-37775	1		Blower Housing (Black)
261	TC-651090	1		Shoulder Screw
265	TC-37627A	1		Cylinder Head Cover, Opp. Breather
265A	TC-37628A	1		Cylinder Head Cover, Breather Side
270A	TC-35829A	1		Exhaust Port Liner
286	TC-37394	1		Flywheel Screen
287	TC-651066	1		Screw, T-20 8-18 x 1-15/32"
290	TC-30962	1		Fuel Line (16.75")
291	TC-30962	1		Fuel Line
291A	~N/A	1		Fuel Line (8-1/4")
291B	~N/A	1		Fuel Line
291C	TC-34357	1		Fuel Line (6.75")
292	TC-26460	1	/P	Fuel Line Clamp
292A	TC-37399	1	S	Fuel Line Retainer
293	TC-35787	1	S	Pulse Pump
293A	TC-650931	1		Screw, 1-1/2"

14A9816P790 GT-950H (2005)
Engine

Page 14 of 31

Ref #	Part Number	Qty	S/P/F	Description
294	N/A	1		UNKNOWN
295A	TC-37422	1	S	Fuel Fitting
296	TC-37768	1	/P	Fuel Filter (Incl. 292)
303	TC-32958	1		Pulse Pump/Fuel Fitting
305	TC-36349	1		Oil Fill Tube
306	TC-37401	1		O-Ring (Oil Fill, Bottom) Kit (P)
307	TC-35499	1	/P	O-Ring (Oil Fill, Top)
309	TC-650974	1		Screw, 1/4-20 x 57/64"
310	TC-37421	1		Dipstick
315	TC-611292	1		Alternator Coil (16 Amp) (Incl.322-323B)
321	N/A	1		UNKNOWN
322	TC-611281	1		Connector Body
323	TC-611276	1		Terminal
325	TC-36342	1		Wire Clip
342	TC-651031	1		Screw, 1/4-20 x 9/16"(Ref. 240 & 265)
346	TC-36413	1		Fuel Pump Bracket
347	TC-651092	1		Screw (without air duct)
347	TC-651093	1		Stud (with air duct)
361	TC-651065	1		Screw, 5/16-18 x 2-3/8"
370A	TC-35274	1		Lubrication Decal
381	TC-650767	1		Screw, 8-32 x 27/64"
382	TC-36931	1		Oil Strainer Screen
385	TC-570673	1		Ball
386	TC-36329	1		Pressure Release Spring
387	TC-37652	1		Cotter Pin
395	TC-37284	1	/P	Electric Starter Motor (12 Volt)
400	TC-37423	1		Gasket Set (Incl. Items Marked PK in Notes)
420	N/A	1		UNKNOWN
428	TC-37362	1		Spacer
475	TC-36563	1	/P	Oil Filter
476	TC-36929	1	/P	Oil Filter Adaptor (Incl. 479)
477	TC-650378	1		Screw, T-30 5/16-18 x 1 3/32"
479	TC-36930	1		Oil Filter Adaptor Gasket Kit (P)
483	N/A	1		UNKNOWN




14A9816P790 GT-950H (2005)
Engine Accessories

Page 16 of 31

Ref #	Part Number	Qty	S/P/F	Description
1	710-0227	1	/P	Screw, #8-18 x .50
2	710-0599	1	/P	Screw, 1/4-20 x .50
3	710-0726	1	/P	Screw, 5/16-18 x .750
4	710-1237	1		Screw, #10-32 x .625
5	710-1314A	1	/P	Socket Cap Screw, 5/16-18 x .625
6	710-1315	1	/P	Self-tapping Screw, 3/8-16 x 1.25
7	712-3017	1	S	Hex Nut, 3/8-16
8	721-0460	1		Exhaust Gasket
9	726-0205	1	/P	Hose Clamp
10	725-0157	1	/P	Cable Tie
11	736-0300	1	S	Lock Washer, .406 x .875 x .059
12	751B221535	1	/P	Casing Clamp
13	751-0535	1		Fuel Line Hose
14	751-0564A	1	S	Muffler Deflector
15	751-0616A	1	S	Muffler, Twin Inlet
16	751-0650B	1	/P	RH Exhaust Pipe
17	751-0651B	1	/P	LH Exhaust Pipe
18	751-3140	1	S	Oil Drain Valve
19	751-3141	1	S	Oil Drain Hose
20	751-3142	1		Oil Drain Cap
21	783-0615D	1	S	Muffler Heat Shield
22	712-0271	1	/P	Sems Nut, 1/4-20

14A9816P790 GT-950H (2005)
Fender & Seat



14A9816P790 GT-950H (2005)
Fender & Seat

Page 18 of 31

Ref #	Part Number	Qty	S/P/F	Description
2	753-06260	1	/P	Lift Shaft Assembly Service Kit Replaces 683-04079
3	711-0332	1	S	Clevis Pin,.5 x.78
4	712-0206	1	S	Hex Nut, 1/2-13
5	712-04065	1	/P	Flange Lock Nut, 3/8-16
6	712-04063	1	/P	Flange Lock Nut, 5/16-18
8	714-0104	1	S	Hairpin Clip
9	714-04023	1	S	Hairpin Clip
10	716-0106A	1		E-Ring
11	720-0311	1		Handle Grip
12	732-0874	1	/P	Torsion Spring
13	732-1184	1	/P	Extension Spring,.84 x 4.6
14	736-0275	1	S	Flat Washer, 5/16
16	736-3019	1		Flat Washer,.31 x 1.062 x.134
17	736-3084	1	/P	Flat Washer,.51 x 1.12 x.06
18	738-0138A	1	/P	Hex Cap Screw, 5/16-18 x.62
19	738-0380	1	S	Shoulder Screw, 3/8-16
20	741-0225	1	S	Hex Flange Bearing
21	741-0715	1	S	Snap Flange Bearing
22	746-0968	1		Lift Cable, 16.16
23	747-04155	1		Lift Handle
24	756-1154	1		Roller Pulley
25	783-0678A	1	S	Arm Lift
26	783-0720A	1	S	Deck Stabilizer Bracket
27	710-0260A	1	/P	Carriage Bolt, 5/16 x.62
28	710-0726	1	/P	Self-tapping Screw, 5/16-18 x.625
29	710-0895	1		Self-tapping Screw, 1/4-15 x.75
30	731-1990	1		Lift Lever Cover
31	731-1993A	1		Cover w/ Cup Holder
32	736-3078	1	/P	Flat Washer,.349 x 1.0 x.063
33	783-0677	1	S	Lift Adjustment Bracket
34	783-04459A	1		Fender 4 Sty Hydro w/ Flares
35	783-1489A	1	/P	Seat Mounting Bracket
36	710-1268	1	/P	Screw, #10-16 x.375
37	712-3027	1	S	Hex Flange Lock Nut, 1/4-20
38	720-0309A	1	/P	Seat Adjuster Grip
39	731-04074	1		Spacer
40	732-0499	1		Compression Spring,.41 x 1.5
42	736-0204	1	/P	Flat Washer,.344 x.62 x.03
43	738-0137A	1	S	Shoulder Screw,.340 x.285,1/4-20
44	738-0966	1	S	Shoulder Screw,.50 x.50, 3/8-16
45	783-0611	1		Seat Stop
46	783-0738B	1	S	Seat Pivot Bracket
47	783-0739A	1	S	Seat Adjustment Lever
48	783-0753	1		Seat Adjustment Selector
49	757-04015	1	S	High Back Seat, Black
50	735-0656	1		RH Foot Pad
51	735-0657	1		LH Foot Pad
51	726-3046	1	/P	Foot Pad Clips Not shown
52	714-0111	1	S	Cotter Pin
54	783-0209C	1	S	Seat Lift Bracket
55	726-0201	1		Speed Clip

14A9816P790 GT-950H (2005)
Fender & Seat

Page 19 of 31

Ref #	Part Number	Qty	S/P/F	Description
56	731-2618	1		RH Fender Flare
57	731-2619	1		LH Fender Flare
58	738-0296	1	S	Shoulder Screw,.437 x.286
59	710-0932	1	/P	Carriage Screw 1/4-20 x 1.00
60	712-0271	1	/P	Sems Nut 1/4-20

14A9816P790 GT-950H (2005)
Fuel and Air Assembly

Page 21 of 31

Ref #	Part Number	Qty	S/P/F	Description
16D	TC-37415	1		Governor Spring, Hi-speed
16E	TC-37417	1		Governor Idle Spring
16F	TC-37418	1		Bell Crank Lever
19	TC-37416	1		Throttle Spring
173A	TC-37410	1		Breather Tube Grommet
173B	TC-37409	1		Breather Tube Fitting
177	TC-651067	1		Carburetor Mounting Stud
184	TC-36352	1	/P	Carburetor to Intake Pipe Gasket Kit
185	TC-37396	1		Intake Pipe (Incl. 387A)
186	TC-37404	1		Governor Link
186A	TC-37405	1		Choke Link
200	TC-37400	1		Control Bracket
207	TC-37406	1		Throttle Link
210	TC-27793	1	/P	Conduit Clip
211	TC-28942	1	/P	Screw, 10-32 x 3/8"
217	TC-37419	1		Control Lever
218	TC-651070	1		Screw, 10-32 x 1-1/4"
223	TC-650971	1		Screw, T-30 5/16-18 x 7/8"
224	TC-33515A	1		Intake Pipe Gasket (Pipe to Head) Kit
234	TC-650928	1		Lock Nut, 1/4-20
238	TC-650902	1		Screw, 10-32 x 7/16"
239	TC-36358	1	/P	Air Cleaner Gasket Kit
240	TC-37691	1		Air Cleaner Body Ass'y. (Incl. 239)
245	TC-37360	1	/P	Air Cleaner Filter (Paper)
245B	TC-37361	1	/P	Air Cleaner Pre-Filter (Poly)
246	TC-37407	1	/P	Connector Bushing Link
250	TC-37690	1		Air Cleaner Cover
251	TC-37689	1	/P	Wing Nut, 1/4-20 x 1-19/32"
255	TC-37776	1		Control Cover
330	TC-37739	1		Fuel Solenoid Wire Assembly (R & G)
330A	TC-37403	1		Fuel Solenoid Wire Assembly (Black)
330B	N/A	1		N/A
380	TC-640333	1		Carburetor (Incl. 184 & 428)
380A	TC-640335	1	/P	Carburetor Repair Kit
383	TC-37411	1		Carburetor Baffle
384	TC-30200	1	/P	Screw, 10-24 x 9/16" Self Tap
387A	TC-37397	1		Roll Pin
406	TC-611221	1	/P	Fuel Shut-Off Solenoid

14A9816P790 GT-950H (2005)
Hood

Page 23 of 31

Ref #	Part Number	Qty	S/P/F	Description
1	683-0305	1	S	Bracket Assembly, Hood
2	710-0376	1	/P	Hex Screw, 5/16-18, 1.00, Gr5
3	710-0599	1	/P	Screw, 1/4-20, 0.500
4	710-0642	1	/P	Screw, 1/4-20, 0.750
5	710-0895	1		Screw, 1/4-15, 0.750
6	710-0924	1	/P	Screw, Machine, 1/4-20, 0.750
7	710-3015	1	/P	Hex Screw, 1/4-20, .75, Gr5
8	712-0292	1	/P	Nut, Clip, 1/4-20
9	712-04063	1	/P	Nut, Flange Lock, 5/16-18, Grf, Nylon
10	712-04064	1	/P	Nut, Flange Lock, 1/4-20, Grf, Nylon
11	726-0201	1		Nut, Speed, .3125 ID
12	731-2283A	1	S	Hood
13	731-2286	1	S	Lens
14	731-2307B	1	S	Side Panel, LH
15	731-2308B	1	S	Side Panel, RH
16	731-2284	1		Hood Plenum
17	736-0173	1	/P	Washer, Flat, .28 x .74 x .063
18	736-0342	1		Washer, Flat, .283 x .75 x .030
19	736-3078	1	/P	Washer, Flat, .344 x 1.0 x .063
20	747-04301	1		Support, Side Panel
21	747-2127	1		Rod, Hood Latch
22	710-0726	1	/P	Screw, 5/16-12, 0.750
23	710-1017	1	/P	Screw, 1/4-14, 0.625
24	710-1611B	1	/P	Screw, 5/16-18, 0.750
25	710-3217	1	/P	Screw, Machine, #8-32, 0.375
26	712-0142	1	/P	Nut, Hex, #8-32
27	731-04213	1		Brake Lever
28	731-04214	1		Cruise Control Lever
29	731-05037	1		Dash Panel (Models w/ Electric PTO)
30	731-1857	1		Control Knob
31	736-0142	1	S	Washer, Flat, .281 x .50 x .063
32	747-1155	1		Rod, Brake / Cruise Pivot
33	783-04285B	1	S	Support Plate, Dash, RH
34	783-04323B	1	S	Support Plate, Dash, LH
35	783-0462	1	/P	Retainer Bracket, PTO Switch
36	751-0658E	1	/P	Fuel Tank, 3 Gal.
37	751-0603	1	S	Fuel Cap
38	711-0332	1	S	Pin, Clevis, .50 x .78
39	714-0145	1	S	Pin, Click, .092 x 1.64
40	768-0010B	1	S	Bumper
41	731-2234A	1	/P	Bellow
42	725-04227	1	S	Ignition Switch Module
43	725-04036A	1	S	Systems Indicator Monitor w/ Hour Meter
44	725-0963	1	S	Miniature Lamp, 12V
45	725-1649	1	S	Socket, Lamp
46	725-1744	1	S	Key, Ignition
	725-1745	1	S	Key w/ Plastic Cover, Ignition
47	746-1086	1	S	Throttle Cable, 39"
48	746-1085A	1	S	Choke Knob w/ Cable, 37.5"
	629-04083	1	S	Headlight Wire Harness (Not pictured)
	629-04104	1	/P	Tractor Wire Harness (Not pictured)
	735-04023	1		Cargo Net (Not pictured)
	726-04029	1		Net (Not pictured)

14A9816P790 GT-950H (2005)
Labels


Page 25 of 31

Ref #	Part Number	Qty	S/P/F	Description
777S30503	777S30503	1	/P	LABEL-DANGER CHUTE
777S32519	777S32519	1		LBL SAFETY HYDRO
777I20809	777I20809	1		LABEL-TRANS RELEAS
777X40219	777X40219	1		LABEL-LENS REFLECT
777I20881	777I20881	1		LABEL-DASH
777S30015	777S30015	1		
778-10609	778-10609	1		
778-10606	778-10606	1		
877S30036	877S30036	1		LBL RDR SFTY 50" M
777D08313	777D08313	1		
777D07662	777D07662	1		LABEL-HOODSIDE LH
777D08646	777D08646	1		LBL RDR WHITE
777D03484	777D03484	1	S	USE 777D09750 LABEL-RIDER HDS
77D03126	77D03126	1		
777D08745	777D08745	1	S	USE 777D09070 LBL RDR ENGINE
777D06874	777D06874	1		LABEL-ENGINE
777D07661	777D07661	1		LABEL-HOODSIDE RH
777D03399	777D03399	1		LABEL-FENDER DX70

14A9816P790 GT-950H (2005)
PTO & Battery

Page 27 of 31

Ref #	Part Number	Qty	S/P/F	Description
1	710-0726	1	/P	Screw, 5/16-12, 0.75
2	710-0859	1	/P	Screw, 3/8-16, 2.50, Gr5
3	710-3157A	1	/P	Screw, 7/16-20, 3.25, Gr5, Lock
4	712-04065	1	/P	Nut, Flange Lock, 3/8-16, Gr F, Nylon
5	717-04174	1	S	PTO Clutch, Electric
6	736-0277	1		Washer, Flat, 1.031 x 1.620 x .095
7	748-0415B	1	/P	Spacer, .385 ID x .635 OD x 1.54
8	756-0978A	1	S	Pulley, Engine, 3.56 Diameter
9	783-04419A	1	S	Clutch Bracket
10	783-04467	1		Deck Bracket, Up-Stop
11	710-0703	1	/P	Screw, Carriage, 1/4-20, .75, Gr5
12	712-0271	1	/P	Nut, Sems, 1/4-20
13	712-3087	1	/P	Nut, Wing, 1/4-20
14	725-1750A	1	S	Battery, 235 CCA
15	738-1132	1		Screw, Shoulder, .250 x .150, 1/4-20
16	683-04173	1	S	Frame Assembly, Lower
17	710-0607	1	/P	Screw, 5/16-18, 0.500
18	710-0642	1	/P	Screw, 1/4-20, 0.750
19	710-3005	1	/P	Screw, 3/8-16, 1.25, Gr5
20	712-04064	1	/P	Nut, Flange Lock, 1/4-20, Gr F, Nylon
21	712-3006	1	/P	Nut, Hex, 1/4-20, Gr5
22	732-04035	1		Spring, Compression, 1.28 OD x 3.125
23	736-0222	1	S	Washer, Lock, 1/4, External
24	736-0329	1	S	Washer, Lock, 1/4
25	738-04058	1		Spacer, Shoulder, .38 x 1.0 x .70
26	747-04121A	1		Hold Rod, Battery
27	783-0349	1		Battery Tray
28	783-04329A	1		Seat Bracket, Frame
29	783-04376A	1		Frame, Upper
30	710-0599	1	/P	Screw, 1/4-20, 0.50
31	725-1426	1	S	Solenoid, 12V, 100 Amp
32	738-1132	1		Screw, Shoulder, .250 x .15, 1/4-20
33	710-0703	1	/P	Screw, Carriage, 1/4-20, .75
34	712-3087	1	/P	Nut, Wing, 1/4-20
35	783-04612	1	S	Support Bracket, Steering



14A9816P790 GT-950H (2005)
Starter

Page 29 of 31

Ref #	Part Number	Qty	S/P/F	Description
	TC-37284	1	/P	Electric Starter (12 Volt)
1	TC-33841	1		Dust Cover
2	TC-33842	1		Retainer Ring
3	TC-33843	1		Spring Retainer
4	TC-33854	1		Anti-drift Spring
5A	TC-36853	1		Gear & Nut (Incl. 2)
8	TC-37354	1		Drive End Cap Assembly
9	TC-37355	1		Armature
14	TC-35897	1		Thrust Washer
15	TC-36856	1		Case Bolt
16	TC-37356	1		End Cap & Brush Card Ass'y (Incl.14,17 & 18)
17	TC-650168	1		Washer
18	TC-650864	1	/P	Nut

14A9816P790 GT-950H (2005)
Steering, Front Wheels & Axle

Page 31 of 31

Ref #	Part Number	Qty	S/P/F	Description
1	710-04095	1		Hex Screw, 3/8-16, 1.00, Gr5
2	710-0514	1	/P	Hex Screw, 3/8-16, 1.00, Gr5
3	710-0643	1	/P	Hex Screw, 5/16-18, 1.00, Gr5
4	711-1408	1		Link, Drag, RH
5	711-1409A	1	/P	Link, Drag, LH
6	712-0214	1	S	Nut, Hex Lock, 3/8-24
7	712-04065	1	/P	Nut, Flange Lock, 3/8-16, Grf, Nylon
8	712-0459	1	/P	Nut, Flange Lock, 7/16-20
9	712-3004A	1	/P	Nut, Flange Lock, 5/16-18, Gr5
10	712-0240	1	S	Nut, Jam, 7/16-20, Gr2
11	717-1550E	1	S	Gear, Steering, 11/90 Ratio
12	717-1554	1		Gear, Pinion, Steering
13	723-0448A	1	S	Ball Joint, 7/16-20, Lock
14	736-3004	1	S	Washer, Flat, .406 x .875 x .105
15	736-3084	1	/P	Washer, Flat, .51 x 1.12 x .06
16	710-0726	1	/P	Screw, 5/16-12, 0.750
17	738-04154	1		Spacer, Shoulder, .38 x 1.00 x .31
18	738-1001A	1	/P	Shaft, Steering, .625 OD x 24.25 Lg
19	741-0475	1	S	Plastic Bushing .380 ID
20	741-0656A	1	S	Hex Flange Bearing 5/8 PM
21	783-0726D	1	/P	Pivot Bracket, Support RH
22	783-0727C	1	/P	Pivot Bracket, Support LH
23	783-0728	1		Pivot Bracket, Bar
24	631-04008	1	S	Steering Wheel, 13.25
25	731-04040	1		Steering Wheel Cap, Round
26	738-1011	1	S	Shoulder Screw, .5 x 2.2, 3/8-16
27	731-2290A	1	/P	Deluxe Hub Cap
28	736-0316	1	S	Flat Washer, .78 x 1.589 x .06
29	714-04039	1		Cotter Pin, 5/32 x 1.25
30	719-04105	1	/P	Cast Iron Pivot Bar
31	726-0341	1	/P	Push Cap
32	638-04006	1	S	LH Axle Assembly, .750
33	638-04005	1	S	RH Axle Assembly, .750
34	711-0332	1	S	Pin, Clevis, .50 x .78
35	714-04023	1	S	Cotter Pin, Internal, .080 x 1.5625
36	783-0720A	1	S	Adjustment Bracket, Front
37	634-04088	1	S	Wheel Assembly Complete,
37	734-04148	1		Tire Only 16 x 7.5 x 8
37	634-04082	1	S	Rim Only w/ Valve Stem
38	738-0143	1	/P	Screw, Shoulder, .498 x .340, 3/8-16