



Components of Bag Assembly pn # 864-0251:



Components of Cover Assembly pn # 664-04018:



Ref #	Part Number	Qty	S/P/F	Description
1	17200A	1	S	Catcher Support Bracket
2	17247	1	S	Tubing Adapter
3	631-0221	1	S	Chute Elbow
4	664-04018	1		Cover Assembly (includes ref. 35 to 46)
5	683-0617	1		Bracket Assembly: Chute Stop
6	689-00002	1	S	Grasscatcher Support Assembly
7	710-0597	1	/P	Hex Bolt 1/4-20 x 1.0
8	710-0751	1	/P	Hex Bolt 1/4-20 x 0.625
9	710-3008	1	/P	Hex Bolt 5/16-18 x 0.75
10	710-3168	1	/P	Carriage Bolt
11	711-0309A	1	/P	Clevis Pin
12	711-04069	1	S	Grasscatcher Pin
13	712-0130	1	/P	Hex Lock Nut 3/8-16
14	712-0431	1	S	Flange Lock Nut 3/8-16
15	712-3004A	1	/P	Flange Lock Nut 5/16-18
16	712-3027	1	S	Flange Lock Nut 1/4-20
17	714-0117	1	/P	Hairpin Clip
18	723-04008A	1	/P	Chute Strap
20	723-0476	1		Chute Strap
21	731-0926B	1	/P	Catcher Tube
23	736-0253	1	S	Beleville Washer
24	736-0270	1	/P	Bell Washer
25	736-3092	1	/P	Flat Washer
26	738-0380	1	S	Shoulder Screw
27	742-04056	1	S	Blade
29	783-0601	1	S	Catcher Support Bracket
30	783-0673	1	S	Catcher Support Bracket RH
31	783-0764	1	S	Catcher Support Bracket LH
32	783-0765	1	S	Bracket: Cross Support
33	783-1501	1	S	Spacer
34	864-0251	1		Grasscatcher Bag Assembly
35	17202A	1		Screen Mounting Bracket
36	710-1652	1	/P	TT Screw 1/4-20 x 0.625
37	720-04018	1	S	Screen
38	726-04027	1		Push Nut
39	726-0479	1	/P	Ratchet Clip
40	728-0123	1	S	Pop Rivet
41	731-04166	1		Grass Bag Cover
42	731-04189	1	S	Retainer Seal
43	731-0824A	1	/P	Plastic Plate
44	735-04020	1	S	Grass Bag Seal
45	736-0400	1	S	Flat Washer
46	749-0747	1	S	Hinge Bracket
47	17201A	1	S	Bag Hanger Bracket
48	710-0473	1	/P	Machine Screw
49	710-0604A	1	/P	TT Screw 5/16-18 x 0.625
50	712-0272	1	/P	Hex Sems Nut
51	749-0745A	1	S	Tube: Grass Bag Frame
52	764-0251	1	S	Grassbag