


24AF510B790 LS-21W (2005-2)
General Assembly

Page 1 of 3



24AF510B790 LS-21W (2005-2)
General Assembly

Page 2 of 3

Ref #	Part Number	Qty	S/P/F	Description
1	718-0773	1		Hydraulic Cylinder
2	727-0634	1		Hydraulic Tube
3	710-1018	1	/P	Hex Cap Screw 1/2-20 x 2.75
4	737-0192	1	/P	90 Degree Solid Adapter
5	736-0371	1	/P	Flat Washer, .434 x .880 x .062
6	737-0153	1		Return Elbow
7	718-0481	1	S	Control Valve
8	736-0119	1	S	Lock Washer, 5/16
9	710-1806	1	/P	Hex Cap Screw 1/2-13 x 3.25
10	719-0550	1	S	Wedge Assembly
11	737-0238	1		Nipple Pipe 1/2-14
12	712-0239	1	S	Lock Nut 1/2-20
13	712-0711	1	/P	Hex Jam Nut 3/8-24
14	710-0459A	1	/P	Hex Cap Screw 3/8-24 x 1.5
15	781-0351	1	/P	Adjustable Gib
16	710-1260A	1	/P	LD Screw 5/16-18 x .75
17	781-1054	1	S	Cylinder Support Bracket
18	681-0173	1		Beam Assembly
19	736-0300	1	S	Flat Washer.406 ID x.875 OD
20	710-0654A	1	/P	Hex Washer Screw 3/8-16 x 1.0
21	781-0791	1	S	Dislodger
22	781-0790	1	S	Back Plate
23	736-0921	1	S	Lock Washer 1/2
24	737-0312	1		Adapter 3/4-14
25	727-0443	1		Return Hose 3/4" ID x 44"
26	726-0132	1	/P	Hose Clamp 5/8"
27	737-0316	1	/P	Filter Housing
28	710-3008	1	/P	Hex Screw, 5/16-18 x .75
29	710-0376	1	/P	Hex Screw , 5/16-18 x 1.0
30	712-04063	1	/P	Hex Flange Nut, Nylon, 5/16-18
31	736-0351	1	S	Flat Washer.760 ID x.500 OD
32	710-3056	1		Hex Bolt 5/16-18 x 3.25"
33	723-0405	1	/P	Oil Filter
35	781-1024	1	S	Mounting Bracket, Fender
36	710-1238	1	/P	Hex Screw, 5/16-18 x .875
37	711-1587	1		Clevis Pin
38	736-0116	1	S	Flat Washer.635 ID x.93 OD
39	714-0470	1	S	Cotter Pin
40	731-2496	1		Fender, Black
41	710-3097	1		Carriage Bolt 3/8-16 x 1.0
42	712-3017	1	S	Hex Nut 3/8-16
43	781-0682	1	S	Log Tray
44	781-0686	1	S	Log Tray Bracket
45	681-04040	1		Frame Assembly
46	726-0214	1	/P	Push Cap
47	732-0583	1		Compression Spring
48	710-0521	1	/P	Hex Bolt 3/8-16 x 3"
49	781-0690	1		Lock Rod
50	737-0348A	1	/P	Vented Dipstick
51	710-1338	1	/P	Hex Screw 5/16-24 x 3.25
53	634-0186	1	/P	Wheel Assembly
53	941-0987	1	/P	Cone Bearing
53	921-0168	1	/P	Washer

24AF510B790 LS-21W (2005-2)
General Assembly

Page 3 of 3

Ref #	Part Number	Qty	S/P/F	Description
54	712-0359	1	/P	Slotted Nut 3/4-16
55	714-0162	1	/P	Cotter Pin
56	734-0873	1		Hub Cap
57	719-0353	1		Coupling Shield
58	714-0122	1	S	Square Key 3/16" x.75
59	718-04145	1	S	Flexible Coupling
59	718-04392	1		Coupling, .5 Engine Side Not shown
59	718-04395	1		Coupling, .875 Pump Side Not shown
59	735-04103	1		Bushing, Spider Coupling Not shown
59	710-1842	1		Set Screw Not shown
60	737-04093	1		Inlet Filter
61	781-0789-0650	1		Jack Stand
62	781-0097	1	S	Rear Coupling Support Bracket
63	727-04103	1	S	Hose
64	718-04127	1	S	Gear Pump
65	737-0329	1		45° Elbow
66	727-0502	1		High Pressure Hydraulic Hose
67	781-0788-0650	1		Tongue Tube Assembly
68	747-1261	1		Tongue Latch Rod
69	781-1045-0650	1		Latch
70	715-0120	1	S	Spiral Pin
71	732-3127	1	S	Compression Spring
72	736-0169	1	S	L-Washer 3/8"
73	712-3022	1	/P	Hex Lock Nut 1/2-13
74	710-0944	1	/P	Hex Cap Screw 3/8-16 x 4.25
75	736-0262	1	/P	Flat Washer.385 ID x.870 OD
76	713-0433	1	S	Chain
77	750-0497	1		Spacer.375 ID x.625 OD
78	681-04030	1		Hitch Coupler
79	712-0375	1	/P	Hex Lock Nut 3/8-16
80	711-0813	1	S	Clevis Pin
81	736-0185	1	S	Flat Washer.375 ID x.738 OD
82	732-0194	1		Spring Pin
83	710-3038	1	/P	Hex Screw, 5/16-18 x .875
84	712-3010	1	S	Hex Nut, 5/16-18
85	781-0526	1		Hose Guard
86	781-0538	1	S	Hose Guard