


WH25CS 41ADW25C990
Engine Assembly

Page 2 of 4

Ref #	Part Number	Qty	S/P/F	Description
1	753-04511	1	/P	Air Cleaner Cover Assembly (includes 2 & 29)
2	791-180350B	1	/P	Air Cleaner Filter
3	791-180351	1		Carburetor Mounting Screw Assembly
4	791-180226	1	S	Wavey Washer
5	753-04418	1	/P	Choke Lever Assembly
6	753-04419	1	/P	Choke Plate Assembly (includes 5)
7	753-05133	1		Carburetor Assembly (includes 8 & 18)
8	791-610675	1		Carburetor Gasket
9	791-181860	1		Carb Mount Screw
10	791-683974B	1	/P	Primer & Hose Assembly
11	753-1196	1	/P	Carb Mount Assembly (includes 9, 12 & 13)
12	791-684451	1		Reed Assembly
13	753-05487	1	S	Carburetor O-Ring
14	791-612134	1		Rear Mounting Pad
15	753-04307	1	/P	Fuel Tank Assembly (includes 16-18)
16	791-182529	1		Fuel Cap Assembly
17	791-181086	1	/P	Fuel Return Line
18	753-04233	1		Fuel Line Assembly
19	791-145308	1		Front Mounting Pad
20	753-05091	1	/P	Shroud Extension & Stand (includes 29)
21	753-05240	1	/P	Flywheel Assembly
22	791-181525	1		Spacer
23	753-05801	1		Starter Housing Assembly (includes 24 & 29)
24	791-181862	1	/P	Housing Screw
25	791-182396	1	S	Clutch Washer
26	791-182369	1	S	Clutch Rotor Assembly
27	791-153592	1	/P	Clutch Drum Assembly
28	753-04403	1		Clutch Cover Assembly (includes 29-32)
29	791-181345	1	/P	Cover Screw
30	791-182519	1		Anti-Rotation Screw
31	753-04003	1		Clamping Screw
32	791-180217	1	S	Clamping Nut
33	753-05025	1	/P	Wire Leads and Sleeve
34	753-04336	1		Module Assembly
35	791-610311B	1	/P	Spark Plug
36	753-05169	1	/P	Muffler Assembly (includes 37, 38 & Spark Arrestor)
37	753-04619	1	/P	Exhaust Gasket
38	753-04620	1	S	Muffler Mounting Bolts
39	753-04814	1	/P	Cylinder Assembly (includes 41 & 42)
40	753-04367	1	/P	Piston and Rod Assembly
41	753-04182	1		Cylinder Gasket
42	791-182723	1		Cylinder Bolt
	753-1209	1		Piston Ring Set Not shown
	753-04812	1	/P	Short Block Assembly (includes Crankcase, 9, 35 & 39-42) Not shown
	791-181599	2		Clutch Springs Not shown



WH25CS 41ADW25C990
General Assembly

Page 4 of 4

Ref #	Part Number	Qty	S/P/F	Description
1	753-04234	1		Throttle Housing Assembly (includes 2-4)
2	753-04119	1	/P	Throttle Trigger
3	791-182690	1		Throttle Trigger Spring
4	791-182405	1	/P	Switch
5	753-04405	1	S	Throttle Cable
6	753-04236	1	/P	Upper Drive Shaft Housing Assembly
7	753-05461	1		D-Handle (includes 8)
8	791-181587	1	/P	D-Handle Hardware
9	791-181928	1		Split Boom Coupler (includes 10-13)
10	791-182057	1		Screw
11	791-181617	1		Bolt
12	791-181951	1	S	Adjustment Knob (includes 13)
13	753-04386	1	S	Knob Retaining Nut
14	791-182387	1		Lower Drive Shaft Housing Assembly (includes 16)
15	791-153597	1		Lower Clamp Assembly (includes 19)
16	791-181852	1	/P	Lower Flexible Drive Shaft
17	791-180531	1	S	Shield Mount Screw
18	791-181857	1		Bushing Housing Assembly
19	791-145569	1	/P	Anti-Rotation Screw
20	791-181659	1	/P	Shield Assembly (includes 21)
21	753-05212	1	S	Blade Assembly
22	791-181457	1		Outer Spool Assembly (includes 23)
23	791-181458	1		Retainer
24	791-181561	1		Thrust Washer
25	791-181459	1		Small Spring
26	753-04257	1	/P	Slider
27	791-181532	1		E-Clip
28	791-181531	1		Spring
29	791-181462	1		Plunger
30	791-181463	1		C-Clip
31	791-181464	1	S	Inner Reel
32	791-181465B	1		Large Spring
33	791-181467	1		Foam Seal
34	791-181468B	1	/P	Bump Head Knob Assembly (includes 32 & 33)
	753-04929	1		Cutting Head Assembly Not shown (includes 15, 18, 19 & 22-24)