For Parts Call 606-678-9623 or 606-561-4983

SECTION 11: PARTS LIST FOR T809H & Z809K



REF. NO.	PART NO.	DESCRIPTION
1	710-0227	Self-tapping Screw, #8-18 x 5
2	710-0599	Self-tapping Screw, 1/4-20 x 5
3	710-0726	AB Screw, 5/16-12 x 75
4	710-1237	Screw, #10-32 x .625
5	710-1314A	Socket Cap Screw, 5/16-18 x .625
6	710-1315	Self-tapping Screw, 3/8-16 x 1 25
7	712-3017	Hex Nut, 3/8-16
8	721-0460	Exhaust Gasket
9	726-0205	Hose Clamp
10	712-0271	Sems Nut
11	736-0300	Flat Washer
12	751B221535	Casing Clamp
13	751-0535	Fuel Line Hose
14	751-0564A	Muffler Deflector
15	751-0616A	Muffler, Twin Inlet
16	751-0650A	RH Exhaust Pipe
17	751-0651A	LH Exhaust Pipe
18	751-3140	Oil Drain Valve
19	751-3141	Oil Drain Hose
20	751-3142	Oil Drain Cap
21	783-0615C	Muffler Heat Shield
22	783-0625C	Engine Heat Shield
23	746-1086	Throttle Cable
24	725-0157	Cable Tie (not shown)

www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models Z809H & Z809K



www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models T809H & Z809K

REF. NO.	PART NO.	DESCRIPTION
1	783-1346	Grill Support Bracket (9-style)
2	710-0599	Self-tapping Screw, 1/4-20 x .5
3	710-0528	Hex Cap Screw, 5/16-18 x 1 25
4	710-0924	Phillips Pan Screw, 1/4-20 x .75
5	710-1017	Truss Phillips Screw, 1/4-20 x .625
6	725-1741	Ignition Switch
7	726-0272	Clamp, 9/16
8	710-0642	Self-tapping Screw, 1/4-20 x .75
9	712-0292	U-type Speed Nut, 1/4-20
10	736-0270	Bell Washer, .265 x .75 x .062
11	725-1976	Systems Indicator Monitor
	725-04036A	Hour Meter
12	712-3004A	Hex Nut, 5/16-18
13	731-2119A	Grille (9-style)
15	725-0175	Cable Tie, 3/16 x .05 x 7 4
16	746-1085A	Choke Knob/Cable
17	783-0783	Hood (9-style)
18	783-0784	RH Side Panel
19	783-04200	LH Side Panel
20	731-2637	Headlight Lens
21	747-2138	Hood Hinge Rod
22	625-0051	Headlight Assembly
23	710-0726	AB Screw, 5/16-12 x .75
24	751-0603	Fuel Cap
25	751-3213A	Fuel Tank, 3 gallon
26	725-1745	Ignition Key w/ plastic cover
	725-1744	Ignition Key w/o plastic cover
27	710-0895	Self-tapping Screw, 1/4-15 x .75
28	710-3217	Truss Phillips Screw, #8-32 x .375
29	712-0142	Hex Nut, #8-32
30	731-1857	Throttle Control Knob
31	731-2225C	Dash Panel, 8/9-style, Electric PTO
32	731-04215	Cruise Control Button
33	731-04217	Parking Brake Button
34	736-0142	Flat Washer, 9/32 x 1/2 x 1/16
35	747-1196	Brake/Cruise Pivot Rod
36	783-04285	Dash Support Plate RH
	783-04383	Dash Support Plate LH
37	712-3010	Hex Nut, 5/16-18
38	731-2270	Hood Plenum*
39	726-3046	Ratchet Clip
40	736-0119	Lock Washer, 5/16
41	726-0201	Speed Nut, .3125
42	736-3078	Flat Washer, .349 x 1.0 x .063
43	710-0650	TT Screw, 5/16-18 x .875
44	725-1752	Electric PTO Switch
45	711-0332	Clevis Pin, .50 x .78
46	768-0010	Bumper Assembly
47	714-0145	Click Pin
48	710-1611B	TT Screw 5/16-18 x 0 75
49	735-04019	Seal: Panel
50	747-04132	Tank Support Rod
51	735-04023	Cargo Net
52	726-3046	Ratchet Clip
53	629-04083	Headlight Wire Harness
54	629-04073	Tractor Wire Harness

*Not standard on all tractors.

www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models T809H & Z809K



www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models T809H & Z809K

REF. NO.	PART NO.	DESCRIPTION
1	747-1130B	Deck Stabilizer Rod (Model T809H)
	747-1324	Deck Stabilizer Rod (Model Z809K)
2	683-0197B	Lift Shaft Assembly (Model T809H)
	683-0462	Lift Shaft Assembly (Model Z809K)
3	711-0332	Clevis Pin, .5 x .78
4	712-0206	Hex Nut, 1/2-13
5	712-0431	Flange Lock Nut, 3/8-16
6	712-0429	Lock Nut, 5/16-18
7	712-3083	Hex Nut, 1/2-13
8	714-0104	Internal Cotter Pin
9	714-0145	Internal Cotter Pin
10	716-0106A	E-Ring
11	720-0311	Handle Grip
12	732-0874	Torsion Spring
13	732-1184	Extension Spring, .84 x 4.6
14	736-0275	Flat Washer, 5/16
15	736-0921	Lock Washer, 1/2
16	736-3019	Flat Washer, .31 x 1.062 x .134
17	736-3084	Flat Washer, .51 x 1.12 x .06
18	738-0138A	Hex Cap Screw, 5/16-18 x .62
19	738-0143	Shoulder Screw, 3/8-16
20	741-0225	Hex Flange Bearing
21	741-0715	Snap Flange Bearing
22	746-0968	Lift Cable, 16.16
23	747-1111A	Lift Handle
24	756-1154	Roller Pulley
25	783-0678A	Arm Lift
26	783-0720A	Deck Stabilizer Bracket
27	710-0260A	Carriage Bolt, 5/16 x .62
28	710-0726	AB Screw, 5/16-12 x .75
29	710-0895	Self-tapping Screw, 1/4-15 x .75
30	731-1990	Lift Lever Cover
31	731-1993	Cover w/ Cup Holder
32	736-3078	Flat Washer, .349 x 1.0 x .063
33	783-0677	Lift Adjustment Bracket
34	783-04331	Fender
35	783-1489	Seat Mounting Bracket
36	710-1268	Screw, #10-16 x .375
37	712-3027	Hex Flange Lock Nut, 1/4-20
38	720-0309A	Seat Adjuster Grip
39	731-04074	Spacer
40	732-0499	Compression Spring, .41 x 1.5
41	736-0275	Spring Washer, .265 x .562 x .025
42	736-0204	Flat Washer, .344 x .62 x .03
43	738-0137A	Shoulder Screw, .340 x .285,1/4-20
44	738-1007	Shoulder Screw, .50 x .50, 3/8-16
45	783-0611	Seat Stop
46	783-0738	Seat Pivot Bracket
47	783-0739	Seat Adjustment Lever
48	783-0753	Seat Adjustment Selector
49	757-04010	High Back Seat, Black
50	735-0656	RH Foot Pad
51	735-0657	LH Foot Pad
—	726-3046	Foot Pad Clips
52	714-0111	Cotter Pin
54	783-0209C	Seat Lift Bracket
55	710-0924	Phillips Pan Screw, 1/4-20 x .75
56	712-0292	U-type Speed Nut, 1/4-20
57	731-2480	Shift Lever Cover
58	738-0296	Shoulder Screw, .437 x .286
59	731-2618	RH Fender Flare
60	731-2619	LH Fender Flare
61	783-1478	Fender Clips
62	710-0599	TT Screw 1/4-20 x 0.5

www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models T809H & Z809K



www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models T809H & Z809K

REF. NO.	PART NO.	DESCRIPTION
1	710-1260A	Self-tapping Screw, 5/16-18 x .75
2	710-0604A	Self-tapping Screw, 16-18 x .625
3	783-0726B	RH Pivot Support Bracket
4	783-0727A	LH Pivot Support Bracket
5	783-0728	Pivot Bar Bracket
6	710-0514	Hex Cap Screw, 3/8-16 x 1
7	711-1408	RH Drag Link
8	711-1409A	LH Drag Link
9	712-0240	Jam Nut, 7/16-20
10	712-0214	Hex Nut, 3/8-24
11	712-0130	Lock Nut, 3/8-16
12	712-0459	Flange Lock Nut, 7/16-20
13	712-3004A	Flange Lock Nut, 5/16-18
14	717-1550E	Steering Gear, 11/90 Ratio
15	717-1554	Steering Pinion Gear
16	723-0448A	Ball Joint, 7/16-20
17	736-0169	Lock Washer, 3/8
18	736-3084	Flat Washer, .51 x 1 12 x .06
19	738-1001A	Steering Shaft, .625 OD x 24.4
20	741-0475	Plastic Bushing, .38 ID
21	741-0656	Hex Flange Bearing, 5/8
22	738-0372B	Shoulder Spacer, .38 ID
23	731-04008	Steering Wheel, Soft Grip, Three Spoke
24	731-04066	Steering Wheel Cap, Round
25	638-04003	LH Axle Assembly, 75 Diameter
26	638-04004	RH Axle Assembly, 75 Diameter
27	719-0525C	Cast Iron Pivot Bar w/ Fittings, .75
29	714-0162	Cotter Pin
30	726-0341	Push Cap, .750
31	736-0242	Bell Washer, 34 x .872
32	736-0316	Flat Washer, .78 x 1 59 x .06
33	736-0285	Flat Washer, .635 x 1.589 x .06
34	738-1011	Shoulder Screw, 5 x 2.2, 3/8-16
35	710-0643	Hex Bolt, 5/16-18 X 1
36	634-04088	Wheel Assembly Complete, 16 x 6.5 x 8
	634-04082	Rim Only w/ Plastic Bearing
	734-0255	Air Valve (Not Shown)
	734-1727	Tire Only, Square Shoulder
	741-0516A	Flange Bearing
	741-0990A	Flange Bearing w/ Grease Fitting
37	734-2290A	Hub Cap
38	783-0653E	Steering Support Bracket
39	738-0143	Shoulder Screw, 3/8-16
40	736-0331	Bell Washer, .39 x 1.13 x 062
41	710-04095	Hex Bolt 3/8-16 x 1.0 Special

www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models T809H & Z809K



* Refer to pages 36 and 37 for break-down of this assembly

www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models T809H & Z809K

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	618-0376A	Transmission Assembly: Two Speed	43.	712-3027	Flanged Lock Nut
2	618-04148	Variable Speed Pulley Assembly	44.	718-04012	Cup: Bearing
3.	647-04023	Shift Rod Assembly	45.	736-0362	Flat Washer
4.	710-0176	Hex Bolt 5/16-18 x 2.75	46.	741-0600	Ball Bearing
5	710-0347	Hex Bolt 3/8-16 x 1.75	47.	656-0059A	Variable Speed Pulley
6	710-0642	TT Screw 1/4-20 x 0 75	48.	735-3049	Brake Pad
7.	710-0726	AB Screw 5/16-12 x 0.75	49.	783-0773A	Brake Pedal
8.	710-0805	Hex Bolt 5/16-18 x 1 5	50.	736-3008	Flat Washer
9.	710-0809	TT Screw 1/4-20 x 1.25	51.	710-1611B	TT Screw 5/16-18 x 0.75
10.	710-1007	TT Sems Screw 3/8-16 x 1 5	52	710-0650	TT Screw 5/16-18 x 0.875
11.	710-3011	Hex Bolt 3/8-16 x 2 25	53.	741-3065B	Hex Flange Bearing: Split
12.	712-0130	Lock Nut 3/8-16	54.	647-0031C	Brake Control Assembly
13.	712-0241	Hex Nut 3/8-24	55.	732-0963	Extension Spring
14	712-0702	Flanged Nut	56.	735-0662	Control Pad
15.	712-3004A	Flanged Lock Nut	57	683-0266	Drive Pedal Assembly
16.	714-0111	Cotter Pin	58.	710-1260A	LD Screw 5/16-18 x 0.75
17.	718-0771A	Pulley Hub	59.	647-0032A	Speed Control Assembly
18.	720-04028	Shift Knob	61.	712-0130	Hex Lock Nut 3/8-16
19.	723-3018	Ball Joint	62	711-04159	Pin
20.	732-0478	Extension Spring	64.	738-0155	Shoulder Screw
21.	732-0716	Extension Spring	65	783-0653F	Steering Support Bracket
22.	732-0963	Extension Spring	66.	741-0225	Hex Flange Bearing
23	736-0105	Bell Washer	67.	726-04028	Push Nut
24.	736-0169	Lock Washer 3/8	68.	732-0335	Compression Spring
25.	736-0642	Flat Washer	69.	712-3004A	Flange Lock Nut
26.	738-0322	Shoulder Screw	70.	783-0732	Lock-Out Bracket
27	738-0372B	Shoulder Spacer	71.	783-0780B	Neutral Return Bracket
28	747-04136	Brake Rod	72.	736-0262	Flat Washer
29.	747-1127	Rod: Idler Adjustment	73	748-04039	Cruise Latch
30.	747-1185	Rod: Belt Guard	74	738-0380	Shoulder Screw
31.	750-0566A	Spacer	75.	732-0955	Extension Spring
32	754-0467	Belt: V Type	76.	714-0104	Cotter Pin
33.	754-0468	Belt: V Type	77.	747-04093	Brake Lock Rod
34.	756-0665	Pulley	78.	747-04096	Cruise Control Rod
35.	756-0981A	Idler Pulley: Flat	79.	634-0104	Wheel Assembly
36	783-04442	Idler Bracket: Center Double		634-0070	Rim Assembly
37.	783-0667B	Torque Bracket		734-0255	Air Valve
38.	783-0669	Idler Bracket		734-1730	Tire
39.	783-0693	Axle Bracket		734-2290A	Hub Cap
40	618-04152	Bracket: Variable Speed		736-0430	Flat Washer
41.	710-0627	Lock Bolt 5/16-24 x 0.75	80.	712-3050	Lug Nut 7/16-14
42.	710-3015	Hex Bolt 1/4-20 x 0.75	81.	712-3026	Jam Nut

IMPORTANT: For a proper working machine, use Factory Approved Parts. **V-belts** are designed to engage and disengage safely. A substitute (non OEM) V-belt can be dangerous by not disengaging completely.

www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models T809H & Z809K



www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models T809H & Z809K

REF. NO.	PART NO.	DESCRIPTION
1	618-0225	Reverse Collar Assembly
2	618-0226	Hi-Lo Collar Assembly
3	618-0227A	Shift Fork Assembly
4	710-0642	Self-tapping Screw, 1/4-20 x .75
5	718-04053	Shft. Cover
6	736-0227	Flat Washer
7	710-3119	Lock bolt 3/8-16 x 0.75
8	741-0681	Ball Bearing
9	618-0365	Wheel Hub Assembly
10	618-0368	Differential Axle Assembly
11	719-0379A	Upper Housing
12	741-0476	Flanged Bearing
13	661-0012	Brake Assembly
14	741-04085	Flanged Bearing
15	710-0788	TT Screw 1/4-20 x 1.0
16	711-1051A	Drive Shaft
17	711-1216	Output Shaft
19	713-0446	9-tooth Sprocket
20	713-0447	16-tooth Sprocket
21	713-0448	22-link Chain, .625
22	716-0131	External Snap Ring
23	717-0678	Brake Pad
24	717-1438	41-tooth Bevel Gear
25	717-1439	20-tooth Spur Gear
26	717-1440	10-tooth Spur Gear
27	717-1441	27-tooth Spur Gear
28	717-1442	37-tooth Spur Gear
30	718-0504	Shifter Insert
31	718-0505	Shifter Cover
33	719-0385	Lower Housing
34	718-0540	Lockout Plate
35	736-0337	Flat Washer, 5/8 x 1 0
36	736-3046A	Flat Washer, 1 01 x 1.86 x .060
37	711-1235	Input Shaft
38	747-1140	Shift Lever
40	761-0215	Disc Brake
41	716-0114	Retaining Ring, .56
42	717-1463	13-tooth Bevel Gear
43	736-0335	Flat Washer
44	736-0336	Flat Washer, 5/8 x 1.0 x .030*
	736-0337	Flat Washer, 5/8 x 1.0 x . 040*
	736-0349	Falt Washer,5/8 x 1.0 x .020*
46	741-0335	Needle Bearing
47	741-0696	Needle Bearing
48	716-0231	E-ring, .75
49	618-0376A	Transmisssion Assembly Complete

NOTE: *Transmission has a grease capacity of 32 oz. Order part number 737-0148.*

NOTE: *Upon reassembling transmission input shaft for any reason, refill its cavity with approximately 2/3 oz. of grease. Order part number 737-0289.*

www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Model T809H



Ref.No.	Part No.	Description
1.	783-0653E	Steering Support Bracket
2	647-0064	PTO Lever Engagement Assembly
3.	683-04060	Engagement Plate Assembly
4.	710-1002	Hex Bolt 7/16-20 x 2.0
5.	710-0276	Carriage Screw 5/16-18 x 1.0
6.	710-0344	Hex Screw 3/8-16 x 1.5
7.	710-0726	AB Screw, 5/16-12 x .75
8.	710-3261	Hex Screw 3/8-16 x 7 0
10.	712-0431	Flange Lock Nut
11.	712-3004A	Flange Lock Nut
12.	712-3010	Hex Nut
13.	714-0470	Cotter Pin
14	726-0201	Speed Nut
15	710-3025	Hex Cap Screw 5/16-18 x .625
16.	732-0944	Extension Spring
17.	732-0991A	Belt Guard
18.	732-1013	Belt Guard
19.	725-1706	12 V Battery
20	710-0751	Hex Cap Screw, 1/4-20 x .62
21.	712-0271	Hex Sems Nut, 1/4-20
22.	712-3087	Wing Nut, 1/4-20
23.	725-1426	Solenoid, 12-Volt, 100 Amp
24.	710-0599	Self Tapping Screw, 1/4-20 x .5
25.	736-0222	Lock Washer, 1/4
26	783-1033A	Hitch Plate
27.	748-0415B	Spacer
28.	741-0708	Hex Split Flange Bearing
29.	783-0349	Battery Tray
30.	712-0459	Flange Lock Nut, 7/16-20
31	783-04467	Deck Stop
32	710-0604A	Self Tapping Screw, 5/16-18 x .625
33.	732-3080	Compression Spring, 1 28 x 3.5
34.	723-0444	Battery Strap
35	738-1020	Shoulder Screw, .625 x .5, 7/16-20

Ref.No.	Part No.	Description
36.	736-0407	Bell Washer, .45 x 1 0 x .062
37.	738-1132	Shoulder Screw
38.	754-0228	PTO Belt
40	783-0693	Axle Bracket
41.	712-3006	Hex Nut 1/4-20
42	736-0329	Lock Washer
43.	710-0607	TT Screw 5/16-18 x 0.5
44.	710-0642	TT Screw 1/4-20 x 0.75
45.	725-1657A	Switch
46.	17962	Switch Plate
47.	710-0224	AB Screw #10-16 x 0 5
48	683-0304C	Lower Frame Assembly
49.	711-1428	Belt Guard Pin
50.	712-0229	Push Nut Retainer
51.	731-2111A	PTO Knob
52.	736-0108	Flat Washer
53	736-0119	Lock Washer
54	736-0140	Flat Washer
55	736-0242	Bell Washer
56.	736-0258	Flat Washer
57.	736-0275	Flat Washer
58.	736-0300	Flat Washer
59.	736-3072	Flat Washer
60.	738-0372B	Shoulder Spacer
61	747-1112D	Deck Engagement Handle
62.	747-1243	Belt Keeper Rod
63.	756-0487	Idler Pulley
64.	756-0627B	Idler Pulley
65	783-0744A	Bracket
66	736-0119	Lock Washer
67	736-0171	Lock Washer
68.	736-0322	Flat Washer
69.	750-0956	Spacer
70.	756-1182A	Engine Pulley

www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Model Z809K



REF. NO.	PART NO.	DESCRIPTION
1	783-0653E	Steering Support Bracket
2	754-0476	PTO Belt
3	717-1774	Elec. PTO Clutch (Mod. Z809K)
4	783-1487	PTO Clutch Anti-rot. Brakt.
5	710-0859	Hex Cap Screw, 3/8-16 x 2.5
6	710-0726	Hex Hd Wash. Screw, 5/16-18 x .875
7	712-0431	Flange Lock Nut, 3/8-16
8	732-0978	Extension Spring, .62 x 5.62
9	712-3004A	Flange Lock Nut, 5/16-18
10	710-3180	Hex Cap Screw, 5/16-18 x 1.75
11	712-3010	Hex Nut, 5/16-18
12	683-0294	Idler Bracket Assembly
13	738-3056	Shoulder Screw, 1/2 x 2.5
14	710-3144	Hex Cap Screw, 3/8-16 x 2.0
15	710-3025	Hex Cap Screw, 5/16-18 x .625
16	738-0785	Shoulder Spacer, 1.38 x .445 x .36
17	736-0171	Lock Washer, 7/16
18	710-3157	Hex Cap Screw, 7/16-20 x 3.25
19	725-1706	12-volt Battery, 270 CCA
20	710-0751	Hex Cap Screw, 1/4-20 x .62
21	712-0271	Hex Sems Nut, 1/4-20
22	712-3087	Wing Nut, 1/4-20
23	725-1426	Solenoid, 12-Volt, 100 Amp
24	710-0599	Self Tapping Screw, 1/4-20 x .5
25	736-0222	Lock Washer, 1/4
26	783-1033A	Hitch Plate
27	748-0415B	Spacer, 3/8 x 1.54
28	756-0627B	Idler Pulley, 3.5
29	783-0349	Battery Tray
30	712-0459	Flange Lock Nut, 7/16-20
31	783-04467	Deck Stop
32	710-0604A	Self Tapping Screw, 5/16-18 x .625
33	732-3080	Compression Spring, 1.28 x 3.5
34	723-0444	Battery Strap
35	738-1020	Shoulder Screw, .625 x .5, 7/16-20
36	736-0407	Bell Washer, .45 x 1.0 x .062
37	738-1132	Shoulder Screw, 1/4-20, .25 x .15
38	736-0322	Flat Washer, .45 x 1.25 x .164
39	629-04047	Harness Assembly, PTO Clutch
40	783-0693	Axle Bracket
41	712-3006	Hex Nut 1/4-20
42	736-0329	Lock Washer
43	710-0607	TT Screw 5/16-18 x 0.5
44	710-0642	TT Screw 1/4-20 x 0.75
45	725-1657A	Switch
46	17962	Switch Plate
47	710-0224	AB Screw #10-16 x 0.5
48	683-0304C	Lower Frame Assembly
49	712-0429	Lock Nut 3/8-16

www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Model T809H



www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Model T809H

Ref. No.	Part No.	Description
1	17116	Deck Brake Assembly
2	17258D	Belt Cover
3	17982	Spindle Plate
4	618-0430A	Spindle Assembly: Pulley w/ftg.
5.	618-0595	Spindle Assembly: Double Pulley
6.	683-0254	Bracket Assembly: Deck Hanger LH
7.	683-04121	Deck Assembly 46" SD w/Nozzle
8	710-0344	Hex Bolt 3/8-16 x 1 5
9	710-0501	Hex Bolt 1/4-20 x 2.0
10.	710-0514	Hex Bolt 3/8-16 x 1.0
11.	710-0528	Hex Bolt 5/16-18 x 1 25
12	710-0599	TT Screw 1/4-20 x 0 5
13	710-0650	TT Screw 5/16-18 x 0.875
14.	710-0751	Hex Bolt 1/4-20 x 0 620
15.	710-0805	Hex Bolt 5/16-18 x 1 5
16.	710-1260A	LD Screw 5/16-18 x 0 75
17	710-3180	Hex Bolt 5/16-18 x 1 75
18	711-04069	Grass Catcher Pin
19	711-0993	Belt Guard Pin
20.	711-1554	Pin 1/4-20
21.	712-0324	Hex Lock Nut 1/4-20
22.	712-0417A	Flange Nut
23	712-0429	Lock Nut 5/16-18
24	712-0431	Flanged Lock Nut 3/8-16
25	712-0641	Hex Nut M16
26.	712-3006	Hex Nut 1/4-20
27.	712-3010	Hex Nut 5/16-18
28.	712-3083	Lock Nut 1/2-13
29	714-0470	Cotter Pin
30	717-04074	Gear: Deck Adjustment
31.	726-0233	Push Nut
32.	732-0306A	Compression Spring
33.	732-0429A	Extension Spring
34	732-0594A	Extension Spring
35	732-1165	Extension Spring
36.	734-04039	Deck Wheel 5.0 dia. Ball
37.	734-0973	Deck Wheel 5.0 x 1 38
38.	736-0119	Lock Washer
39.	736-0270	Bell Washer
40.	736-0418A	Flat Washer
41.	736-0760	Lock Washer
42	737-04003B	Water Nozzle
43	738-0347	Shoulder Spacer
44.	738-0373	Shoulder Screw 3/8-16
45.	742-0611A	Blade: 16.28" Three in One
46.	742-0612A	Blade: 14.88" Three in One
47.	746-1107	Cable: Bracket
48	747-1116	Rod: Deck Release Handle
49.	747-1130B	Rod: Front Adjustment
50	748-0234	Shoulder Spacer
51.	750-1291	Spacer
52.	754-0228	Belt: V Type
53.	754-0349	Belt: V Type
54.	756-0627B	Idler Pulley
55	771-11725A	Label: Danger Tag
56	783-0139A	Idler Bracket
57	783-0141	Deck Skirt: Center
58	783-0142	Deck Skirt RH
59.	783-1025	Chute Stop
60.	783-1347B	Belt Cover
61	619-0042	Spindle Housing
	17983	Bearing
	738-1128	Spindle Shaft
	741-0919	Ball Bearing
62.	756-1214	Deck Pulley: Double
63.	756-1187	Deck Pulley
64.	726-0106	Speed Nut
65	711-0792	Hinge Pin
66.	703-1693A	Mounting Bracket
67.	732-0602	Torsion Spring
68.	731-1032B	Chute Deflector: Side Discharge

IMPORTANT: For a proper working machine, use Factory Approved Parts. **V-belts** are designed to engage and disengage safely. A substitute (non OEM) V-belt can be dangerous by not disengaging completely.

www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Model Z809K



www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Model Z809K

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	12650	Bracket, Adjustment, Height	43	731-0335	Roller, Deck
2	16606	Bracket, Hook, Retainer	44	731-3005	Front Roller
3	618-0671	Spindle Assembly, Pulley, 5 39 Dia x .5625	45	731-3131A	Deflector, Chute
4	683-0254	Bracket Assembly, Deck, Hanger LH	46	732-0306	Spring, Compression, .406 x .531 x 1 75
5	683-0459	Idlr Assembly, 54"	47	732-0459	Spring, Extension, .94 Dia x 6.74
6	683-0608	Bracket Assembly, Lift, 54"	48	732-0934	Spring, Extension, 1.15 Dia x 5.99
7	683-0609	Bracket Assembly, LH-Front	49	732-3070	Torsion Spring .44 I d x 2.10
8	683-0610	Bracket Assembly, RH-Front	50	734-04039	Deck Wheel, 5" Dia
9	683-0617	Stop Assembly, Chute	51	736-0119	Lock Washer
10	703-2093	Baffle, RR, Inner	54	736-0760	Lock Washer
13	710-0216	Hex Screw 3/8-16 x 0.75	55	736-0921	Lock Washer
14	710-0514	Hex Screw 3/8-16 x 1.0	56	736-3039	Flat Washer .406 ID X 1 5 x 11ga
15	710-0528	Hex Screw, 5/16-18 x 1.25	57	736-3072	Washer, Flat .38 ID x.93 OD x.110
16	710-1260A	LD Screw 5/16-18 x 0.75	58	737-04003B	Water Nozzle: Deck Wash-Out System
17	710-0726	AB Screw 5/16-12 x 0.75	59	738-0295	Shoulder Screw, .750 x .47 12
20	710-3011	Hex Screw, 3/8-16 x 2.25	60	738-1229A	Shoulder Screw
21	710-3073	Hex Screw, 5/16-18 x 2 25	61	738-0373	Shoulder Screw
22	710-3168	Bolt, Carriage, 3/8-16 x 1.0	62	742-0677	Blade, 18.50"
23	710-3178	Short Neck Carriage Bolt 3/8-16 x .75	63	747-1116	Deck Release Handle Rod, .375 Dia
24	711-0332	Pin, Clevis, .50 Dia x .78	64	750-0151	Spacer .550 ID x .755 OD x 1.1
25	711-1737	Pin, Roller, .5" Dia x 10.06 .	65	750-0212	Spacer, .82 ID x 1 00 OD x .53
26	711-1762	Pin, Hinge, Dia .375 x 14 06	67	754-0642	Belt, V-Type, B Section
27	712-0229	Push Nut Retainer	68	756-3105	Pulley, Idler, 5.0 Dia.
28	712-0417A	Nut, Hex Flange, 5/8-18	69	783-04013A	Bracket, Stabilizing
29	712-0130	Nut, Lock, 3/8-16	70	683-04127	Deck Assembly SD: 54" w/ Water Nozzle
30	712-0641	Hex Nut M16		783-04232	Deck: SD w/Water Nozzle Ftg
31	712-0429	Nut, Flange Lock, 5/16-18	71	783-1453	Bracket, Mounting, 54" Roller
32	712-3010	Nut, Hex, 5/16-18, Gr5	72	783-1454	Bracket, Roller, Front
33	712-3022	Nut, Hex Lock, 1/2-13	73	783-1455	Bracket, Idler
35	714-0145	Pin, Click, .092 x 1.64	74	783-1470	Cover, Spindle RH
36	714-0470	Pin, Cotter, 1/8 x 1 25	75	783-1471	Cover, Spindle LH
37	714-3004	Pin, Cotter, 3/32 x 1.25	76	783-1482	RH Skirt
38	715-0108	Pin, Spring 1/4 Dia x 1.00	77	783-1483	LH Skirt
39	714-0162	Cotter Pin	78	783-1484	LH Extension Skirt
40	717-1553B	Adjustment, Deck, Gear	79	703-3279	Chute Stop (not shown)
41	721-04041	Water Nozzle Adaptor			

IMPORTANT: For a proper working machine, use Factory Approved Parts **V-belts** are designed to engage and disengage safely. A substitute (non OEM) V-belt can be dangerous by not disengaging completely.

NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Powder Black, the part number to order would be 700-xxxx-0637

Red: 0638
Oyster Gray: 0662
Powder Black: 0637

www.mymowerparts.com