For Parts Call 606-678-9623 or 606-561-4983

TORO

Count on it.

Part's Catalog

LX420 & LX460 Lawn Tractors

Model No. 13AX60RG744
Model No. 13AX60RH744



Original Instructions (EN)
769-02255 (01/31/06)

www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models X60RG & X60RH



REF. NO.	PART NUMBER	DESCRIPTION
1	734-1730-0901	Turf Tire, 20 x 8.0 x 8
2	934-0070-4009	Rim, 8.0 x 7.0
3	634-0104-0991	Wheel Assembly, 20 x 8.0 x 8
4	734-1731-0901	Tire, 15.0 x 6.0 x 6.0
5	934-04081-4009	Rim Assembly, 6.0 x 4.5 (Includes Bearings and Valve)
6	634-04086-0991	Wheel Assembly, 15.0 x 6.0 x 6.0
7	731-2290A	Hub Cap
—	934-0255	Valve, Tubeless

www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models X60RG & X60RH



REF. NO.	PART NUMBER	DESCRIPTION
1	683-04079-4008	Shaft Assembly, Lift
2	911-0332	Pin, Clevis, .50 Dia x .78 Lg
3	783-0720A-4008	Bracket, Deck (Model X60RH)
4	712-04065	Nut, Nylon Lock, 3/8-16
5	712-04063	Nut, Nylon Lock, 5/16-18, Gr5
6	712-3083	Nut, Hex Lock, 1/2-13, Gr8, Nylon
7	914-0104	Pin, Cotter, .072 Dia. x 1.13 Lg
8	914-0111	Pin, Cotter, 3/32, 1.0
9	914-04023	Pin, Click, .092 x 1.64 Lg
10	716-0106A	E-ring, .625 Dia. Shaft
11	720-0311	Grip, Handle
12	732-0874	Spring, Torsion
18	738-0138A	Screw, Hex Cap, 5/16-18x.620 Gr2
19	938-0143	Shoulder Screw, 3/8-16
20	941-0225	Bearing, Hex Flange
22	746-0968	Cable, Lift, 16.16 Lg
23	747-04155	Handle, Lift
24	747-1130B	Rod, Deck .5" Dia. (Model X60RH)
25	756-1154	Pulley, Roller
26	783-04963-0637	Arm, Lift (Model X60RH)
27	783-04568-0637	Hanger Bracket, Deck (Model X60RG)
28	747-04269A	Rod, Deck, .448" Dia. (Model X60RG)
29	783-04494-0637	RH Arm, Lift (Model X60RG)
30	783-04711-0637	LH Arm, Lift (Model X60RG)
31	748-04069	Pivot Cup
32	912-0206	Nut, Hex, 1/2-13
33	738-04130	Shoulder Screw, 3/8-16

www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models X60RG & X60RH



www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models X60RG & X60RH

REF. NO.	PART NUMBER	DESCRIPTION
1	710-0514	Hex Cap Screw, 3/8-16, 1.00, Gr5, Std
2	711-1408	Link, Drag, RH
3	711-1409A	Link, Drag, LH
4	910-0643	Screw, 5/16-18 x 1.00
5	912-0240	Nut, Jam, 7/16-20, Gr2
6	912-0214	Nut, Hex, 3/8-24, Gr5
7	712-04065	Nut, Nylon Lock, 3/8-16
8	712-0459	Nut, Flange Lock, 7/16-20
9	912-3004A	Nut, Flange Lock, 5/16-18
10	717-1550E	Gear, Steering, 11/90 Ratio
11	717-1554	Gear, Pinion, Steering
12	923-0448A	Ball Joint, 7/16-20
13	710-04095	Hex Cap Screw, 3/8-16, 1.00
14	936-3004	Washer, Flat, .406 x .875 x .105
15	936-3084	Washer, Flat, .510 x 1.120 x .060
16	731-05542	Cover, Steering Wheel
17	738-04154	Spacer, Shoulder, 1.00 x .38 x .38
18	738-04075	Shaft, Steering, .625 OD x 25.00 Lg
19	941-0475	Bushing, Plastic, .380 ID
20	941-0656A	Bearing, Hex Flange, 5/8
21	638-04003P	Axle Ass'y, LH .750 Dia (Model X60RH)
	938-04005	Axle Ass'y, LH .750 Dia (Model X60RG)
22	938-04004	Axle Ass'y, RH .750 Dia (Model X60RH)
	938-04006	Axle Ass'y, RH .750 Dia (Model X60RG)
23	726-0341	Push Cap, .75
24	714-04039	Pin, Cot, 5/32, 1.25
25	919-04105	Axle, Pivot, Cast .750 Dia
26	736-0866	Washer, Flat, .755 x 1.92 x.060
27	738-1011A	Screw, Shoulder, .500 x 2.230, 3/8-16
28	631-04008A	Wheel, Steering, Three Spoke

www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models X60RG & X60RH



www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models X60RG & X60RH

REF. NO.	PART NUMBER	DESCRIPTION
1	17962	Plate, Switch
2	683-04173-0637	Frame Assembly, Lower
3	783-0349-0637	Tray, Battery
4	910-0224	Screw, Hex Washer, 10-16 x .5
5	910-0726	Screw, Self-tapping, 5/16-18, 0.75
6	910-1260A	Screw, Self-tapping, 5/16-12, 0.75
7	910-1652	Screw, Hex Washer, 1/4-20 x 0.625
8	747-04121A	Hold-down Rod, Battery
9	712-04065	Nut, Nylon Lock, 3/8-16
10	710-0607	Screw, Hex Wash. Tapp, 5/16-18 x .5
11	710-0703	Screw, Carriage, 1/4-20, .75,
12	925-04039	Switch, Interlock
13	732-04035	Spring, Compression, 1.28 OD x 3.125
14	936-0222	Washer, Lock, Ext 1/4
16	738-04058	Shoulder Spacer
17	738-0143	Shoulder Screw, 3/8-16
18	910-3005	Hex Screw 3/8-16 x 1.25
19	783-0726E-0637	Bracket, Pivot, Support RH
20	783-0727D-0637	Bracket, Pivot, Support LH
21	783-0728-0637	Bracket, Pivot, Bar
22	783-04811-0637	Frame, Upper
23	783-04329A-0637	Bracket, Frame, Seat
24	712-04064	Nut, Nylon Lock, 1/4-20
25	910-0599	Screw, Self-tapping, 1/4-20, 0.500
26	925-1426A	Solenoid, 12V, 100 Amp
27	936-0222	Washer, External Lock, 1/4
28	910-0642	Screw, Hex. 1/4-20 x .75
29	925-1707D	Battery, 190 CCA
30	712-0324	Nut, Sems, 1/4-20

www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models X60RG & X60RH



www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models X60RG & X60RH

REF. NO.	PART NUMBER	DESCRIPTION
1	910-0227	Screw, #8-18, 0.500
2	910-0528	Screw, 5/16-18, 1.25
3	910-0599	Screw, 1/4-20, 0.500
4	710-0604A	Screw, 5/16-18, 0.625
5	710-0788	Screw, 1/4-20, 1.000
6	710-0895	Screw, 1/4-15, 0.750
7	910-0932	Screw, Carriage, 1/4-20, 1.00, Gr1
8	912-0271	Nut, Sems, 1/4-20
9	712-04063	Nut, Flange Lock, 5/16-18, GrF, Nylon
10	731-05498A	Cover, Lift Lever
11	731-05515A	Cover, w/ Cup Holder
12	726-0279	Plate, Insulator
13	925-1303	Spring Switch, Outer
14	725-1439	Spring Switch, Inner
15	726-0278	Plate, Insulator Boss
16	926-3046	Clip, Ratchet, .250 Dia
17	736-0607	Washer, Lock, 5/16 Ext. Tooth
18	936-3078	Washer, Flat, .344 x 1.0 x .063
19	783-04477A-4008	Fender
20	783-0677B-4008	Lift Bracket, Adjustment
21	783-1489A-0637	Seat Bracket
22	720-04061	Knob, 3/8-16, .875
23	732-1184	Spring, Extension, .80 Dia x 4.6 Lg.
24	938-0296	Shoulder Screw .437 x .286 Lg
25	738-04012A	Shoulder Screw, .625 x .145, 3/8-16
26	783-04081A-0637	Pivot Bracket, Seat
27	783-0209D	Bracket, Seat Lift
28	757-04044	Seat, *Toro* Medium Back
29	735-0656	RH Foot Pad
30	735-0657	LH Foot Pad
31	735-0690	Grommet
32	750-3310	Spacer, Flange, .3125 x .4375 x .625

www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models X60RG & X60RH



www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models X60RG & X60RH

REF. NO.	PART NUMBER	DESCRIPTION
1	910-0599	Screw, 1/4-20, 0.500
2	910-0642	Screw, 1/4-20, 0.750
3	910-0726	Screw, 5/16-12, 0.750
4	710-0895	Screw, 1/4-15, 0.750
5	710-1017	Screw, 1/4-14, 0.625
6	710-1611B	Screw, 5/16-18, 0.750
7	710-3217	Screw, #8-32, 0.375
8	712-0142	Nut, Hex, #8-32
9	931-04215	Lever, Cruise
10	931-04217	Lever, Parking Brake
11	731-05491	Dash Panel
12	731-1857	Knob
13	936-0270	Washer, Bell, .265 x .75 x .062
14	747-1196	Rod, Lever
15	783-04285D-0637	Support, Dash, RH
16	783-04323D-0637	Support, Dash, LH
17	783-0462	Bracket, PTO
18	931-05461	Hood
19	910-0623	Screw, 3/8-16, 0.750
20	731-05478	Grill
21	738-04091	Screw, Shoulder, .43 x .29, 5/16-18
22	783-04606A-4008	Pivot Bracket
23	783-04840-4008	Pivot Bracket, Hood RH
24	783-04841-4008	Pivot Bracket, Hood LH
25	783-05119-4008	Support Bracket, Hood
26	747-04161	Tank Support Rod
27	751-0603	Fuel Cap
28	751-10283	Fuel Tank, 3 Gal.
29	731-05507	Hood Plenum
30	931-05469	Lens, RH
31	931-05471	Lens, LH
32	777X42200	Reflector, RH
33	777X42201	Reflector, LH
34	925-1649	Lamp Socket, 1/4 Turn
35	925-0963	Miniature Lamp, 12V
36	925-1745	Key, Ignition
37	925-04036B	Meter, Systems Indicator
38	725-04340	Module, Ignition Switch
39	746-1084	Throttle/Choke Control
—	929-04083	Headlight Harness
—	725-04339	Wiring Harness

www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models X60RG & X60RH



www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models X60RG & X60RH

REF. NO.	PART NO.	DESCRIPTION
1	17840-0637	Mounting Bracket, Transaxle
2	925-04039	Switch, Interlock
3	17962	Plate, Switch
4	647-04020	Lever Assembly, Shift
5	710-0607	Screw, 5/16-18, 0.500
6	910-0726	Screw, 5/16-12, 0.750
7	710-0809	Screw, 1/4-20, 1.250
8	710-1007	Screw, Sems, 3/8-16, 1.500
9	710-1266	Screw, 5/16-18, 3.50, Gr5
10	910-3144	Screw, 3/8-16, 2.00, Gr5
11	711-0736	Adjustment Ferrule 1/4-20 x 1.
12	912-0241	Nut, Hex, 3/8-24, Gr5
13	712-04063	Nut, Flange Lock, 5/16-18, GrF, Nylon
14	712-04065	Nut, Flange Lock, 3/8-16, GrF, Nylon
15	912-0700	Nut, Flange, 9/16-18, Gr2
16	914-0104	Pin, Cotter, .072 Dia. x 1.13
17	914-0111	Pin, Cotter, 3/32, 1.0
18	914-0209	Cotter Pin, Internal, .125 Dia.
19	914-0470	Pin, Cotter, 1/8 x 1.25
20	918-0758A	Pulley Hub, 5/8 Spline
21	720-04028	Knob, Shift
22	923-3018	Ball Joint
23	731-04602	Sleeve, .758 x .821 x 3.31
24	731-04604	Sleeve, .758 x .821 x 2.4375
25	932-04370	Spring, Extension, .62 Dia x 6.12
26	732-0525	Spring Clip, Shifter
27	732-0716C	Spring, Extension, .59 OD x 4.00
28	732-0963	Spring, Extension, .50 Dia x 6.37
29	936-0169	Washer, Lock, 3/8
30	710-0224	Screw, #10-16, .50
31	738-0372B	Spacer, Shoulder, 1.00 x .38 x .38
32	747-04146B	Rod, Shift
33	747-04164	Rod, Brake
34	747-1127	Idler Rod, Adjustable, 3/8
35	948-0334	Spacer, .68
36	750-0566A	Spacer, .260 x .372 x 1.030
37	954-0467	Belt, V-Type
38	954-0468	Belt, V-Type
39	956-04002	Pulley, V-Type, 7.25 Dia.
40	756-0981B	Idler Pulley, Flat 2.75 OD
41	783-04224	Bracket, Shift
42	783-04360	Bracket, Shift, F-N-R
43	783-04442-0637	Idler Bracket, Center Double
44	647-0031B-0637	Control Assembly, Brake
45	647-0032A-0637	Control Assembly, Speed
46	683-0266	Pedal Assembly
47	910-0650	Screw, 5/16-18, 0.875
48	910-1260A	Screw,5/16-18, 0.750
49	710-1611B	Screw, 5/16-18, 0.750
50	711-04159B	Pin, 3/8-16 x 2.68
51	912-3004A	Nut, Flange Lock, 5/16-18, Gr5
52	732-0335	Spring, Compression, .405 x 1.17
53	732-0955	Spring, Extension, .50 OD x 1.41
54	732-0963	Spring, Extension, .50 OD x 6.37
55	735-0662	Pad
56	735-3049	Pad, Brake
57	936-0187	Washer, Flat, .64 x 1.24 x .06
58	736-0262	Washer, Flat, .385 x .870 x .092
59	936-0300	Washer, Flat, .406 x .875 x .059
60	936-3008	Washer, Flat, .344 x .750 x .120
61	938-0155	Screw, Shoulder .437 Dia x .162
62	938-0380	Screw, Shoulder, .50 x .27 Lg, 3/8-16
63	941-0225	Bearing, Hex Flange
64	741-3065B	Split Bearing, Hex Flange
65	747-04093	Rod, Brake Lock
66	747-04096	Rod, Cruise Control
67	748-04039B	Latch, Cruise Control
68	683-04186	Bracket, Lockout
69	747-04521-0637	Ped, Brake
70	936-0119	Washer, Lock, 5/16
71	918-04034	Transmission, Single Speed
72	683-04055A	Bracket Assembly, Torque
73	683-04130	Bracket, Idler
74	710-0227	Screw, #8-18 x .50
75	710-0514	Screw, 3/8-16, 1.00
76	710-0604A	Screw, 5/16-18, .625
77	710-3290	Screw, 3/8-16, 1.12
78	712-0130	Nut, Lock, 3/8-16, Nylon
79	725-1644	Switch Spring, Short
80	926-0320	Plate, Insulator
81	750-04294	Spacer, Shoulder
82	756-04209	Pulley, V-Type, 3.06
83	956-04015	Pulley Assembly, Variable Speed
84	683-04129	Bracket, Pulley
85	710-0627	Screw, 5/16-24, .750
86	710-0642	Screw, 1/4-20, .750
87	718-04012	Cup, Bearing
88	736-0362	Washer, Flat
89	941-0600	Ball Bearing
90	736-3010	Washer, Flat, .407 x .812 x 135
91	936-0242	Washer, Bell, .340 x .872 x .060

www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models X60RG & X60RH



www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models X60RG & X60RH

REF. NO.	PART NUMBER	DESCRIPTION
1	732-0614	Ring, Wire
2	716-0231	Ring, E Type, .750
3	936-0336	Flat Washer, 5/8 x 1.0 x .030*
	936-0337	Flat Washer, 5/8 x 1.0 x .040*
	936-0349	Flat Washer, 5/8 x 1.0 x .020*
4	936-0335	Washer, Thrust .635 x 1.26 x .06
5	910-1325	Self-tapping Screw, 1/4-20 x 1.625
6	918-04168	Upper Housing
7	711-1109	Input Shaft
8	941-0335	Needle Bearing, .625 x .813 x .495
9	717-1464	14-tooth Bevel Pinion
10	716-0108	Retaining Ring, .437
11	941-0340	Sleeve Bearing, .75 x .1.0 x 1.0
12	921-0338	Seal, .75 x 1.0 x .125
13	918-04096	Differential Assembly
14	941-0336	Flange Bearing, 5/8 x 3/4 x 3/4
15	917-04056	42-tooth Bevel Gear
16	961-0001	Brake Assembly
17	918-04045	Clutch Collar
18	936-0519	Flat Washer, .70 x 1.125 x .031
19	711-04134	Drive Shaft
20	936-0495	Thrust Washer, 1.0 x .632 x .0
21	941-0337	Flange Bearing, 5/8 x 3/4 x 15/16
22	911-0011	Detent Shaft Assembly
23	741-0862	Detent Ball
24	932-0863	Compression Spring
25	919-04018	Lower Housing
26	917-0678	Brake Puck
27	761-0202	Brake Disc
28	910-1206	Self-tapping Screw, 1/4-20 x 2.375
—	737-0148	Grease

*Use applicable flat washer in this application allowing .0150/.0020 in. end-play

NOTE: If rebuilding the upper housing, include two ounces (2 oz.) of a good quality grease in the input shaft cavity.

www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models X60RG & X60RH



www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models X60RG & X60RH

REF. NO.	PART NUMBER	DESCRIPTION
1	17962	Plate, Switch
2	947-04036	Lever Assembly, Engagement
3	714-0145	Click Pin
4	910-0224	Screw, #10-16, 0.500
5	910-0276	Screw, Carriage, 5/16-18, 1.00
6	732-04248	Extension Spring, .38 OD x 3.9 Lg
7	710-3157A	Screw, 7/16-20, 3.25 Gr5 (Model X60RG)
	710-04377	Screw, 7/16-20, 2.75, Gr5 (Model X60RH)
8	910-0726	Screw, 5/16-12, 0.750
9	910-0778	Screw, 1/4-20 x 1.50
10	711-1044A	Pin, Belt Guard, 5/16 x 4.75 (Model X60RG)
11	910-3011	Screw, 3/8-16 x 2.25
12	712-04063	Nut, Flange Lock, 5/16-18, GrF
13	712-04065	Nut, Flange Lock, 3/8-16, GrF
14	912-3004A	Nut, Flange Lock, 5/16-18, Gr5
15	914-0470	Pin, Cotter, 1/8 x 1.25
16	726-0201	Nut, Speed, .3125 ID
17	731-2111A	Knob, PTO
18	746-04092	Deck Engagement Cable
19	750-0566A	Spacer, .260 x .372 x 1.030 Lg.
20	783-04590A-0637	Cable Bracket
21	936-0108	Washer, Flat, .510 x .750 x .033
22	936-0119	Washer, Lock, 5/16
23	936-0242	Washer, Bell, .340 x .872 x .060
24	936-0275	Washer, Flat, .344 x .688 x .065
25	936-0322	Washer, Flat, .450 x1.250 x.164
26	941-0708	Bearing, Flange, Hex Split .500 ID
27	747-1286A	Keeper Rod, Belt (Model X60RG)
28	747-04470	Engagement Handle, Deck
29	748-0415B	Spacer, .385 ID x .635 OD x 1.54
30	910-1260A	Screw, 5/16-18 x .750
31	956-04207	Pulley, Engine, 3.39 x 6.12 Dia. (Model X60RG)
	956-04196	Pulley, Engine, 3.39 x 6.12 Dia. (Model X60RH)
32	783-04467-0637	Stop Bracket, Deck-Up (Model X60RH)
33	783-0744A-0637	Stop Bracket, Engagement
34	710-0607	Screw, 5/16-18, 0.500
35	725-04039	Switch, Interlock
36	783-04612-0637	Support Bracket, Steering
37	736-0173	Washer, Flat, .28 x .74 x .063

www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Model X60RG



www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Model X60RG

REF. NO.	PART NUMBER	DESCRIPTION
1	918-0624	Spindle Assembly, Pul, 6.23” Dia
2	683-04138A-4008	Brake Assembly, Deck
3	983-04261-4008	Deck Shell, 42”
4	983-04167	Brake Assembly, Deck
5	683-0254B-4008	Hanger Bracket Assembly, LH
6	910-3015	Screw, 1/4-20, .75, Gr5
7	910-0654A	Screw, 3/8-16, 1.00
8	910-0528	Screw, 5/16-18, 1.250
9	910-0726	Screw, 5/16-12, 0.750
10	910-0510	Screw, 7/16-20, 3.00, Gr5
11	910-0778	Screw, 1/4-20, 1.500
12	910-1260A	Screw, 5/16-18, .75
13	932-0470A	Extension Spring, .53 OD x 4.75
14	783-05045-4008	Pivot Support Bracket
15	712-3006	Nut, Hex, 1/4-20, Gr5
16	912-0417A	Nut, Flange, 5/8-18
17	938-0373	Screw, Shldr, .498 x 1.53, 3/8-16
18	712-04063	Nut, Flange Lock, 5/16-18, GrF
19	712-04065	Nut, Flange Lock, 3/8-16, GrF
20	912-0641	Nut, Hex, M16-1.5
21	912-3061	Hex Lock Nut, 3/8-24
22	712-0459	Flange Lock Nut, 7/16-20
23	914-0104	Pin, Cot, .072 Dia. x 1.13 Lg
24	917-04074	Gear, Deck Adjustment
25	926-0233	Nut, Push, .25 ID x .50 OD
26	732-0459B	Spring, Exten. , .94 Dia. x 6.74
27	732-04287	Spring, Exten. , .50 Dia. x 6.375
28	734-0973	Wheel, Deck 5.0 x 1.38

REF. NO.	PART NUMBER	DESCRIPTION
29	936-0119	Washer, Lock, 5/16
30	936-0270	Washer, Bell, .265 x.75 x .062
31	783-04740-4008	Deck Engagement Cable Bracket
32	936-0300	Washer, Flat, .406 x .875 x .059
33	936-0760	Washer, Lock
34	936-0187	Washer, Flat, .64 x 1.24 x .06
35	738-04166	Spacer, Shoulder, .500 x .1475
36	738-04146	Plug
37	738-04162A	Spacer, Shoulder, .8840 x .190
38	942-0616A	Blade, 21.23”, Star 3-in-1
39	910-3005	Screw, 3/8-16 x 1.25
40	747-04501	Control Rod, Brake
41	710-0216	Screw, 3/8-16 x .75
42	683-04252-4008	Deck Idler Assembly
43	750-0566A	Spacer, .260 x .372 x 1.030
44	954-04045	Belt, V-Type
45	756-04129	Idler Pulley, 4.25” Dia.
46	747-1116	Deck Release Rod
47	783-04327A-4008	Cover, Belt, 6.00 Dia.
48	750-04637	Spacr, .455 ID x .680 OD
49	710-0347	Screw, 3/8-16 x 1.75
50	931-1032B	Chute Assembly, Discharge
51	736-0407	Bell Washer, .45 x 1.00 x .062
52	735-0271	Bumper
53	912-0431	Flange Lock Nut, 3/8-16
54	914-0470	Cotter Pin
55	932-0306A	Compession Spring, .531x 1.75

www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Model X60RH



www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Model X60RH

REF. NO.	PART NUMBER	DESCRIPTION
1	97116	Brake Assembly, Deck
2	17258E-4008	RH Belt Cover, Deck 46”
3	918-0430A	Spindle Assembly, 5.00 Dia.
4	918-04134B	Spindle Ass’y, Double Pulley
5	683-0254B-4008	Hanger Bracket Assembly
6	983-04254-4008	Deck Weldment
7	710-0520	Screw, 3/8-16, 1.50, Gr5
8	710-0514	Screw, 3/8-16, 1.00, Gr5
9	910-0528	Screw, 5/16-18, 1.25, Gr5
10	910-0599	Screw, 1/4-20, 0.500
11	910-3015	Screw, 1/4-20, .75, Gr5
12	910-0778	Screw, 1/4-20, 1.500
13	710-0805	Screw, 5/16-18, 1.50, Gr5
14	910-1260A	Screw, Ld, 5/16-18, 0.750
15	910-1026	Screw, 1/4-20 x 1.75
16	936-0247	Washer, Flat, .406 x 1.25 x .157
17	911-0993	Belt Guard Pin 1/4 Dia x 1.43
18	711-1554	Pin, 1/4-20, 3/8 x 2.0
19	783-04991-4008	Brake Bracket
20	712-04063	Nut, Flange Lock, 5/16-18, GrF
21	712-04064	Nut, Flange Lock, 1/4-20, GrF
22	712-04065	Nut, Flange Lock, 3/8-16, GrF
23	912-0417A	Nut, Flange, 5/8-18
24	912-0431	Nut, Flange Lock, 3/8-16, GrF
25	912-0641	Nut, Hex, M16-1.5
26	712-3006	Nut, Hex, 1/4-20, Gr5
27	738-0322	Shoulder, Screw, .625 Dia. x .217
28	750-04456	Spacer, .260 x .372 x 1.420 Lg.
29	914-0470	Pin, Cot, 1/8 x 1.25
30	917-04074	Adjustment Gear, Deck
31	926-0233	Nut, Push, .25 ID x .50 OD
32	932-0306A	Spring, Compress, .531 OD x 1.75
33	932-0429A	Spring, Extension, .50 Dia x 3.97
34	932-0594A	Spring, Extension, .91 Dia x 7.33
35	732-0944	Spring, Extension, .75 OD x 6.75
36	734-0973	Wheel, Deck 5.0 x 1.38
37	936-0119	Washer, Lock, 5/16
38	936-0211	Washer, Flat, .285 x 1.25 x .06
39	936-0270	Washer, Bell, .265 x.75 x .062
40	936-0418A	Washer, Flat, .34 x 2.25 x.10
41	736-0225	Washer, Lock, 5/8
42	931-1032B	Chute Assembly
43	938-0347	Spacer, Shoulder, .625 ID x .169
44	938-0373	Spacer, Shoulder, .498 x 1.53
45	738-04146	Plug
46	942-0611A	Blade, 16.28”, Star 3-in-One
47	942-0612A	Blade, 14.88”, Star 3-in-One
48	738-04216	Shld. Screw, .625 x 2.515 x .875
49	747-1116	Rod, Deck Release
50	910-0623	Screw, 3/8-16 x .750
51	748-0234	Shoulder Spacer
52	750-0566A	Spacer, .260 x .372 x 1.030
53	750-1320	Spacer, .375 x .63 x .595
54	954-0349	Belt, V-Type, Poly, A x 79.10 Lg.
55	754-04122	Belt, V-Type, A x 90.24
56	756-04129	Pulley, Idler, 4.25” Dia.
57	783-1348C-4008	Belt Cover, LH
58	783-0141-4008	Deck Skirt, Center
59	783-0142-4008	Deck Skirt, RH
60	783-04641-4008	Bracket, Idler
61	683-04250-4008	Idler Bracket Assembly - LH
62	683-04251-4008	Idler Bracket Assembly - RH

www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

Models X60RG & X60RH



REF. NO.	PART NUMBER	DESCRIPTION
1	910-0227	Screw, #8-18, 0.500
2	910-0599	Screw, Hex, 1/4-20, 0.500
3	910-0642	Screw, Hex, 1/4-20, 0.750
4	910-0654A	Screw, Hex, 3/8-16 x 1.00
5	751-0617B	Muffler, Single Inlet
6	725-0157	Cable, Tie, 3/16 x .05 x 7.4
7	783-05106-0637	Shield, Heat
8	683-04256-0637	Shield, Muffler
9	751-10353	Extension, Deflector
10	751-0564A	Deflector, Muffler
11	783-04573-0637	Muffler Bracket, LH
12	783-04574-0637	Muffler Bracket, RH
13	751-10017	Pipe, Exhaust
14	951-3140	Drain, Oil
15	751-3141-14	Extension Hose, Oil Drain
16	951-3142	Cap, Oil Drain
17	751-10349-16	Fuel Hose, Low Permeation
18	726-0205	Clamp
19	728-04000	Rivet, Pop, .188 x .325

www.mymowerparts.com

For Parts Call 606-678-9623 or 606-561-4983

www.mymowerparts.com