


31AH54K3897 (2010)
2 Way Chute Control

Page 1 of 28



31AH54K3897 (2010)
2 Way Chute Control

Page 2 of 28

Ref #	Part Number	Qty	S/P/F	Description
1	711-05329	1		Hex Shaft
2	731-06440A	1	/P	Tall Lower Chute
3	984-04325	1	/P	2 Way Chute Control Assembly
4	790-00342B-0637	1	/P	Chute Gear Ro ta tion Bracket
5	710-0262	1	/P	Carriage Bolt 5/16-18 x 1.50 Gr. 2
6	710-04071	1		Carriage Screw 5/16-18 x 1.0
7	710-04187	1	/P	Hi-Lo Screw 1/4-15 x .5
9	736-3072	1	/P	Flat Washer .38 x .92 x .110
10	710-0895	1		Hex Tapp Scr 1/4 x .75" Lg.
11	711-04469A	1		Clevis Pin 3/8 x 1.87
12	714-04040	1		Bow Tie Cotter Pin
13	712-04063	1	/P	Flange Locknut 5/16-18 Gr. F Nylon
14	712-3087	1	/P	Wing Nut 1/4-20
15	731-04425B	1		Upper Chute w/Ex port Label, Remote
16	731-1313C	1	/P	Cable Guide
20	720-04072A	1	/P	Handle Knob Assembly
21	784-5594	1		Cable Bracket Chute Tilt
22	712-04064	1	/P	Hex L-Flanged Nut 1/4-20 Gr. F Nylon
24	736-0290	1	/P	Flat Washer .625 x 1.0 x .067
25	936-0159	1	/P	Flat Washer .349 ID x .879 OD x .063
26	941-0225	1	/P	Hex Flg. Bearing
27	732-04756	1		Compression Spring .39 x .60 x .88
28	741-04388	1		Hex Bearing
29	710-0627	1	/P	Hex Hd. Cap Screw 5/16-24 x .75
30	736-04446	1		Flat Washer .25 ID x .63 OD x .0515 HT.
31	790-00341	1		Support Rod Bracket
32	720-04039	1		Knob
33	731-05307	1		Control Cover - 2 Way
35	736-0413	1	/P	Spring Washer .390 x .625 x .012
36	738-04185	1		Flg Shlder Screw .310 x .995: 1/4-20
37a	946-04527	1	/P	Cable
37b	946-04551	1	/P	Cable
38	790-00200	1		Mount ing Bracket - 2 Way
39	790-00210A	1		Lever - 2 Way
41	918-04933	1	/P	Gear box Assembly
42	710-1652	1	/P	Hex Wash Hd TT Scr. 1/4-20 x .625
43	731-06451	1		Cable Guide
44	926-0100	1	/P	Push Nut 3/8" Rod
45	738-04367	1		Flg. Shoulder Screw .312 x 3.5: 1/4-20
46	914-0101	1	/P	Internal Cotter Pin
47	710-04370	1		Hex. Hd. Cap Scr. 1/4-20 x 3.0 Gr. 5
48	747-05386-0637	1	/P	Chute Crank .375 Dia. x 30.5" Lg.
49	720-04102	1		Knob
50	936-0185	1	/P	Flat Washer .375 x .738 x .063
51	710-04373A	1		Hi-Lo Screw #12-16 x .75
52	712-04065	1	/P	Hex L-Flanged Nut 3/8-16 Gr. F Nylon
53	717-04667	1		Gear 14 teeth helical w/hub
54	717-04672	1		Worm - Nylon
55	731-07529	1		Cover
56	684-04310A-0637	1	/P	Chute Sup. Bkt. Ass'y (w/277 cc & 357 cc engines only)
57	684-04311A-0637	1	/P	Chute Support Bracket Ass'y


31AH54K3897 (2010)
2 Way Chute Control

Page 3 of 28

Ref #	Part Number	Qty	S/P/F	Description
58	731-07525	1		Chute Adapter
59	710-0703	1	/P	Carriage Screw 1/4-20 x .75 Gr. 5
60	712-04064	1	/P	Hex L-Flanged Nut 1/4-20 Gr. F Nylon

31AH54K3897 (2010)
478-SU-10-Carburetor Assembly

Page 4 of 28




31AH54K3897 (2010)
478-SU-10-Carburetor Assembly

Page 5 of 28

Ref #	Part Number	Qty	S/P/F	Description
132	951-11193A	1	/P	Carburetor Assembly
133	951-10639A	1	/P	Primer Assembly
134	951-11824	1	/P	Primer Bulb
a		1		Choke Shaft
b		4		Lock Washer
c		5		Screw M3×5
d		1		Choke Plate
e		1		Throttle Shaft
f		1		Throttle Plate
g		1		Lock Plate
h		1		Idle Jet Assembly
i		1		Idle Speed Adjusting Screw
j		1		Mixture Screw
k	751-12082	1		Primer Hose
l		2		Hose Clamp
m		1		Carburetor Body
n		1		Float Pin
o		1		Emulsion Tube
p		1		Needle Valve
q		1		Main Jet
r		1		Needle Valve Spring
s		1		Float
t	751-11970	1	S	Fuel Bowl Gasket
u		1		Fuel Bowl
v	751-11348	1	S	Fuel Bowl Gasket
w	710-04945	1		Fuel Bowl Mounting Bolt
x	751-11349	1	S	Fuel Drain Plug Gasket
y	710-04903	1	S	Fuel Drain Plug
	951-11219	1	/P	Carburetor Repair Kit - Major (Incl. Ref No. g,n,o,p,q,r,s,t,v & x) Not shown

31AH54K3897 (2010)
478-SU-10-Crankcase & Lubrication

Page 6 of 28



31AH54K3897 (2010)
478-SU-10-Crankcase & Lubrication

Page 7 of 28

Ref #	Part Number	Qty	S/P/F	Description
41	751-12066	1	S	Connecting Rod Assembly
42	751-12043	1	S	Piston
43	951-11632	2	/P	Piston Pin Snap Ring
44	751-12044	1	S	Piston Pin
45	751-12067	1	S	Piston Ring Assembly
49	751-12068	1		Governor Gear/Shaft Asm
50	751-12069	2	S	Radial Ball Bearing
51	736-04453	1		Washer 8×20×0.8
52	714-04077	1		Cotter Pin
53	751-12070	1	S	Governor Seal
54	751-12071	1	S	Governor Arm Shaft
55	951-11229	1	/P	Crankshaft Kit (Incl. Ref No. 50,55,56,65 & 81)
56	951-10307	1	/P	Woodruff Key
57	715-04102	1		Dowel Pin 9×12
58	715-04092	1		Dowel Pin 7×14
59	751-12072	1	S	Camshaft Assy.
60	951-11374	1	/P	Crankcase Cover Gasket
61	736-04545	1		Washer 16×24×0.5
62	951-11577	1	/P	O-Ring 15.8×2.5
63	951-11377	1	/P	Oil Filler Plug Assembly
64	951-11228	1	/P	Crankcase Cover Kit (Incl. Ref No. 50,60,61,64-67)
65	951-11372	1	/P	Oil Seal,30×46×8
66	710-04971	5		Bolt M8×38
67	710-04972	1		Bolt M8×45
68	710-05052	2		Bolt M8×35
69	710-04968	1	/P	Bolt M6×16
70	951-11320	1	/P	Oil Tube Support Bracket
71	710-04966	1		Bolt M6×8
73	951-11903	2	/P	Oil Fill Tube O-Ring
74	751-12073	1	S	Oil Fill Tube Asm
75	951-11934	1	/P	Dipstick O-Ring
76	751-12074	1	S	Dipstick Asm
77	951-11230	1	/P	Crankcase Kit (Incl. Ref No. 50,53,77 & 81)
78	951-11350	1	/P	Oil Drain Pipe
79	736-04440	1	/P	Washer 10×16×1.5
80	710-04906	1		Oil Drain Plug
81	951-11498	1	/P	Oil Seal 30×46×8
126	951-11180	1	/P	Cylinder Baffle
127	710-04915	2		Bolt M6×12
144	951-11377	1	/P	Oil Filler Plug Assembly
145	951-10641	1	/P	Oil Drain Assembly
	951-11187	1	/P	Short Block Assembly (Incl. Ref No. 41-45,49-68,77-81,102,105,106,108,110,123,1 & 130) Not shown
	951-11230	1	/P	Crankcase Kit (Incl. Ref No. 50,53,77 & 81) Not shown
	951-11229	1	/P	Crankshaft Kit (Incl. Ref No. 50,55,56,65 & 81) Not shown


31AH54K3897 (2010)
478-SU-10-Crankcase & Lubrication

Page 8 of 28

Ref #	Part Number	Qty	S/P/F	Description
	951-11228	1	/P	Crankcase Cover Kit (Incl. Ref No. 50,60,61,64-67) Not shown
	952Z478-SU-10	1	/P	Complete Engine Not shown

31AH54K3897 (2010)
478-SU-10-Cylinder Head

Page 9 of 28




31AH54K3897 (2010)
478-SU-10-Cylinder Head

Page 10 of 28

Ref #	Part Number	Qty	S/P/F	Description
100	951-11198	1	/P	Exhaust Valve
101	951-11198	1	/P	Intake Valve
102	951-11962	2	/P	Tappet
103	951-11199	2	/P	Push Rod Kit
104	951-11188	1	/P	Cylinder Head Assembly
105	715-04097	2		Dowel Pin 12×20
106	751-12076	1	S	Gasket,Cylinder Head
107	951-10292	1	/P	Spark Plug
108	951-11212	1	/P	Exhaust Pipe Gasket
109	710-04964	2		Muffler Stud M8×48.5
109	951-11207	1	/P	Muffler Stud Assembly
110	710-04973	4		Bolt M10×1.25×80
111	951-11964	1	/P	Intake Valve Seal
112	751-12077	2	S	Valve Spring Retainer
113	751-12078	2	S	Valve Spring
114	751-12080	2	S	Retainer,Ex.Valve Spring
115	751-12081	2	S	Adjuster,Exh Valve
116	951-11965	1	/P	Push Rod Guide
117	951-11981	2	/P	Rocker Arm Assembly
118	710-04962	2		Bolt,Pivot
119	951-11966	2	/P	Rocker Arm
120	751-11123	2		Adjusting Nut ,Valve
121	751-11124	2		Nut,Pivot Locking
122	710-05054	5		Valve Cover Bolt
123	951-11967	1	/P	Valve Cover Gasket
124	951-11220	1	/P	Valve Cover
128	710-04963	2		Carburetor Stud M6-8×106
129	951-11225	1	/P	Intake Gasket
130	951-11222	1	/P	Carburetor Insulator
131	951-11223	1	/P	Carburetor Gasket
141	726-04101	1		Hose Clamp
142	951-11221	1	/P	Breather Hose
146	951-11333	1	/P	Valve Cover Kit
	951-11226	1	/P	Cylinder Head Kit (Incl. Ref No. 106,110,111 & 123) Not shown
	951-11188	1	/P	Cylinder Head Assembly (Incl. Ref No. 100,101,104,106,108-116,118-121,123,128-130) Not shown
	951-11187	1	/P	Short Block Assembly (Incl. Ref No. 41-45,49-68,77-81,102,105,106,108,110,123,141 & 130) Not shown

31AH54K3897 (2010)
478-SU-10-Fuel Tank & Mounting

Page 11 of 28




31AH54K3897 (2010)
478-SU-10-Fuel Tank & Mounting

Page 12 of 28

Ref #	Part Number	Qty	S/P/F	Description
16	951-10649	1	/P	Fuel Cap Assembly
17	951-11933	1	/P	Fuel Level Indicator
18	710-04970	4		Bolt M8×20
19	750-05312	2		Bushing I, Gas Tank
20	750-05313	2		Bushing II, Gas Tank
21	951-11201	1	/P	Fuel Tank Assembly
22	951-11184	1	/P	Fuel Tank Shroud
23	951-11183	1	/P	Fuel Tank Mounting Bracket
24	951-11419	1	/P	Engine Shroud
25	710-04968	4	/P	Bolt M6×16
26	736-04452	4		Flat Washer
27	951-11200	1	/P	Fuel Line Kit
28	951-11700	2	/P	Fuel Hose Clamp
29	710-04921	4		Bolt M8×14
30	951-11182	1	/P	Gas Tank Support Bracket
31	712-04219	1		Nut M8
33	712-04212	1	/P	Nut M6
34	710-04908	1		Governor Arm Bolt
35	951-11231	1	/P	Governor Arm
36	951-11202	1	/P	Governor Spring
37	951-11203	1	/P	Throttle Return Spring
38	951-11204	1	/P	Governor Rod
39	951-11213	1	/P	Throttle Control Asm
40	710-04916	1		Bolt,M6×14
	951-10651	1	/P	Fuel Tank Nipple Not shown

31AH54K3897 (2010)
478-SU-10-Muffler & Controls

Page 13 of 28




31AH54K3897 (2010)
478-SU-10-Muffler & Controls

Page 14 of 28

Ref #	Part Number	Qty	S/P/F	Description
1	710-04916	1		Bolt, M6×14
2	951-11194	1	/P	Muffler Shield
3	710-04941	8		Bolt M6×12
4	951-11224	1	/P	Throttle Control Knob
5	951-11594	1	/P	Control Panel
7	731-05632	1		Key
8	951-10637	1	/P	Key Switch Assembly
9	951-11302	1	/P	Choke Knob
10	710-04940	3		Bolt M6×10
11	951-11181	1	/P	Muffler Baffle
12	951-11227	1	/P	Carb Isolator Bracket
13	710-04968	1	/P	Bolt M6×16
14	951-11195	1	/P	Muffler Assembly
15	712-04219	2		Nut, M8

31AH54K3897 (2010)
478-SU-10-Starter Assembly & Blower Housing

Page 15 of 28



31AH54K3897 (2010)


Page 16 of 28

478-SU-10-Starter Assembly & Blower Housing

Ref #	Part Number	Qty	S/P/F	Description
46	710-04965	2		Bolt M4×55
47	951-11196	1	/P	Electric Starter
48	710-04967	2		Bolt M8×55
82	951-11197	1	/P	Ignition Coil Assembly
83	710-04920	2		Ignition Coil Bolt
84	751-12075	1	S	Stator
85	710-04969	2		Bolt M6×30
86	710-04966	1		Bolt M6×8
87	951-11186	1	/P	Alternator Wire Clamp Brkt
88	751-12090	1	S	Flywheel
89	951-11217	1	/P	Fan, Cooling
90	951-11218	1	/P	Starter Cup
91	712-04220	1		Nut, Special,M16×1.5
92	710-04968	1	/P	Bolt M6×16
93	710-04915	4		Bolt M6×12
95	951-11379	1	/P	Blower Housing
96	951-11208	1	/P	Recoil Starter
97	736-04455	3		Washer
98	710-04974	3		Bolt M6×10
136	951-11190	1	/P	Heater Box
137	951-11192	1	/P	Choke Assembly
138	736-04477	2		Lock Washer
139	712-04212	2	/P	Nut M6
143	731-05696	1		Starter Handle

31AH54K3897 (2010)
Auger & Housing Assembly

Page 17 of 28



31AH54K3897 (2010)
Auger & Housing Assembly

Page 18 of 28

Ref #	Part Number	Qty	S/P/F	Description
1	931-2643	1	/P	Clean-Out Tool
2	684-04057A-0637	1	/P	Impeller Ass'y 12 po
3	710-0347	1	/P	Hex Screw 3/8-16 x 1.75
4	710-0451	1	/P	Carriage Bolt 5/16-18 x .75
7	712-04063	1	/P	Flange Locknut 5/16-18 Gr. F Nylon
9	712-04065	1	/P	Hex L-Flanged Nut 3/8-16 Gr. F Nylon
10	725-0157	1	/P	Cable Tie
11	731-04871	1		Spacer 1.25 x .75 x 3/16" Lg.
12	926-04012	1	/P	Push-on Nut .25 dia.
14	732-04460	1		Extension Spring .38 OD x 4.59" Lg.
15	736-0174	1	/P	Wave Washer .660 ID x .88 OD x .010
16	731-2635	1		Cleanout Tool Mount
17	738-0143	1	/P	Shld. Scr. .500 Dia. x .335" Lg.
18	938-0281	1	/P	Shoulder Scr .625 Dia x .170
19	720-04072A	1	/P	Hand Knob
20	941-0245	1	/P	Hex. Flange Brg. .751" I.D.
21	941-0309	1	/P	Self-aligning Bearing
22	756-04224	1	/P	Flat Idler Pulley 2.75" OD
23	790-00075	1		Bearing Housing 1.85 ID
24	790-00080A-0637	1	/P	Auger Idler Brake Bracket
25	710-04484	1		Hex TT Screw 3/8-16 x .75
27	684-04107-0637	1		Spiral Ass'y LH
28	684-04108-0637	1		Spiral Ass'y RH
29	714-04040	1		Bow Tie Cotter Pin
31	736-0188	1	/P	Flat Washer .760 ID x 1.49 OD
32	738-04124A	1	/P	Shear Pin .25 x 1.5 Gr. 2
33	741-0493A	1	/P	Flange Bushing
34	790-00087A-0637	1	/P	Bushing Housing
34	790-00138A-0637	1	/P	Bushing Housing (w/grease Fitting hole)
38	790-00181-0606	1		Drift Cutter - optional
39	790-00091-0606	1		Reversible Slide Shoe (steel)
40	937-3000	1	/P	Grease Fitting (optional)
41	731-04870	1		Spacer 1.25 x .75 x 1.00
42	741-0661A	1	/P	Flange Bearing .75 ID x 1.0 OD x .975
43	746-04230	1		Auger Clutch Cable
44	784-5580	1		Slide Shoe
45	918-0123A	1	/P	RH Reduced Auger Housing
46	918-0124A	1	/P	LH Reduced Auger Housing
47	921-0338	1	/P	Oil Seal .75 x 1.0 x .125
48	741-0662	1		Flange Bearing .75 ID x 1.00 OD x .50
49	710-0642	1	/P	Thd Forming Scr. 1/4-20 x .75
51	914-0161	1	/P	Hi Pro Key 3/16 x 5/8
52	715-04021	1		Dowel Pin .25 OD x 1.2
53	917-04126	1	/P	Worm Shaft .75 OD
54	917-04861	1	/P	Worm Gear 20T (22", 24" & 26")
54	917-0528A	1	/P	Worm Gear 20T (28" & 30")
55	718-04071	1		Thrust Collar
56	721-0325	1		Plug, 1/4 x .437
57	721-0327	1		Oil Seal .75 x 1 x .131
58	936-0351	1	/P	Flat Washer .76 ID x 1.5 OD x .03
59	736-3084	1	/P	Fl. Washer .510 x 1.120 x .060
60	741-0663	1		Flange Bearing .75 ID x 1.0 OD x .925
61	736-0242	1	/P	Flat Washer .345 ID x .88 OD x .060


31AH54K3897 (2010)
Auger & Housing Assembly

Page 19 of 28

Ref #	Part Number	Qty	S/P/F	Description
62	N/A	1		Loctite Seal ant 5699
63	737-0168A	1	/P	Grease - Alvania EP Lead Free
64	731-05984A	1	/P	Reversible Slide Shoe (plas tic)
65	710-0451	1	/P	Carriage Bolt 5/16-18 x .75 (w/steel slide shoes)
66	731-06439	1		Small Reversible Slide Shoe (plas tic)
67	936-0159	1	/P	Flat Washer .349 ID x .879 OD x .063
68	684-04270-0606	1		Auger Housing - 24"
68	684-04271-0606	1		Auger Housing - 26"
68	684-04272-0606	1		Auger Housing - 28"
68	684-04273-0606	1		Auger Housing - 30"
69	790-00120-0606	1		Shave Plate - 24"
69	790-00121-0606	1		Shave Plate - 26"
69	790-00118-0606	1		Shave Plate - 28"
69	790-00119-0606	1		Shave Plate - 30"
70	918-04171B	1	/P	Gearbox Assy - 24"
70	711-04285	1		Auger Axle - 24"
70	918-04172B	1	/P	Gearbox Assy - 26"
70	711-04284	1		Auger Axle - 26"
70	918-04173A	1	/P	Gearbox Assy - 28"
70	711-04283	1		Auger Axle - 28"
70	918-04165A	1	/P	Gearbox Assy - 30"
70	711-04282	1		Auger Axle - 30"
71	731-04870	1		Spacer
	753-06206	1		Standard Polymer Reversible Shoe Kit (Will replace 731-06439, Incl. Hardware) Not shown
	753-06205	1		Deluxe Polymer Reversible Shoe Kit (Will replace 731-05984A, Incl. Hardware) Not shown

31AH54K3897 (2010)
Drive Assembly

Page 20 of 28



31AH54K3897 (2010)
Drive Assembly

Page 21 of 28

Ref #	Part Number	Qty	S/P/F	Description
1	710-1652	1	/P	Hex Wash Hd TT Scr. 1/4-20 x .625
2	731-06401	1		Belt Cover (w/277 cc - 357 cc engines)
2	731-05353	1		Belt Cover (w/208 cc engines)
3	732-04677	1		Cable Control Wire
4	711-1268B	1		Drive Shaft Actuator
5	746-04229	1		Drive Clutch Cable 44.83" Lg.
6	732-04345	1		Extension Spring .5 OD x 1.71 Lg.
7	790-00207B	1		Guide Bracket - Drive Cable
8	684-04156A	1		Shift Rod Ass'y
9	750-04474	1		Axle Support Tube
10	914-0126	1	/P	#9 HI-Pro Key 3/16 x 3/4 Dia HT
12	917-04210	1	/P	Gear, 56T
13	712-04063	1	/P	Flange Lock-Nut 5/16-18 Gr. F Nylon
14	941-0245	1	/P	Hex. Flange Bearing.751" ID
15	790-00206A-0637	1	/P	Guide Bracket - Auger Cable
16	756-0625	1		Cable Guide Roller
17	738-0924A	1	/P	Hex Shld.Scr.1/4-28 x .375
18A	618-04288	1		Dogg Assembly - LH
18B	618-04287	1		Dogg Assembly - RH
19	926-04012	1	/P	Push Nut
20	750-04477A	1		Spacer .340 x .750 x .360" Lg.
21	936-0329	1	/P	L-Wash 1/4 ID
22	732-04311	1		Torsion Spring .750 ID x .968" Lg.
23	731-05297	1		Spacer
24	916-0104	1	/P	Retaining Ring
25	736-0188	1	/P	Flat Washer .760 ID x 1.49 OD
26	736-0626	1		Flat Washer .580 x 1.125 x .080
27	741-04076	1		Ball Bearing
28	938-04180	1	/P	Axle
30	710-0654A	1	/P	Hex Wash HD Tap Scr 3/8-16 x .88
31	710-0788	1	/P	Hex Bolt 1/4-20 x 1.00
32	790-00185	1		Shaft Retainer - LH
34	736-0242	1	/P	Cupped Washer .345 ID x .88 OD x .060
35	738-04439	1		Shoulder Screw .50 x .145: 5/16-24
36	684-04154B	1		Friction Wheel Support Brkt Ass'y
37	790-00096-0637	1	/P	Auger Cable Guide Bracket
38	748-0190	1	/P	Spacer .513 ID x 1.0
39	738-04184A	1		Shoulder Screw .373 x .105:TT 1/4-20
40	790-00316-0606	1		Frame Cover
41	656-04055	1		Friction Wheel Disc Assembly
42	918-04322A	1	/P	Drive Shaft Assembly (w/o Friction Wheel Ass'y)
42A	711-04416A	1		Hex Drive Shaft (500)
42B	918-04284	1	/P	Planetary Carrier Ass'y
42C	717-1209A	1	/P	Gear 12T
42D	936-0502	1	/P	Flat Washer .58 x 1.12 x .02
42E	936-0336	1	/P	Flat Washer 5/8 ID x 1.0 OD
42F	717-1210A	1	/P	Gear 18T
42G	918-04285	1	/P	Ring Planetary Gear Ass'y (500)
42H	716-0194	1	/P	Retaining Ring 1.56 diam.
43	684-04159	1		Friction Wheel Assembly
43A	935-04054	1	/P	Friction Wheel Rubber

31AH54K3897 (2010)
Drive Assembly

Page 22 of 28

Ref #	Part Number	Qty	S/P/F	Description
43B	790-00174	1		Friction Plate
44	716-0136	1		Retainer Ring
45	726-0221	1	/P	Cap Speed Nut 1/4 Rod
46	790-00183B-0606	1		Wheel Drive Frame
47	756-04109	1		Auger Pulley
48	736-0505	1		Flat Washer .34 x 1.50 x .150
49	710-1245B	1	/P	Hex Bolt 5/16-24 x 0.875
50	936-0119	1	/P	L-Wash 5/16 ID
51	790-00230	1		Bearing Sleeve
52	941-0919	1	/P	Ball Bearing 20 x 47 x 14:6204:DS
53	750-04571	1		Spacer
54	732-04308A	1	/P	Torsion Spring .850 ID x .354" Lg.
55	710-0672	1	/P	Hex HD. Cap Scr. 5/16-24 x 1.25 Lg.
56	756-04252	1		Pulley Half
57	954-04260	1	/P	Belt 3/8 x 34.13" Lg.(w/208 cc engines)
57	954-04201A	1	/P	Belt 3/8 x 35.68" Lg.(w/277cc - 357cc engines)
58	710-0809	1		Hex Bolt 1/4-20 x 1.25
59	790-00208C	1	/P	Wheel Drive Idler Bracket
60	748-04112B	1	/P	Shoulder Spacer
61	932-0264	1	/P	Extension Spring 3/8 OD x 2.50
62	712-0417A	1	/P	Jam L-Nut 5/8-18 Gr. 5 Nylon
63	750-04303	1		Spacer .875 ID x 1.185 OD
64	756-04113	1		Pulley Half
65	736-0247	1	/P	Flat Washer .40 ID x 1.25 OD x .160
66	710-0191	1	/P	Hex Screw 3/8-24 x 1.25
67	748-04053A	1	/P	Pulley Adapter
68	946-0956B	1	/P	Steering Cable
69	790-00186	1		Shaft Retainer - RH
70	750-0767	1		Axle Spacer
71	712-04065	1	/P	Flange Lock-Nut 3/8-16 Gr. F Nylon
72	954-04050	1	/P	Belt .5 x 35.0" Lg. (w/208 cc engines)
72	954-04195	1	/P	Belt .5 x 37.0" (w/277cc - 357cc engines)
73	710-0751	1	/P	Hex Bolt 1/4-20 x .62 Gr. 5
74	790-00217A-0637	1	/P	Pivot Bracket
75	790-00218A-0637	1	/P	Shift Bracket
76	712-04064	1	/P	Flange Lock-Nut 1/4-20 Gr. F Nylon
77	710-0896	1	/P	Hex Wash. Hd. TT Scr. 1/4-14 x .625
79	736-0320	1	/P	Flat Washer .38 x 1.38 x .125 (Rear left hole)
80	735-04100	1		Plug 1/2"
81	735-04099	1		Plug 3/8"
82	936-3015	1	/P	Flat Washer .469 x .875 x .105
83	790-00289A-0637	1	/P	Cover Plate (optional)
84	746-04230	1		Auger Clutch Cable 47.23" Lg.
85	710-04022	1		Hex. Hd. Cap Scr. M8-1.25:20 Gr. 8
86	936-0264	1	/P	Flat Washer .330 ID x .630 OD x .0635
87	634-04145-0911	1		X-Trac LH 16 x 4.8 x 8 26"
87	634-04146-0911	1		X-Trac RH 16 x 4.8 x 8 26"
87	734-2038-0901	1	/P	Tire Only 26" (not shown)
87	634-04173-0662	1	/P	Rim Only 26" (not shown)
87	634-04136-0911	1		X-Trac LH 16 x 6.5 x 8 28" & 30"
87	634-04137-0911	1		X-Trac RH 16 x 6.5 x 8 28" & 30"


31AH54K3897 (2010)
Drive Assembly

Page 23 of 28

Ref #	Part Number	Qty	S/P/F	Description
87	734-2031	1		Tire Only 28" & 30" (not shown)
87	634-04174-0662	1		Rim Only 28" & 30" (not shown)
87	634-04147A-0911	1		X-Trac LH 15 x 5 x 6 24"
87	634-04148A-0911	1		X-Trac RH 15 x 5 x 6 24"
87	734-04012-0901	1	/P	Tire Only 24" (not shown)
87	634-04172A-0662	1	/P	Rim Only 24" (not shown)
88	731-04873	1		Spacer All Models

31AH54K3897 (2010)
Handle & Panel Assembly

Page 24 of 28



31AH54K3897 (2010)
Handle & Panel Assembly

Page 25 of 28

Ref #	Part Number	Qty	S/P/F	Description
1	931-04183	1	/P	Handle Panel Ass'y-Black w/Chute Control
2	631-04133A	1	/P	LH Clutch Lock Handle Ass'y
3	631-04134B	1		RH Clutch Lock Handle Ass'y
4	684-04105B	1	/P	Engagement Handle Assembly LH - Black
5	684-04106B	1	/P	Engagement Handle Assembly RH - Black
6	710-04326	1		Screw #8-16 x .50
7	710-3069	1	/P	Hex Cap Socket Screw 1/4-20 x .5
8	710-0837	1		Oval HD C-Sunk Scr #10 x 5/8
9	710-04586	1		Hex TT-Tap Scr 1/4-20 x 1.625
10	710-1233	1	/P	Oval C-Sunk Hd Screw 10-24 x 1.375
11	684-04250	1	/P	Pivot Rod
12	936-0119	1	/P	Lockwasher 5/16 ID
13	710-1880	1		Hex TT Screw 5/16-18 x .75 Gr. 5 Patch
14	712-04064	1	/P	Hex L-Flanged Nut 1/4-20 Gr. F Nylon
15	712-04081A	1		Hex Shoulder Nut 1/4-20
15	712-04064	1	/P	Hex L-Flg Nut 1/4-20 Gr. F Nylon
16	N/A	1		Handle Panel Ass'y Not used in this application
17	749-04191A	1		Upper Handle LH
18	720-0274	1	/P	Grip
19	720-04039	1		Shift Knob
20	725-1629	1		Lamp
21	925-04137	1	/P	Wire Harness
22	725-05148	1		Heated Grip Wire Harness
23	925-1649	1	/P	Socket
24	725-04393	1		Switch
25	725-05149	1		Heated Grip
26	926-0154	1	/P	Cable Tie (w/plug)
26	725-0157	1	/P	Cable Tie (w/heated grips)
27	731-04894D	1	/P	Lock Plate
28	731-04896B	1	/P	Clutch Lock Cam
29	732-0193	1	/P	Compression Spring .38 ID x .88 Lg
30	732-04219C	1	/P	Spring: Clutch Lock
31	732-04238	1		Torsion Spring .8156 x .3038
32	935-0199A	1	/P	Rubber Bumper
33	749-04190A	1	/P	Upper Handle RH
34	936-0267	1	/P	Flat Washer .38 ID x .87 OD x .09
35	738-04348	1	/P	Shoulder Screw .437 x 1.345: 1/4-20
36	738-04125	1		Shoulder Screw .374 Dia. x 1.05 Lg.
37	936-0275	1	/P	Flat Washer .344 ID x .688 OD x .065
38	946-04396A	1	/P	Selector Speed Cable
39	720-04072A	1	/P	Handle Knob Assembly
40	790-00311A	1		Shift Lever
41	790-00248B-0637	1	/P	Panel Support
42	914-0145	1	/P	Cotter Pin
43	710-0572	1	/P	Carriage Bolt 5/16-18 x 2.25
44	749-04138A	1	/P	Lower Handle
45	716-04036	1		E Ring
46	731-04913	1		Steering Control - Black
46	731-04954	1		Steering Control - Yellow
47	738-04126	1		Pin 3/16
48	N/A	1		Handle Panel Ass'y - Red (w/lens)


31AH54K3897 (2010)
Handle & Panel Assembly

Page 26 of 28

Ref #	Part Number	Qty	S/P/F	Description
49	731-05324	1		Lens
50	710-0599	1	/P	Hex Wash S-Tapp Scr 1/4-20 x .50

31AH54K3897 (2010)
Label Map 90026PC

Page 27 of 28



31AH54K3897 (2010)
Label Map 90026PC

Page 28 of 28

Ref #	Part Number	Qty	S/P/F	Description
777D14906	777D14906	1		LABEL-SNOW PANEL LH
777S33641	777S33641	1		LBL-AUGR HSG SAFETY PICTORIAL
777D14894	777D14894	1		LBL:SNOW:AUG LT 26IN COLUM
777D14898	777D14898	1		LBL:SNOW:AUG RT 90026PC
777D14880	777D14880	1		LBL:SNOW/ENG/SPN:277/ES:CAN
777D14801	777D14801	1		LBL-POWERMORE ENG
777S32823	777S32823	1		LBL:SNW:CHUTE:EXP Mold In
777CI00143	777CI00143	1		LABEL-SNOW CONTROL PANEL STYLE 0
777CI00139	777CI00139	1		LABEL-SNOW CONTROL PANEL